



North American Market

SUPER DC INVERTER SERIES

Service Manual 2014

LISAS-B-1405



Part 1 General Information	1
Part 2 Indoor Units	6
Part 3 Outdoor Units.....	60
Part 4 Installation.....	75
Part 5 Electrical Control System	106

※The specifications, designs, and information in this book are subject to change without notice for product improvement.

Part 1

General Information

1. Model Lists	2
2. External Appearance	3
2.1 Indoor Units.....	3
2.2 Outdoor Units.....	3
3. Nomenclature.....	4
4. Features.....	5

1. Model Lists

1.1 Indoor Units

R410A (capacity multiplied by 1000Btu/h)

Type	Function	12	18	24	36	48
4-way cassette	Cooling and heating	●	●	●	●	●
Duct	Cooling and heating	●	●	●	●	●
Ceiling-floor	Cooling and heating	●	●	●	●	●
Console	Cooling and heating	●				

1.2 Outdoor Units

Universal Outdoor unit Model	Compressor type	Compressor Brand	Matched indoor units
MOC-12HFN1-MS0W	Rotary	GMCC	MUBU-12HRFN1-M MCA2U-12HRFN1-M MFAU-12HRFN1-M MTBU-12HRDN1-M
MOC-12HFN1-MV0W	Rotary	GMCC	
MOZ-12HFN1-MW0W	Rotary	GMCC	MFAU-12HRFN1-M(B) MCA2U-12HRFN1-M(B) MUBU-12HRFN1-M(B) MTBU-12HRDN1-M(B)
MOF-18HFN1-MS0W	Rotary	GMCC	MUBU-18HRFN1-M MCA2U-18HRFN1-M MTBU-18HRDN1-M
MOF-18HFN1-MU0W	Rotary	GMCC	
MOU-24HFN1-M	Rotary	GMCC	MUE-24HRFN1-M MCD-24HRFN1-M MTB-24HRFN1-M
MOG-24HFN1-MT0W	Rotary	GMCC	MUE-24HRFN1-MW MTB-24HRFN1-MW MCD-24HRFN1-MW
MOU-36HFN1-M	Rotary	MITSUBISHI	MUE-36HRFN1-M MCD-36HRFN1-M MTB-36HWFN1-M
MOU-48HFN1-M	Rotary	MITSUBISHI	MUE-48HRFN1-M MTB-48HWFN1-M MCD-48HRFN1-M

2. External Appearance

2.1 Indoor Units

4-way cassette (12K, 18K)



4-way cassette (24K~48K)



Duct



Console



Ceiling-Floor (12K, 18K)



Ceiling-Floor (24K~48K)



2.2 Outdoor Units



Single fan outdoor unit



Double fan outdoor unit

3. Nomenclature

3.1 Indoor Unit

M U B T- 36 H R D N1- Q RC4

Energy Efficiency Code

Power Supply

Q 220~240V, 1N, 50Hz
R 380~420V, 3N, 50Hz
N 220~230V, 1N, 60Hz
D 220V~, 3N, 60Hz
C 380~420V, 3N, 60Hz

Refrigerant

N1 R410A -- R22

D DC Inverter -- On-Off

F Full DC

Control Mode

W Wired Control **E** Electric Control
M Mechanical Control **R** Remote Control

Function Code

C Cooling Only **H** Cooling & Heating
A Cooling & Heating+PTC

Capacity (×1000Btu/h)

T Tropical Condition
-- T1 Condition

Designed Time

A Time A Designed **B** Time B Designed
C Time C Designed **D** Time D Designed

Product Category

C Cassette Type **V** AHU Type
T Duct Type **F** Console Type
U Ceiling & Floor Type
H High Static Pressure Duct Type

Midea

3.2 Outdoor Unit

M O U T- 36 H D N1- R RC4

Energy Efficiency Code

Power Supply

Q 220~240V, 1N, 50HZ
R 380~420V, 3N, 50Hz
N 220~230V, 1N, 60Hz
D 220V~, 3N, 60Hz
C 380~420v, 3N, 60HZ

Refrigerant

N1 R410A -- R22

D DC Inverter -- On-Off

F Full DC

Function Code

C Cooling Only **H** Cooling & Heating
A Cooling & Heating+PTC

Capacity (×1000Btu/h)

T Tropical Condition
-- T1 Condition

U Side Discharge Outdoor Unit

V Top Discharge Outdoor Unit

S Centrifugal Fan Outdoor Unit

O Outdoor unit

Midea

4. Features

- 4.1. Low ambient kit is standard for outdoor units
- 4.2. Network control function is standard for the indoor units.
- 4.3. Standard auto restart function and follow me function.
- 4.4. Slim cassette with standard remote controller, wire controller and CCM for optional. Med Duct and HESP duct with standard wired controller, remote controller and CCM for optional.
- 4.5. Standard anti-cold air function.
- 4.6. Standard auto defrosting function.
- 4.7. Standard self-diagnose function.
- 4.8. Standard timer function and sleep mode function controlled by controller.

Part 2

Indoor Units

4-way Cassette Type	7
Duct Type	22
Ceiling & Floor Type	38
Console Type	50

4-way Cassette Type

1. Features (12K, 18K).....	8
2. Features (24K,36K)	9
3. Dimensions.....	13
4. Service Space.....	15
5. Wiring Diagrams	16
6. Electric Characteristics	18
7. Sound Levels.....	18
8. Accessories	19
9. The Specification of Power	20
10. Field Wiring	21

1. Features (12K, 18K)

1.1 New panel

- 360°surrounding air outlet design, affords comfortable feeling



1.2 Compact design

- The body size is 570×260×570mm, it's just smaller than the ceiling board, so it's very easy for installation and will not damage the decoration. The panel size is 647×50×647mm.
- The hooks are designed in the four corners of the body, which can save installation space.



1.3 Electric control box built-in design

- The E-box is simply and safely built inside the indoor unit. It's convenient for installation and maintenance. Can check the control part easily, you only need to open the air return grille.



1.4 Air passage function


- Reserves the space for air outlet from the side of indoor unit; It's availed to connect air duct from the two sides to the nearby small rooms.



2. Features (24K,36K)

2.1 Overview


- Compact design, super slim body size, less space requiring in installation
- Each louver can be separately controlled, more comfort air blowing is possible.
- Auto-lifting panel design, more convenient to clean and maintain the filter.(optional)



	Old Cassette		New slim cassette		Volume change
Dimension	18K-24K:	840*230*840	18K-24K:	840*205*840	11%↓
	30K:	840*300*840	30K:	840*205*840	32%↓
	36K-48K:	840*300*840	36K-48K:	840*245*840	18%↓


2.2 Fresh air intake function

- Fresh air fulfills air quality more healthy and comfortable.
- Ventilation motor is optional to increase the effect of fresh air.



2.3 Optional ionizer generator

- Ionizer generator is optional to get refreshing air to your room.



Ionizer generator
connector


Ventilation motor
connector

- Ionizer can be switched on or off by remote controller. When pressing the Clean Air button on the remote controller, Ionizer will work and the indicator light on display board will shine.




2.4 External air duct design

- Reserve external air duct, more flexible for the air supply.




2.5 Built-in draining pump

- Due to the improvement of structure, more convenient to repair or replace the draining pump.



Draining Pump

- Built-in draining pump to make sure condensed water drain out reliably.



2.6 Terminals for alarm lamp and long-distance on-off controller connection are standard

- Reserve terminals for the connection of alarm lamp and long-distance on-off controller, more human control.



Alarm lamp

Long-distance on-off controller


2.7 Optional touch screen wired controller


- Touch screen wired controller is optional, with error code indication function. Better man-machine conversation interface.
- Undated structure design, 4-way wire layout design, no raised part at backside, more convenient to place the wires and install the device.




3. Dimensions

12K, 18K






4. Service Space




5. Wiring Diagrams


MCA2U-12HRFN1-M MCA2U-18HRFN1-M




MCA2U-12HRFN1-M(B)



MCD-24HRFN1-M MCD-36HRFN1-M MCD-48HRFN1-M




MCD-24HRFN1-MW



6. Electric Characteristics














Model	Indoor Unit			
	Hz	Voltage	Min	Max
MCA2U-12HRFN1-M	60	208-230V	187V	253V
MCA2U-12HRFN1-M(B)	60	208-230V	187V	253V
MCA2U-18HRFN1-M	60	208-230V	187V	253V
MCD-24HRFN1-M	60	208-230V	187V	253V
MCD-24HRFN1-MW	60	208-230V	187V	253V
MCD-36HRFN1-M	60	208-230V	187V	253V
MCD-48HRFN1-M	60	208-230V	187V	253V

7. Sound Levels



Model	Noise level dB(A)		
	H	M	L
MCA2U-12HRFN1-M	51	46	40.5
MCA2U-12HRFN1-M(B)	51	46	40.5
MCA2U-18HRFN1-M	51	46	40.5
MCD-24HRFN1-M	51	47	43
MCD-24HRFN1-MW	51	47	43
MCD-36HRFN1-M	52	47	44
MCD-48HRFN1-M	52	48	44

8. Accessories

	Name	Shape	Quantity
Installation fittings	1. Expansible hook		4
	2. Installation hook		4
	3. Installation paper board		1
Drainpipe Fittings	4. Out-let pipe sheath		1
	5. Out-let pipe clasp		1
	6. Tightening band		20
	7. Drain joint		1
Remote controller & Its holder	8. Remote controller		1
	9. Remote controller holder		1
	10. Mounting screw(ST2.9×10-C-H)		2
	11. Alkaline dry batteries (AM4)		2
Others	12. Owner's manual		1
	13. Installation manual		1


9. The Specification of Power

Model		MCA2U-12HRFN1-M MCA2U-12HRFN1-M(B) MCA2U-18HRFN1-M	MCD-24HRFN1-MW
Power	Phase	1-phase	1-phase
	Frequency and Voltage	208-230V, 60Hz	208-230V, 60Hz
Circuit Breaker/ Fuse (A)		20/16	40/30
Indoor Unit Power Wiring (mm ²)		————	————
Indoor/Outdoor Connecting Wiring	Ground Wiring	2.0	2.0
	Outdoor Unit Power Wiring	3×2.0	3×2.0
	Strong Electric Signal	4×1.5	4×1.5
	Weak Electric Signal	————	————


Model		MCD-24HRFN1-M,	MCD-36HRFN1-M	MCD-48HRFN1-M
Power	Phase	1-phase	1-phase	1-phase
	Frequency and Voltage	208-230V, 60Hz	208-230V, 60Hz	208-230V, 60Hz
Circuit Breaker/ Fuse (A)		40/30	60/40	70/55
Indoor Unit Power Wiring (mm ²)		————	————	————
Indoor/Outdoor Connecting Wiring	Ground Wiring	4.0	4.0	4.0
	Outdoor Unit Power Wiring	3×4.0	3×4.0	3×4.0
	Strong Electric Signal	3×1.5	3×1.5	3×1.5
	Weak Electric Signal	3×0.5	3×0.5	3×0.5

10. Field Wiring

MCA2U-12HRFN1-M, MCA2U-12HRFN1-M(B), MCA2U-18HRFN1-M, MCD-24HRFN1-MW



MCD-24HRFN1-M, MCD-36HRFN1-M, MCD-48HRFN1-M




Duct Type

1. Features	23
2. Dimensions.....	26
3. Service Space.....	27
4. Wiring Diagrams	28
5. Static Pressure	31
6. Electric Characteristics	33
7. Sound Level.....	34
8. Accessories	35
9. The Specification of Power	36
10. Field Wiring	37

1. Features

1.1 Installation accessories: (Optional)


- Front Board, Canvas Air Passage, Filter, Panel, for easy installation



Panel

1.2 Easy Installation: Two air inlet styles (Bottom side or Rear side)

- Air inlet from rear is standard for all capacity; air inlet from bottom is optional.
- The size of air inlet frame from rear and bottom is same, it's very easy to move the cover from bottom to rear side, or from rear to the bottom, in order to matching the installation condition.




Air intake from rear (Standard)

Air intake from bottom (Optional)


1.3 Fresh air intake function

- Install one duct from the reserved fresh-air intake to outdoor. Continually inhale the fresh air to improve the quality of the indoor air, fulfills air quality more healthy and comfortable.




1.4 Easy maintenance

- Clean the filter (Optional, standard product without filter)
It is easy to draw out the filter from the indoor unit for cleaning, even the filter is installed in rear side or bottom side.




- Replace the motor or centrifugal fan
Remove the ventilated panel firstly. Remove a half of blower housing and take out the motor with centrifugal fan. Directly remove two bolts, and then replace the motor or centrifugal fan easily.



1.5 Reserved remote on-off and central control ports



- Reserved remote on-off ports and central control ports, can connect the cable of an on-off controller or a central controller to realize remote on-off control function or group control function.



Remote on-off ports Central control ports

1.6 Built-in drain pump (Optional):


- Built-in drain pump can lift the water to 750mm upmost. It's convenient to install drainage piping under most space condition.




1.7 Built-in display board

- The standard indoor unit can be controlled by wired controller.
- There is a display board with a receiver in the E-box. Move out the display, and fix it in other place, even in the distance of 10m. The unit will realized remoter control.
- The wired controller and the display board can display the error code or production code when the chips detect some failure.


Wired Controller (Standard)



Remote Controller (Optional)




2. Dimensions




Note: standard product without filter														Unit: mm			
Capacity(KBtu/h)	Outline dimension(mm)				Air outlet opening size				Air return opening size			Size of install hanger		Size of refrigerant pipe			
	A	B	C	D	E	F	G	H	I	J	K	L	M	H1	H2	W1	W2
12	700	210	635	570	65	493	35	119	595	200	80	740	350	120	143	95	150
18	920	210	635	570	65	713	35	119	815	200	80	960	350	120	143	95	150
24	920	270	635	570	65	713	35	179	815	260	20	960	350	120	143	95	150
36	1140	270	775	710	65	933	35	179	1035	260	45	1240	500	120	143	95	150
48	1200	300	865	800	80	968	40	204	1094	288	45	1240	500	175	198	155	210

3. Service Space

Ensure enough space required for installation and maintenance.




All the indoor units reserve the hole to joint the fresh air pipe. The hole size as following:




MODLE	
12-24	30-60

4. Wiring Diagrams

MTBU-12HRDN1-M MTBU-18HRDN1-M



MTBU-12HRDN1-M(B)







MTB-24HRFN1-MW





WIRING DIAGRAM (INDOOR UNIT)
202052290087


POWER SETTING :				
ENC1	 ON 1 2	 ON 1 2	 ON 1 2	 ON 1 2

MODEL	20	26	32/35	53
FACTORY SETTING	ACCORDING TO RELATED MODEL.			


FOR TEMP. COMPENSATION				
SW6	 1 2	 1 2	 1 2	 1 2
CODE	6°C	2°C	4°C	According to E Function
FACTORY SETTING	✓			

FOR ANTI-COLD WIND				
SW1	<div>ON  1 2</div>	<div>ON  1 2</div>	<div>ON  1 2</div>	<div>ON  1 2</div>
TE1	28	30	Fan motor do not stop.	According to E Function -
TE2	30	32		
TE3	24	28		
TE4	15	24		
TE5	32	35		
TE6	30	32		
FACTORY SETTING	✓			

FOR SETTING NETADDRESS				
S1+S2				
CODE	0-F	0-F	0-F	0-F
NETADDRESS	0-15	16-31	32-47	48-63
FACTORY SETTING	✓			



MTB-24HRFN1-M MTB-36HWFN1-M MTB-48HWFN1-M



For Setting NETAddress

S1+S2				
Code	0~F 00	0~F 01	0~F 10	0~F 11
NETAddress	0~15	16~31	32~47	48~63
Factory Setting	✓			

For Setting static pressure

ENC2				
Code	0	1	2	3
high static pressure	0~50	51~80	81~120	121~150
Middle static pressure	0~25	26~37	38~50	51~100
Factory Setting	✓			

For Setting POWER

ENC1						
Code	4	5	7	8	9	A B
POWER	53	71	90	105	140	160 175
Factory Setting	According to related model.					

For temp. compensation

SW6				
TYPE	/	/	/	/
DUCT TYPE	3℃	4℃	6℃	According to E Function
CEILING AND FLOOR TYPE	1℃	4℃	6℃	
For Setting CEILING TYPE or FLOOR TYPE	FLOOR TYPE	CEILING TYPE		
Factory Setting	✓			

FUNCTION SETTING INDICATION

202070590737

For Setting Fan Motor Control then No Power Request

SW2		
Mode	Fan OFF	Fan ON
Factory Setting	✓	

For Setting Auto-Restart


SW3		
Mode	ON	OFF
Factory Setting	✓	

For Setting Fan Quantity (optional)


SW4		
Mode	Single Fan	Double Fan
Factory Setting		✓

5. Static Pressure


12,000Btu/h




18,000Btu/h




24,000Btu/h



36,000Btu/h






6. Electric Characteristics










Model	Indoor Unit			
	Hz	Voltage	Min.	Max.
MTBU-12HRDN1-M	60	208-230V	187V	253V
MTBU-12HRDN1-M(B)				
MTBU-18HRDN1-M	60	208-230V	187V	253V
MTB-24HRFN1-M	60	208-230V	187V	253V
MTB-24HRFN1-MW	60	208-230V	187V	253V
MTB-36HWFN1-M	60	208-230V	187V	253V
MTB-48HWFN1-M	60	208-230V	187V	253V

7. Sound Level



Model	Noise level dB(A)		
	H	M	L
MTBU-12HRDN1-M	38	34	30
MTBU-12HRDN1-M(B)	38	34	30
MTBU-18HRDN1-M	40	35	30
MTB-24HRFN1-M	50	47	43
MTB-24HRFN1-MW	45	41.5	38
MTB-36HWFN1-M	51	48	44
MTB-48HWFN1-M	49	46	43

8. Accessories

	Name	Shape	Quantity
Tubing & Fittings	Soundproof / insulation sheath		2
	Binding tape		1
	Seal sponge		1
Drainpipe Fittings (for cooling & heating)	Drain joint		1
	Seal ring		1
Wired controller & Its Frame	Wired controller		1
Others	Owner' s manual		1
	Installation manual		1
EMS & It's fitting	Magnetic ring (twist the electric wires L and N around it to five circles)		1


9. The Specification of Power

Model		MTBU-12HRDN1-M MTBU-12HRDN1-M(B) MTBU-18HRDN1-M	MTB-24HRFN1-MW
Power	Phase	1-phase	1-phase
	Frequency and Voltage	208-230V, 60Hz	208-230V, 60Hz
Circuit Breaker/ Fuse (A)		20/16	40/30
Indoor Unit Power Wiring (mm ²)		—————	—————
Indoor/Outdoor Connecting Wiring	Ground Wiring	2.0	2.0
	Outdoor Unit Power Wiring	3×2.0	3×2.0
	Strong Electric Signal	4×1.5	4×1.5
	Weak Electric Signal	—————	—————


Model		MTB-24HRFN1-M	MTB-36HWFN1-M	MTB-48HWFN1-M
Power	Phase	1-phase	1-phase	1-phase
	Frequency and Voltage	208-230V, 60Hz	208-230V, 60Hz	208-230V, 60Hz
Circuit Breaker/ Fuse (A)		40/30	60/40	70/55
Indoor Unit Power Wiring (mm ²)		—————	—————	—————
Indoor/Outdoor Connecting Wiring	Ground Wiring	4.0	4.0	4.0
	Outdoor Unit Power Wiring	3×4.0	3×4.0	3×4.0
	Strong Electric Signal	3×1.5	3×1.5	3×1.5
	Weak Electric Signal	3×0.5	3×0.5	3×0.5

10. Field Wiring

MTBU-12HRDN1-M, MTBU-12HRDN1-M(B), MTBU-18HRDN1-M, MTB-24HRFN1-MW



MTB-24HRFN1-M, MTB-36HWFN1-M, MTB-48HWFN1-M



Ceiling & Floor Type

1. Features	39
2. Dimensions.....	41
3. Service Space.....	44
4. Wiring Diagrams	45
5. Electric Characteristics	47
6. Sound Levels.....	47
7. Accessories	48
8. The Specification of Power	48
9. Field Wiring.....	49

1. Features

12K, 18K


1.1 Two-way installation

- The rounded design of the ceiling and floor type air conditioner allows either ceiling or floor-level installation. Ceiling installation saves room space, while floor installation helps prevent the loss of warm air.



1.2 Brief design

- Brief design that is suitable for any interior will not only give you cooling and heating performance but also upgrade your lifestyle.




1.3 3D airflow

- Vertical air flow and horizontal airflow can be adjusted by remote controller, the cooperation of the two airflow ways help to spread air comfortably throughout even a large room. With these functions, the whole room can be evenly air-conditioned for both floor-level and ceiling installation.



1.4 Optional drainage pipe connection

- Both right side and left side drainage holes are available to avoid the space limitation for drainage pipe installation. Make you more convenient during installation.



1.5 Five panels for optional



Standard Panel



A Panel



B Panel (LED display)



C Panel (LED display)




D Panel

1.6 Convenience operating and easy maintenance

- Remote controller as standard, wired controller for optional.
- The filter without screw fixed, can be took out easily.

1.7 Easy installation, save working time

- The pipes can be connected from bottom, back and right side, makes the installation more easily.
- The wiring works can be finished before installation.



1.8 Outside water pump for optional when ceiling installation.

24K,36K

1.1. New design, more modern and elegant appearance.




1.2. Convenient installation

- The ceiling type can be easily installed into a corner of the ceiling even if the ceiling is very narrow
- It is especially useful when installation of an air conditioner in the center of the ceiling is impossible due to a structure such as one lighting.

1.3. Two direction auto swing (vertical & horizontal) and wide angle air flow,

- Air flow directional control minimizes the air resistance and produces wilder air flow to vertical direction.
- The range of horizontal air discharge is widened which secures wider air flow distribution to provide more comfortable air circulation no matter where the unit is set up



1.4. Three level fan speed, more humanism design, meets different air-supply requirement.

1.5. New foam drain pan with plastic-spraying inner surface




1.6. Easy operation.


1.7. Remote control and optional wired control method.

2. Dimensions

12K, 18K





24K~48K





Capacity (Btu/h)	A	B	C	D
24K	1068	675	235	983
36K	1285	675	235	1200
48K	1650	675	235	1565

3. Service Space


12K,18K



24K~48K



MUE-24HRFN1-M MUE-36HRFN1-M MUE-48HRFN1-M



For Setting NETAddress

Code	0-F	00	0-F	01	0-F	10	0-F	11
NETAddress	0-15	16-31	32-47	48-63				

Factory Setting: ☒

For Setting static pressure

Code	0	1	2	3	4
High static pressure	0-50	51-80	81-120	121-160	>160
Middle static pressure	0-25	26-37	38-60	61-100	>100

Factory Setting: ☒

For Setting POWER

Code	4	5	7	8	9	A	B
POWER	53	71	90	105	140	160	175

According to related model.

For temp. compensation

TYPE	3℃	4℃	6℃	According to E Function
DUCTTYPE	3℃	4℃	6℃	
CEILING/FLOOR TYPE	1℃	4℃	6℃	

Factory Setting: ☒

For Setting Fan Motor Control then No Power Request

Mode	Fan OFF	Fan ON
Factory Setting	<input checked="" type="checkbox"/>	<input type="checkbox"/>

For Setting Auto-Restart

Mode	ON	OFF
Factory Setting	<input checked="" type="checkbox"/>	<input type="checkbox"/>

For Setting Fan Quantity (optional)

Mode	Single Fan	Double Fan
Factory Setting	<input type="checkbox"/>	<input checked="" type="checkbox"/>


FUNCTION SETTING INDICATION

202070590737


5. Electric Characteristics

Model	Indoor Units			
	Hz	Voltage	Min.	Max.
MUBU-12HRFN1-M	60	208-230V	187V	253V
MUBU-12HRFN1-M(B)	60	208-230V	187V	253V
MUBU-18HRFN1-M	60	208-230V	187V	253V
MUE-24HRFN1-M	60	208-230V	187V	253V
MUE-24HRFN1-MW	60	208-230V	187V	253V
MUE-36HRFN1-M	60	208-230V	187V	253V
MUE-48HRFN1-M	60	208-230V	187V	253V

6. Sound Levels










Ceiling



Floor

Model	Noise level dB(A)		
	H	M	L
MUBU-12HRFN1-M	44	38	33
MUBU-12HRFN1-M(B)	44	38	33
MUBU-18HRFN1-M	46	38	34
MUE-24HRFN1-M	58.5	55	52
MUE-24HRFN1-MW	54	49	44
MUE-36HRFN1-M	55	48	41
MUE-48HRFN1-M	57	54	52

7. Accessories

Remote controller & Its holder	1. Remote controller		1
	2. Remote controller holder		1
	3. Mounting screw (ST2.9×10-C-H)		2
	4. Alkaline dry batteries (AM4)		2
Others	5. Owner's manual		1
	6. Installation manual		1
	7. Remote controller manual		1


8. The Specification of Power

Model		MUBU-12HRFN1-M MUBU-12HRFN1-M(B) MUBU-18HRFN1-M	MUE-24HRFN1-MW
Power	Phase	1-phase	1-phase
	Frequency and Voltage	208-230V, 60Hz	208-230V, 60Hz
Circuit Breaker/ Fuse (A)		20/16	40/30
Indoor Unit Power Wiring (mm ²)		—————	—————
Indoor/Outdoor Connecting Wiring	Ground Wiring	2.0	2.0
	Outdoor Unit Power Wiring	3×2.0	3×2.0
	Strong Electric Signal	4×1.5	4×1.5
	Weak Electric Signal	—————	—————


Model		MUE-24HRFN1-M,	MUE-36HRFN1-M,	MUE-48HRFN1-M
Power	Phase	1-phase	1-phase	1-phase
	Frequency and Voltage	208-230V, 60Hz	208-230V, 60Hz	208-230V, 60Hz
Circuit Breaker/ Fuse (A)		40/30	60/40	70/55
Indoor Unit Power Wiring (mm ²)		—————	—————	—————
Indoor/Outdoor Connecting Wiring	Ground Wiring	4.0	4.0	4.0
	Outdoor Unit Power Wiring	3×4.0	3×4.0	3×4.0
	Strong Electric Signal	3×1.5	3×1.5	3×1.5
	Weak Electric Signal	3×0.5	3×0.5	3×0.5

9. Field Wiring

MUBU-12HRFN1-M, MUBU-12HRFN1-M(B), MUBU-18HRFN1-M, MUE-24HRFN1-MW



MUE-24HRFN1-M, MUE-36HRFN1-M, MUE-48HRFN1-M



Console Type

1. Features	51
2. Dimensions.....	53
3. Service Space.....	54
4. Wiring Diagrams	55
5. Electric Characteristics	56
6. Sound Levels.....	57
7. Accessories	58
8. The Specification of Power	58
9. Field Wiring	59

1. Features

1.1. Modern and elegant appearance


- The simple and stylish designs can nicely harmonies with your living space.



1.2. Four panels optional



1.3. Two air-outlet ways Cooling mode



Quick Cooling

To maintain room temp


- Air outlet from top and bottom to make quick cooling -----When the A/C is just switched on, or room temp. is still high, cold air will be blown out from top and bottom air outlet to cool down the room quickly
- Air outlet from top to maintain room temp. ----When the room has been cooled down, or the A/C has been opened over 1 hour, cold air only from the top outlet to keep constant room temp

Heating mode

- Anti-cold air -----When the AC is just turn on, temperature of evaporator is very low, in this case, in order to prevent cold air direct blowing, only the upper louver is opened in a high position, the lower louver closed.




1.4. Four air inlets




1.5. Low noise

- DC indoor fan motor, which has five speeds.
- Low noise and energy saving.




- Advanced centrifugal fan technology makes a fast airflow and reduces the indoor noise lower to 28dB.




1.6. Golden fin is optional.

1.7. Active carbon filter is standard

2. Dimensions




3. Service Space




4. Wiring Diagrams

MFAU-12HRFN1-M




MFAU-12HRFN1-M(B)



5. Electric Characteristics






Model	Indoor Unit			
	Hz	Voltage	Min	Max
MFAU-12HRFN1-M	60	208-230V	187V	253V
MFAU-12HRFN1-M(B)	60	208-230V	187V	253V

6. Sound Levels



Model	Noise level dB(A)		
	H	M	L
MFAU-12HRFN1-M	40	35	30
MFAU-12HRFN1-M(B)			

7. Accessories


	Name	Shape	Quantity
Installation fittings	Hook		2
Remote controller & Its Frame	Remote controller		1
	Frame		1
	Mounting screw(ST2.9×10-C-H)		2
	Alkaline dry batteries (AM4)		2
Others	Installation manual	/	1
	Owner's manual	/	1

8. The Specification of Power

Model		MFAU-12HRFN1-M MFAU-12HRFN1-M(B)
Power	Phase	1-phase
	Frequency and Voltage	208-230V, 60Hz
Circuit Breaker/ Fuse (A)		20/16
Indoor Unit Power Wiring (mm ²)		—————
Indoor/Outdoor Connecting Wiring	Ground Wiring	2.0
	Outdoor Unit Power Wiring	3×2.0
	Strong Electric Signal	4×1.5
	Weak Electric Signal	—————

9. Field Wiring

MFAU-12HRFN1-M, MFAU-12HRFN1-M(B)




Part 3


Outdoor Units

1. Dimensions.....	61
2. Service Space	63
3. Piping Diagrams.....	64
4. Wiring Diagrams.....	66
5. Electric Characteristics	72
6. Operation Limits.....	73
7. Sound Levels.....	74

1. Dimensions





Model	Unit: mm						
	A	B	C	D	E	F	H
MOC-12HFN1-MS0W	760	530	290	315	270	285	590
MOC-12HFN1-MV0W	760	530	290	315	270	285	590
MOZ-12HFN1-MW0W	810	549	325	350	305	310	558
MOF-18HFN1-MS0W	845	560	335	360	312	320	700
MOF-18HFN1-MU0W	845	560	335	360	312	320	700
MOU-24HFN1-M	900	590	333	355	302	315	860
MOG-24HFN1-MT0W	900	590	333	355	302	315	860
MOU-36HFN1-M	990	624	366	396	340	345	965




Model	Unit: mm						
	A	B	C	D	E	F	H
MOU-48HFN1-M	938	634	404	448	370	392	1369

2. Service Space




3. Piping Diagrams


MOC-12HFN1-MS0W MOZ-12HFN1-MW0W MOF-18HFN1-MS0W



MOC-12HFN1-MV0W MOF-18HFN1-MU0W MOG-24HFN1-MT0W




For MOF-18HFN1-MU0W & MOG-24HFN1-MT0W, there is no accumulator.

MOU-24HFN1-M MOU-36HFN1-M MOU-48HFN1-M

For MOU-24HFN1-M, there are no high pressure switch and low pressure switch.


4. Wiring Diagrams


MOC-12HFN1-MV0W




MOZ-12HFN1-MW0W

202037490492




MOC-12HFN1-MS0W MOF-18HFN1-MS0W MOF-18HFN1-MU0W


MOU-24HFN1-M




MOG-24HFN1-MT0W



MOU-36HFN1-M



MOU-48HFN1-M



5. Electric Characteristics

Model	Outdoor Unit				Power Supply
	Hz	Voltage	Min.	Max.	MFA
MOC-12HFN1-MS0W	60	208-230V	187V	253V	16
MOC-12HFN1-MV0W	60	208-230V	187V	253V	16
MOZ-12HFN1-MW0W	60	208-230V	187V	253V	16
MOF-18HFN1-MS0W	60	208-230V	187V	253V	16
MOF-18HFN1-MU0W	60	208-230V	187V	253V	16
MOU-24HFN1-M	60	208-230V	187V	253V	30
MOG-24HFN1-MT0W	60	208-230V	187V	253V	30
MOU-36HFN1-M	60	208-230V	187V	253V	40
MOU-48HFN1-M	60	208-230V	187V	253V	55

Note:

MFA: Max. Fuse Amps. (A)


6. Operation Limits

Mode \ Temperature	Cooling operation	Heating operation	Drying operation
Room temperature	17°C~32°C	0°C~30°C	17°C~32°C
Outdoor temperature	0°C~50°C	-15°C~24°C	0°C~50°C
	(-15°C~50°C: For the models with low temperature cooling system)		

CAUTION:

1. If the air conditioner is used beyond the above conditions, certain safety protection features may come into operation and cause the unit to operate abnormally.
2. The room relative humidity should be less than 80%. If the air conditioner operates beyond this figure, the surface of the air conditioner may attract condensation. Please set the vertical air flow louver to its maximum angle (vertically to the floor), and set HIGH fan mode.
3. The optimum performance will be achieved during this operating temperature zone.

7. Sound Levels



Note: $H = 0.5 \times \text{height of outdoor unit}$


Model	Noise Level dB(A)
MOC-12HFN1-MS0W	55
MOC-12HFN1-MV0W	54
MOZ-12HFN1-MW0W	57
MOF-18HFN1-MS0W	60.5
MOF-18HFN1-MU0W	60
MOU-24HFN1-M	61.5
MOG-24HFN1-MT0W	60
MOU-36HFN1-M	66
MOU-48HFN1-M	64

Part 4

Installation

1. Installation Procedure	76
2. Location selection	77
3. Indoor unit installation	78
4. Outdoor unit installation (Side Discharge Unit).....	95
5. Refrigerant pipe installation	97
6. Drainage pipe installation	98
7. Vacuum Drying and Leakage Checking	102
8. Additional refrigerant charge	103
9. Engineering of insulation	103
10. Engineering of electrical wiring	104
11. Test operation	105

1. Installation Procedure




2. Location selection

2.1 Indoor unit location selection

- The place shall easily support the indoor unit's weight.
- The place can ensure the indoor unit installation and inspection.
- The place can ensure the indoor unit horizontally installed.
- The place shall allow easy water drainage.
- The place shall easily connect with the outdoor unit.
- The place where air circulation in the room should be good.
- There should not be any heat source or steam near the unit.
- There should not be any oil gas near the unit
- There should not be any corrosive gas near the unit
- There should not be any salty air near the unit
- There should not be strong electromagnetic wave near the unit
- There should not be inflammable materials or gas near the unit
- There should not be strong voltage vibration.

2.2 Outdoor unit location selection


- The place shall easily support the outdoor unit's weight.
- Locate the outdoor unit as close to indoor unit as possible
- The piping length and height drop cannot exceed the allowable value.
- The place where the noise, vibration and outlet air do not disturb the neighbors.
- There is enough room for installation and maintenance.
- The air outlet and the air inlet are not impeded, and not face the strong wind.
- It is easy to install the connecting pipes and cables.
- There is no danger of fire due to leakage of inflammable gas.
- It should be a dry and well ventilation place
- The support should be flat and horizontal
- Do not install the outdoor unit in a dirty or severely polluted place, so as to avoid blockage of the heat exchanger in the outdoor unit.
- If is built over the unit to prevent direct sunlight, rain exposure, direct strong wind, snow and other scraps accumulation, make sure that heat radiation from the condenser is not restricted.




3. Indoor unit installation

3.1 Compact cassette indoor unit installation

3.1.1 Service space for indoor unit



3.1.2 Bolt pitch



3.1.3 Install the pendant bolt

Select the position of installation hooks according to the hook holes positions showed in upper picture. Drill four holes of $\varnothing 12\text{mm}$, 45~50mm deep at the selected positions on the ceiling. Then embed the expansible hooks (fittings).




Face the concave side of the installation hooks toward the expansible hooks. Determine the length of the installation hooks from the height of ceiling, then cut off the unnecessary part.


If the ceiling is extremely high, please determine the length of the installation hook depending on the real situation.

3.1.4 Install the main body

Make the 4 suspender through the 4 hanger of the main body to suspend it. Adjust the hexangular nuts on the four installation hooks evenly, to ensure the balance of the body. Use a leveling instrument to make sure the levelness of the main body is within $\pm 1^\circ$.



Adjust the position to ensure the gaps between the body and the four sides of ceiling are even. The body's lower part should sink into the ceiling for 10~12 mm. In general, L is half of the screw length of the installation hook.




Locate the air conditioner firmly by wrenching the nuts after having adjusted the body's position well.




3.1.5 Install the panel


Remove the grille



Hang the panel to the hooks on the mainbody.



Tighten the screws under the panel hooks till the panel closely stick on the ceiling to avoid condensate water.





Hang the air-in grill to the panel, then connect the lead terminator of the swing motor and that of the control box with corresponding terminators on the body respectively.

Note: The panel shall be installed after the wiring connected.


3.2 Super slim cassette indoor unit installation

3.2.1 Service space for indoor unit



Model	A	H		Remark
24	205	>235	R410A and R22	Cooling / Cooling & Heating
36	245	>275	R410A and R22	Cooling / Cooling & Heating
48	287	>317	R410A and R22	Cooling / Cooling & Heating

3.2.2 Bolt pitch



3.2.3 Install the pendant bolt

Select the position of installation hooks according to the hook holes positions showed in upper picture. Drill four holes of $\varnothing 12\text{mm}$, 45~50mm deep at the selected positions on the ceiling. Then embed the expansible hooks (fittings).




3.2.4 Install the main body


Make the 4 suspender through the 4 hanger of the main body to suspend it. Adjust the hexangular nuts on the four installation hooks evenly, to ensure the balance of the body. Use a leveling instrument to make sure the levelness of the main body is within $\pm 1^\circ$.



Adjust the position to ensure the gaps between the body and the four sides of ceiling are even. The body's lower part should sink into the ceiling for 10~12 mm. In general, L is half of the screw length of the installation hook.




Locate the air conditioner firmly by wrenching the nuts after having adjusted the body's position well.




3.2.5 Install the panel


Remove the grille





Remove the 4 corner covers.



Hang the panel to the hooks on the mainbody. If the panel is with auto-lift grille, please watch the ropes lifting the grille, DO NOT make the ropes entwined or blocked.




Tighten the screws under the panel hooks till the panel closely stick on the ceiling to avoid condensate water.



Hang the air-in grill to the panel, then connect the lead terminator of the swing motor and that of the control box with corresponding terminators on the body respectively.


Install the 4 corner covers back.




Note: The panel shall be installed after the wiring connected.

3.3 A5 duct indoor unit installation

3.3.1 Service space for indoor unit




3.3.2 Bolt pitch



Capacity(KBtu)	Size of outline dimension mounted plug	
	L	M
12	740	350
18/24	960	350
36	1180	490
48	1240	500


3.3.3 Install the pendant bolt

Select the position of installation hooks according to the hook holes positions showed in upper picture. Drill four holes of $\varnothing 12\text{mm}$, 45~50mm deep at the selected positions on the ceiling. Then embed the expansible hooks (fittings).




3.3.4 Install the main body

Make the 4 suspender through the 4 hanger of the main body to suspend it. Adjust the hexangular nuts on the four installation hooks evenly, to ensure the balance of the body. Use a leveling instrument to make sure the levelness of the main body is within $\pm 1^\circ$.




3.3.5 Install the air filter

Insert the air filter through the filter slot and fix it with 2 screws.




3.3.6 Install the air duct

Please design the air duct as below recommended picture




3.3.7 Change the air inlet direction


- ① Take off ventilation panel and flange, cut off the staples at side rail.




- ② Stick the attached seal sponge as per the indicating place in the following fig, and then change the mounting positions of air return panel and air return flange .



- ③ When install the filter mesh, please plug it into flange inclined from air return opening, and then push up.




- ④ The installation has finish, upon filter mesh which fixing blocks have been insert to the flange positional holes.




3.4 Ceiling & floor indoor unit installation (24K~48K)

3.4.1 Service space for indoor unit




3.4.2 Bolt pitch

① Ceiling installation



Capacity (Btu/h)	D	E
24K	983	220
36K	1200	220
48K	1565	220

② Wall-mounted installation



3.4.3 Install the pendant bolt


① Ceiling installation

Select the position of installation hooks according to the hook holes positions showed in upper picture. Drill four holes of $\varnothing 12\text{mm}$, 45~50mm deep at the selected positions on the ceiling. Then embed the expansible hooks (fittings).



② Wall-mounted installation


Install the tapping screws onto the wall. (Refer to picture below)




3.4.4 Install the main body

① Ceiling installation (The only installation method for the unit with drain pump)



Remove the side board and the grille.



Locate the hanging arm on the hanging screw bolt. Prepare the mounting bolts on the unit.





Put the side panels and grilles back.




② Wall-mounted installation

Hang the indoor unit by insert the tapping screws into the hanging arms on the main unit. (The bottom of body can touch with floor or suspended, but the body must install vertically.)




3.5 Ceiling & floor indoor unit installation (12K, 18K)

3.5.1 Service space for indoor unit




3.5.2 Bolt pitch

① Ceiling installation



Capacity (Btu/h)	D	F	G
12K, 18K	505	907	200

② Floor standing installation



3.5.3 Install the pendant bolt


① Ceiling installation

Select the position of installation hooks according to the hook holes positions showed in upper picture. Drill four holes of $\varnothing 12\text{mm}$, 45~50mm deep at the selected positions on the ceiling. Then embed the expansible hooks (fittings).



② Floor standing installation


Fix the hook with tapping screw onto the wall. (Refer to picture below)




3.5.4 Install the main body

① Ceiling installation (The only installation method for the unit with drain pump)


Remove the side board and the grille. (For models 48 and 60, do not remove the grille.)




Locate the hanging arm on the hanging screw bolt. (for some of the models 60, do not do this). Prepare the mounting bolts on the unit.



Hang the unit on the hanging arm by sliding backward. Securely tighten the mounting bolts on both sides.
(some of the models 60 do not do this)




For some of the models 60 please securely tighten the mounting bolts on both sides.



Then install the side panels and grilles back to the main unit.


② Floor standing installation

Hang the indoor unit on the hook. (The bottom of body can touch with floor or suspended, but the body must install vertically.)




3.6 Console indoor unit installation

3.6.1 Service space for indoor unit




3.6.2 Install the main body

- Fix the hook with tapping screw onto the wall




- Hang the indoor unit on the hook.
(The bottom of body can touch with floor or suspended, but the body must install vertically.)




4 Outdoor unit installation (Side Discharge Unit)

4.1 Service space for outdoor unit



4.2 Bolt pitch



Model	B	C	D
MOC-12HFN1-MS0W	530	290	315
MOC-12HFN1-MV0W	530	290	315
MOZ-12HFN1-MW0W	549	325	350
MOF-18HFN1-MS0W	560	335	360
MOF-18HFN1-MU0W	560	335	360
MOU-24HFN1-M	590	333	355
MOG-24HFN1-MT0W	590	333	355
MOU-36HFN1-M	624	366	396
MOU-48HFN1-M	634	404	448

4.3 Install the Unit


Since the gravity center of the unit is not at its physical center, so please be careful when lifting it with a sling. Never hold the inlet of the outdoor unit to prevent it from deforming.

Do not touch the fan with hands or other objects.

Do not lean it more than 45°, and do not lay it sidelong.

Make concrete foundation according to the specifications of the outdoor units.

Fasten the feet of this unit with bolts firmly to prevent it from collapsing in case of earthquake or strong wind.



5 Refrigerant pipe installation

5.1 Maximum pipe length and height drop

Considering the allowable pipe length and height drop to decide the installation position. Make sure the distance and height drop between indoor and outdoor unit not exceeded the date in the following table.

Model	Max. Length	Max. Elevation
12,000Btu/h	25m	10m
18,000Btu/h	30m	20m
24,000Btu/h	50m	25m
36,000Btu/h-48,000Btu/h	65m	30m

5.2 The procedure of connecting pipes


5.2.1 Choose the pipe size according to the specification table.

5.2.2 Confirm the cross way of the pipes.

5.2.3 Measure the necessary pipe length.

5.2.4 Cut the selected pipe with pipe cutter

- Make the section flat and smooth.



5.2.5 Insulate the copper pipe

- Before test operation, the joint parts should not be heat insulated.

5.2.6 Flare the pipe

- Insert a flare nut into the pipe before flaring the pipe
- According to the following table to flare the pipe

Pipe diameter	Flare dimension A (mm)		Flare shape
	Min	Max	
1/4" (6.35)	8.3	8.7	
3/8" (9.52)	12.0	12.4	
1/2" (12.7)	15.4	15.8	
5/8" (15.9)	18.6	19.1	
3/4" (19)	22.9	23.3	

- After flared the pipe, the opening part must be seal by end cover or adhesive tape to avoid duct or exogenous impurity come into the pipe.

5.2.7 Drill holes if the pipes need to pass the wall.

5.2.8 According to the field condition to bend the pipes so that it can pass the wall smoothly.


5.2.9 Bind and wrap the wire together with the insulated pipe if necessary.

5.2.10 Set the wall conduit**5.2.11 Set the supporter for the pipe.****5.2.12 Locate the pipe and fix it by supporter**

- For horizontal refrigerant pipe, the distance between supporters should not be exceed 1m.
- For vertical refrigerant pipe, the distance between supporters should not be exceed 1.5m.

5.2.13 Connect the pipe to indoor unit and outdoor unit by using two spanners.

- Be sure to use two spanners and proper torque to fasten the nut, too large torque will damage the bellmouthing, and too small torque may cause leakage. Refer the following table for different pipe connection.

Pipe Diameter	Torque		Sketch map
	(kgf.cm)	(N.cm)	
1/4" (6.35)	144~176	1420~1720	
3/8" (9.52)	333~407	3270~3990	
1/2" (12.7)	504~616	4950~6030	
5/8" (15.9)	630~770	6180~7540	
3/4" (19)	990~1210	9270~11860	

6 Drainage pipe installation

Install the drainage pipe as shown below and take measures against condensation. Improperly installation could lead to leakage and eventually wet furniture and belongings.

6.1 Installation principle

- Ensure at least 1/100 slope of the drainage pipe
- Adopt suitable pipe diameter
- Adopt nearby condensate water discharge

6.2 Key points of drainage water pipe installation**6.2.1 Considering the pipeline route and elevation**

- Before installing condensate water pipeline, determine its route and elevation to avoid intersection with other pipelines and ensure slope is straight.

6.2.2 Drainage pipe selection

- The drainage pipe diameter shall not small than the drain hose of indoor unit
- According to the water flowrate and drainage pipe slope to choose the suitable pipe, the water flowrate is decided by the capacity of indoor unit.

Relationship between water flowrate and capacity of indoor unit

Capacity (x1000Btu)	Water flowrate (l/h)
12	2.4
18	4
24	6
30	7
36	8
42	10
48	12
60	14

According to the above table to calculate the total water flowrate for the confluence pipe selection.

For horizontal drainage pipe (The following table is for reference)

PVC pipe	Reference value of inner	Allowable maximum water flowrate (l/h)	Remark
----------	--------------------------	--	--------

	diameter of pipe (mm)	Slope 1/50	Slope 1/100	
PVC25	20	39	27	For branch pipe
PVC32	25	70	50	
PVC40	31	125	88	Could be used for confluence pipe
PVC50	40	247	175	
PVC63	51	473	334	

Attention: Adopt PVC40 or bigger pipe to be the main pipe.

For Vertical drainage pipe (The following table is for reference)

PVC pipe	Reference value of inner diameter of pipe (mm)	Allowable maximum water flowrate (l/h)	Remark
PVC25	20	220	For branch pipe
PVC32	25	410	
PVC40	31	730	Could be used for confluence pipe
PVC50	40	1440	
PVC63	51	2760	
PVC75	67	5710	
PVC90	77	8280	


Attention: Adopt PVC40 or bigger pipe to be the main pipe.

6.2.3 Individual design of drainage pipe system


- The drainage pipe of air conditioner shall be installed separately with other sewage pipe, rainwater pipe and drainage pipe in building.
- The drainage pipe of the indoor unit with water pump should be apart from the one without water pump.


6.2.4 Supporter gap of drainage pipe

- In general, the supporter gap of the drainage pipe horizontal pipe and vertical pipe is respectively 1m~1.5m and 1.5m~2.0m.
- Each vertical pipe shall be equipped with not less than two hangers.
- Overlarge hanger gap for horizontal pipe shall create bending, thus leading to air block.



6.2.5 The horizontal pipe layout should avoid converse flow or bad flow






- The correct installation will not cause converse water flow and the slope of the branch pipes can be adjusted freely
- The false installation will cause converse water flow and the slope of the branch pipe cannot be adjusted.


6.2.6 Water storage pipe setting

- If the indoor unit has high extra static pressure and without water pump to elevate the condensate water, such as high extra static pressure duct unit, the water storage pipe should be set to avoid converse flow or blow water phenomena.



6.2.7 Lifting pipe setting of indoor unit with water pump


- The length of lifting pipe should not exceed the pump head of indoor unit water pump.
Pump head of big four way cassette: 750mm
Pump head of compact four way cassette: 500mm
- The drainage pipe should be set down inclined after the lifting pipe immediately to avoid wrong operation of water level switch.
- Refer the following picture for installation reference.



6.2.8 Blowhole setting

- For the concentrated drainage pipe system, there should design a blowhole at the highest point of main pipe to ensure the condensate water discharge smoothly.

- The air outlet shall face down to prevent dirt entering pipe.
- Each indoor unit of the system should be installed it.
- The installation should be considering the convenience for future cleaning.



6.2.9 The end of drainage pipe shall not contact with ground directly.


6.3 Drainage test

6.3.1 Water leakage test

After finishing the construction of drainage pipe system, fill the pipe with water and keep it for 24 hours to check whether there is leakage at joint section.

6.3.2 Water discharge test

1. Natural drainage mode(the indoor unit with outdoor drainage pump)
Infuse above 600ml water through water test hole slowly into the water collector, observe whether the water can discharge through the transparent hard pipe at drainage outlet.
2. Pump drainage mode
2.1 Disconnect the plug of water level switch, remove the cover of water test hole and slowly infuse about 2000ml water through the water test hole, be sure that the water will not touch the motor of drainage pump.



- 2.2 Power on and let the air conditioner operate for cooling. Check operation status of drainage pump, and then connect the plug of water level switch, check the operation sound of water pump and observe whether the water can discharge through the transparent hard pipe at drainage outlet. (In light of the length of drainage pipe, water shall be discharged about 1 minute delayed)
- 2.3 Stop the operation of air conditioner, power off the power supply and put the cover of water test hole back to the original place.
 - a. After stopped the air conditioner 3 minutes, check whether there is anything abnormal. If drainage pipes have not been distributed properly, over back-flow water shall cause the flashing of alarm indicator at remote-controlled receiving board and even water shall run over the water collector.
 - b. Continuously infusing water until water level alarmed, check whether the drainage pump could discharge water at once. If water level does not decline under warning water level 3 minutes later, it

shall cause shutdown of unit. When this situation happens, the normal startup only can be recovered by turning down power supply and eliminating accumulated water.

Note: Drain plug at the main water-containing plate is used for eliminating accumulated water in water-containing plate when maintaining air conditioner fault. During normal operation, the plug shall be filled in to prevent leakage.

6.4 Insulation work of drainage pipe

Refer the introduction to the insulation engineering parts.

7 Vacuum Drying and Leakage Checking

7.1 Purpose of vacuum drying

- Eliminating moisture in system to prevent the phenomena of ice-blockage and copper oxidation. Ice-blockage shall cause abnormal operation of system, while copper oxide shall damage compressor.
- Eliminating the non-condensable gas (air) in system to prevent the components oxidizing, pressure fluctuation and bad heat exchange during the operation of system.

7.2 Selection of vacuum pump

- The ultimate vacuum degree of vacuum pump shall be -756mmHg or above.
- Precision of vacuum pump shall reach 0.02mmHg or above.

7.3 Operation procedure for vacuum drying

Due to different construction environment, two kinds of vacuum drying ways could be chosen, namely ordinary vacuum drying and special vacuum drying.

7.3.1 Ordinary vacuum drying

1. When conduct first vacuum drying, connect pressure gauge to the infusing mouth of gas pipe and liquid pipe, and keep vacuum pump running for 1hour (vacuum degree of vacuum pump shall be reached -755mmHg).
2. If the vacuum degree of vacuum pump could not reach -755mmHg after 1 hour of drying, it indicates that there is moisture or leakage in pipeline system and need to go on with drying for half an hour.
3. If the vacuum degree of vacuum pump still could not reach -755mmHg after 1.5 hours of drying, check whether there is leakage source.
4. Leakage test: After the vacuum degree reaches -755mmHg, stop vacuum drying and keep the pressure for 1 hour. If the indicator of vacuum gauge does not go up, it is qualified. If going up, it indicates that there is moisture or leak source.

7.3.2 Special vacuum drying

The special vacuum drying method shall be adopted when:

1. Finding moisture during flushing refrigerant pipe.
2. Conducting construction on rainy day, because rain water might penetrated into pipeline.
3. Construction period is long, and rain water might penetrated into pipeline.
4. Rain water might penetrate into pipeline during construction.

Procedures of special vacuum drying are as follows:

1. Vacuum drying for 1 hour.
2. Vacuum damage, filling nitrogen to reach 0.5Kgf/cm² .
Because nitrogen is dry gas, vacuum damage could achieve the effect of vacuum drying, but this method could not achieve drying thoroughly when there is too much moisture. Therefore, special attention shall be drawn to prevent the entering of water and the formation of condensate water.
3. Vacuum drying again for half an hour.
If the pressure reaches -755mmHg, start to pressure leakage test. If it cannot reach the value, repeat vacuum damage and vacuum drying again for 1 hour.

- 4 Leakage test: After the vacuum degree reaches -755mmHg, stop vacuum drying and keep the pressure for 1 hour. If the indicator of vacuum gauge does not go up, it is qualified. If going up, it indicates that there is moisture or leak source.

8 Additional refrigerant charge

- After the vacuum drying process is carried out, the additional refrigerant charge process needs to be performed.
- The outdoor unit is factory charged with refrigerant. The additional refrigerant charge volume is decided by the diameter and length of the liquid pipe between indoor and outdoor unit. Refer the following formula to calculate the charge volume.

Diameter of liquid pipe (mm)	Φ6.35	Φ9.52
Formula	$V=15g/m \times (L-7.5)$	$V=30g/m \times (L-7.5)$

V: Additional refrigerant charge volume (g).

L : The length of the liquid pipe (m).

Note:

- Refrigerant may only be charged after performed the vacuum drying process.
- Always use gloves and glasses to protect your hands and eyes during the charge work.
- Use electronic scale or fluid infusion apparatus to weight refrigerant to be recharged. Be sure to avoid extra refrigerant charged, it may cause liquid hammer of the compressor or protections.
- Use supplementing flexible pipe to connect refrigerant cylinder, pressure gauge and outdoor unit. And The refrigerant should be charged in liquid state. Before recharging, The air in the flexible pipe and manifold gauge should be exhausted.
- After finished refrigerant recharge process, check whether there is refrigerant leakage at the connection joint part.(Using gas leakage detector or soap water to detect).

9 Engineering of insulation

9.1 Insulation of refrigerant pipe

9.1.1 Operational procedure of refrigerant pipe insulation

Cut the suitable pipe → insulation (except joint section) → flare the pipe → piping layout and connection → vacuum drying → insulate the joint parts

9.1.2 Purpose of refrigerant pipe insulation


- During operation, temperature of gas pipe and liquid pipe shall be over-heating or over-cooling extremely. Therefore, it is necessary to carry out insulation; otherwise it shall debase the performance of unit and burn compressor.
- Gas pipe temperature is very low during cooling. If insulation is not enough, it shall form dew and cause leakage.
- Temperature of gas pipe is very high (generally 50-100℃) during heating. Insulation work must be carried out to prevent hurt by carelessness touching.

9.1.3 Insulation material selection for refrigerant pipe

- The burning performance should over 120℃
- According to the local law to choose insulation materials
- The thickness of insulation layer shall be above 10mm.If in hot or wet environment place, the layer of insulation should be thicker accordingly.

9.1.4 Installation highlights of insulation construction

- Gas pipe and liquid pipe shall be insulated separately, if the gas pipe and liquid pipe were insulated together; it will decrease the performance of air conditioner.



- The insulation material at the joint pipe shall be 5~10cm longer than the gap of the insulation material.
- The insulation material at the joint pipe shall be inserted into the gap of the insulation material.
- The insulation material at the joint pipe shall be banded to the gap pipe and liquid pipe tightly.
- The linking part should be use glue to paste together
- Be sure not bind the insulation material over-tight, it may extrude out the air in the material to cause bad insulation and cause easy aging of the material.

9.2 Insulation of drainage pipe

9.2.1 Operational procedure of refrigerant pipe insulation

Select the suitable pipe → insulation (except joint section) → piping layout and connection → drainage test → insulate the joint parts

9.2.2 Purpose of drainage pipe insulation

The temperature of condensate drainage water is very low. If insulation is not enough, it shall form dew and cause leakage to damage the house decoration.

9.2.3 Insulation material selection for drainage pipe

- The insulation material should be flame retardant material, the flame retardancy of the material should be selected according to the local law.
- Thickness of insulation layer is usually above 10mm.
- Use specific glue to paste the seam of insulation material, and then bind with adhesive tape. The width of tape shall not be less than 5cm. Make sure it is firm and avoid dew.

9.2.4 Installation and highlights of insulation construction

- The single pipe should be insulated before connecting to another pipe, the joint part should be insulated after the drainage test.
- There should be no insulation gap between the insulation material.

10 Engineering of electrical wiring

10.1 Highlights of electrical wiring installation

- All field wiring construction should be finished by qualified electrician.
- Air conditioning equipment should be grounded according to the local electrical regulations.
- Current leakage protection switch should be installed.
- Do not connect the power wire to the terminal of signal wire.
- When power wire is parallel with signal wire, put wires to their own wire tube and remain at least 300mm gap.
- According to table in indoor part named “the specification of the power” to choose the wiring, make sure the selected wiring not small than the date showing in the table.
- Select different colors for different wire according to relevant regulations.

- Do not use metal wire tube at the place with acid or alkali corrosion, adopt plastic wire tube to replace it.
- There must be not wire connect joint in the wire tube If joint is a must, set a connection box at the place.
- The wiring with different voltage should not be in one wire tube.
- Ensure that the color of the wires of outdoor and the terminal No. are same as those of indoor unit respectively.

11 Test operation

11.1 The test operation must be carried out after the entire installation has been completed.

11.2 Please confirm the following points before the test operation.

- The indoor unit and outdoor unit are installed properly.
- Tubing and wiring are correctly completed.
- The refrigerant pipe system is leakage-checked.
- The drainage is unimpeded.
- The ground wiring is connected correctly.
- The length of the tubing and the added stow capacity of the refrigerant have been recorded.
- The power voltage fits the rated voltage of the air conditioner.
- There is no obstacle at the outlet and inlet of the outdoor and indoor units.
- The gas-side and liquid-side stop valves are both opened.
- The air conditioner is pre-heated by turning on the power.

11.3 Test operation

Set the air conditioner under the mode of "COOLING" by remote controller, and check the following points.

Indoor unit

- Whether the switch on the remote controller works well.
- Whether the buttons on the remote controller works well.
- Whether the air flow louver moves normally.
- Whether the room temperature is adjusted well.
- Whether the indicator lights normally.
- Whether the temporary buttons works well.
- Whether the drainage is normal.
- Whether there is vibration or abnormal noise during operation.

Outdoor unit

- Whether there is vibration or abnormal noise during operation.
- Whether the generated wind, noise, or condensed of by the air conditioner have influenced your neighborhood.
- Whether any of the refrigerant is leaked.

Part 5

Electrical Control System

1. Electrical Control Function	107
2. Troubleshooting	121
3. Controller	148

1. Electrical Control Function

1.1 Definition

T1: Indoor room temperature

T2: Coil temperature of indoor heat exchanger middle.

T2B: Coil temperature of indoor heat exchanger outlet.

T3: Coil temperature of condenser

T4: Outdoor ambient temperature

T5: Compressor discharge temperature

1.2 Main Protection

1.2.1 Time delay at restart for compressor.

1.2.2 Temperature protection of compressor top

The unit will stop working when the compressor top temp. protector cut off, and will restart after the compressor top temp. protector restart.

1.2.3 Temperature protection of compressor discharge

When the compressor discharge temp. is getting higher, the running frequency will be limited as below rules:

For 12K-18K units & MOG-24HFN1-MT0W:

---Compressor discharge temp. $T_5 > 115^{\circ}\text{C}$ for 5s, compressor stops.

--- $108 \leq T_5 \leq 115^{\circ}\text{C}$, decrease the frequency to the lower level every 3 minutes till F1.

--- $90 \leq T_5 < 105^{\circ}\text{C}$, keep running at the current frequency.

--- $T_5 < 90^{\circ}\text{C}$, no limit for frequency.

For other units:

---If $102^{\circ}\text{C} < T_5 < 115^{\circ}\text{C}$, decrease the frequency to the lower level every 2 minutes till to F1.

---If $T_5 > 115^{\circ}\text{C}$ for 10 seconds, the compressor will stop and restart till $T_5 < 90^{\circ}\text{C}$.

1.2.4 Sensor protection at open circuit and breaking disconnection.

1.2.5 Indoor fan delayed open function

When the unit starts up, the louver will be active immediately and the indoor fan will open 10s later.

If the unit runs in heating mode, the indoor fan will be also controlled by anti-cold wind function.


1.2.6 Fan speed is out of control

When Indoor Fan Speed keeps too low for 50s, the unit will stop and the LED will display the failure


1.3 Operation Modes and Functions

1.3.1 Fan mode

- (1) Outdoor fan and compressor stop.
- (2) Temperature setting function is disabled, and no setting temperature is displayed.
- (3) Indoor fan can be set to high/med/low/auto.
- (4) The louver operates same as in cooling mode.
- (5) Auto fan:
For 12-18K units, MUE-24HRFN1-MW, MTB-24HRFN1-MW, MCD-24HRFN1-MW:



For other units:



1.3.2 Cooling Mode

1.3.2.1 Electronic Expansion Valve (EXV) Control(Excluding MOC-12HFN1-MS0W, MOF-18HFN1-MS0W)

For MOC-12HFN1-MV0W, MOZ-12HFN1-MW0W, MOF-18HFN1-MU0W:

- 1.EXV will be fully closed when turning on the power. Then EXV will be standby with 480P open and will open to target angle after compressor starts.
- 2.EXV will close with -160P when compressor stops. Then EXV will be standby with 480P open and will open to target angle after compressor starts.
3. The initial open angle of EXV is 220P, adjustment range is 80-480p. The unit starts to work for 3 minutes then adjusting open angle according to the temperature of compressor discharge every 2 minutes.

For MOG-24HFN1-MT0W:

- 1.EXV will be fully closed when turning on the power. Then EXV will be standby with 480P open and will

open to target angle after compressor starts.

2.EXV will close with -160P when compressor stops. Then EXV will be standby with 480P open and will open to target angle after compressor starts.

3. The initial open angle of EXV is 140P, adjustment range is 80-480p. The unit starts to work for 3 minutes then adjusting open angle according to the temperature of compressor discharge every 2 minutes.

For other models:


1.EXV will be fully closed when turning on the power. Then EXV will be standby with 300P open and will open to target angle after compressor starts.

2.EXV will close with -160P when compressor stops. Then EXV will be standby with 300P open and will open to target angle after compressor starts.


3. The initial open angle of EXV is 300P. The unit starts to work for 3 minutes then adjusting open angle according to the temperature of compressor discharge every 2 minutes.

1.3.2.2 Outdoor fan running rules

For MOC-12HFN1-MS0W, MOC-12HFN1-MV0W, MOZ-12HFN1-MW0W, MOF-18HFN1-MS0W, MOF-18HFN1-MU0W, MOG-24HFN1-MT0W:



For other models:




1.3.2.3 Indoor fan running rules


In cooling mode, indoor fan runs all the time and the speed can be selected as high, medium, low and auto.

The auto fan:


For Console:



For 2nd Ceiling-floor & Compact cassette & A5 Duct(12-18K), MUE-24HRFN1-MW & MTB-24HRFN1-MW, MCD-24HRFN1-MW



For other units:



1.3.2.4 Evaporator low temperature T2 protection.

For 12K-18K units, MUE-24HRFN1-MW, MTB-24HRFN1-MW, MCD-24HRFN1-MW (Excluding MCA2U-12HRFN1-M(B), MUBU-12HRFN1-M(B), MTBU-12HRDN1-M(B)):

--- $T2 < 0^\circ\text{C}$, the compressor will stop and restart when $T2 \geq 5^\circ\text{C}$.

--- $0^{\circ}\text{C} \leq T_2 < 4^{\circ}\text{C}$, the compressor frequency will be limited and decreased to the lower level every 1 minute till off.

--- $4^{\circ}\text{C} \leq T_2 \leq 7^{\circ}\text{C}$, the compressor will keep the current frequency.

--- $T_2 > 7^{\circ}\text{C}$, the compressor frequency will not be limited.

For MCA2U-12HRFN1-M(B), MUBU-12HRFN1-M(B), MTBU-12HRDN1-M(B): When $T_2 < 4^{\circ}\text{C}$ and lasts for 250s or $T_2 < 0^{\circ}\text{C}$, the indoor has no capacity demand and resume till $T_2 > 8^{\circ}\text{C}$.

For other units: When $T_2 < 2^{\circ}\text{C}$ and lasts for 3 minutes, the indoor has no capacity demand and resume till $T_2 \geq 7^{\circ}\text{C}$.

1.3.2.5 Condenser high temperature T3 protection

For 12K-18K units&MOG-24HFN1-MT0W:

--- $55^{\circ}\text{C} < T_3 < 60^{\circ}\text{C}$, the compressor frequency will decrease to the lower level every 3 minutes till F1 and then runs at F1. If $T_3 < 54^{\circ}\text{C}$, the compressor will keep running at the current frequency.

--- $T_3 < 52^{\circ}\text{C}$, the compressor will not limit the frequency and resume to the former frequency.

--- $T_3 > 60^{\circ}\text{C}$ for 5 seconds, the compressor will stop until $T_3 < 52^{\circ}\text{C}$.

For other units: When $T_3 > 65^{\circ}\text{C}$ for 3 seconds, the compressor will shut off. When $T_3 < 52^{\circ}\text{C}$, the compressor will restart.

1.3.3 Heating Mode

1.3.2.1 Electronic Expansion Valve (EXV) Control(Excluding MOC-12HFN1-MS0W, MOF-18HFN1-MS0W)

For MOC-12HFN1-MV0W, MOZ-12HFN1-MW0W, MOF-18HFN1-MU0W:

1. EXV will be fully closed when turning on the power. Then EXV will be standby with 480P open and will open to target angle after compressor starts.

2. EXV will close with -160P when compressor stops. Then EXV will be standby with 480P open and will open to target angle after compressor starts.

3. The initial open angle of EXV is 480P, adjustment range is 80-480p. The unit starts to work for 3 minutes then adjusting open angle according to the temperature of compressor discharge every 2 minutes.

For MOG-24HFN1-MT0W:

1. EXV will be fully closed when turning on the power. Then EXV will be standby with 480P open and will open to target angle after compressor starts.

2. EXV will close with -160P when compressor stops. Then EXV will be standby with 480P open and will open to target angle after compressor starts.

3. The initial open angle of EXV is 110P, adjustment range is 80-480p. The unit starts to work for 3 minutes then adjusting open angle according to the temperature of compressor discharge every 2 minutes.

For other models:

1. EXV will be fully closed when turning on the power. Then EXV will be standby with 300P open and will


open to target angle after compressor starts.

2.EXV will close with -160P when compressor stops. Then EXV will be standby with 300P open and will open to target angle after compressor starts.


3. The initial open angle of EXV is 300P..The unit starts to work for 3 minutes then adjusting open angle according to the temperature of compressor discharge every 2 minutes.

1.3.3.2 Outdoor fan running rules:

For MOC-12HFN1-MS0W, MOC-12HFN1-MV0W, MOZ-12HFN1-MW0W, MOF-18HFN1-MS0W, MOF-18HFN1-MU0W, MOG-24HFN1-MT0W:



For other models:




1.3.3.3 Indoor fan running rules:


When the compressor is on, the indoor fan can be set to high/med/low/auto. And the anti-cold wind function has the priority.

Auto fan action:


For Console



For 2nd Ceiling-floor, Compact cassette, A5 Duct(12-18K), MUE-24HRFN1-MW, MTB-24HRFN1-MW, MCD-24HRFN1-MW



For other units:



1.3.3.4 Defrosting mode:

For 12K-18Kunits & MOG-24HFN1-MT0W(Excluding MOZ-12HFN1-MW0W):

Condition of defrosting:

--- $T_4 > 0^{\circ}\text{C}$,

Defrosting starts when either of the following ①&②:

- ①The units run with $T_3 < 3^{\circ}\text{C}$ for 40 minutes and T_3 keeps lower than $\text{TCDI}^{\circ}\text{C}$ for more than 3 minutes.
- ②:The units run with $T_3 < 3^{\circ}\text{C}$ for 80 minutes and T_3 keeps lower than $(\text{TCDI}+2)^{\circ}\text{C}$ for more than 3 minutes..

--- $T_4 < 0^{\circ}\text{C}$,

If ① and ② are satisfied, then the program judges if T_2 has decreased more than 5°C . When T_2 has decreased more than 5°C , enter the defrosting mode.

---No matter what value of the T_4 is and whether the T_2 drops more than 5°C or not, if the machine runs with $T_3 < 3^{\circ}\text{C}$ for more than 120 minutes and T_3 keeps lower than $(T_{CDI} + 4)^{\circ}\text{C}$ for more than 3 minutes, the machine will enter defrosting mode.

Condition of ending defrosting:

If any one of the following items is satisfied, the defrosting will finish and the machine will turn to normal heating mode.


--- T_3 rises to be higher than $T_{CDE1}^{\circ}\text{C}$.

--- T_3 keeps to be higher than $T_{CDE2}^{\circ}\text{C}$ for 80 seconds.


---The machine has run for 10 minutes in defrosting mode.

● Defrosting action:

For 12K units:




For 18K units & MOG-24HFN1-MT0W:



For 24K(Excluding MOG-24HFN1-MT0W) & 48K units:

Condition of defrosting:



Time conditions:

time1

Time conditions(Meet the following conditions)

1. Running in heating mode
2. $T4 \geq 3^{\circ}\text{C}$
3. Compressor is on
4. $T3 \leq \text{TempEnterDefrost_ADD } ^{\circ}\text{C}$

Cleared conditions (Meet any one of the following conditions)

1. Compressor is off.
2. $T3 > \text{TempEnterDefrost_ADD } ^{\circ}\text{C}$

Time2

Time conditions (Meet the following conditions)

1. Running in heating mode
2. $T4 < 3^{\circ}\text{C}$
3. Compressor is on
4. $T3 \leq \text{TempEnterDefrost_ADD } ^{\circ}\text{C}$

Cleared conditions (Meet any one of the following conditions)

1. Compressor is off and $T3 > \text{TempEnterDefrost_ADD} + 2^{\circ}\text{C}$ last for 20 minutes
2. Running in cooling mode.
3. Compressor is off for 1 hour.

Condition of entry defrosting:

time1+ time2 \geq 40 minutes, When defrosting is end,time1 and time2 are cleared.

Condition of ending defrosting:

If any one of following items is satisfied, defrosting will stop and the machine will turn to normal heating mode.

- ① The defrosting time achieves 10min;
- ② $T3 \geq \text{TempQuitDefrost_ADD } ^{\circ}\text{C}$;
- ③ $T3 \geq 7^{\circ}\text{C}$ for 60seconds.

For 36K units:

Condition of defrosting:


$T3 \leq \text{TempEnterDefrost_ADD } ^{\circ}\text{C}$ and lasts for 40 minutes.

Condition of ending defrosting:

If any one of following items is satisfied, defrosting will stop and the machine will turn to normal heating mode.

- ① $T3 > \text{TempQuitDefrost_ADD } ^\circ\text{C}$;
- ② The defrosting time achieves 10min.
- ③ Turn to other modes or off.

Defrosting action:



1.3.3.5 High evaporator coil temp.T2 protection:

For 12K-18K units, MUE-24HRFN1-MW,MTB-24HRFN1-MW,MCD-24HRFN1-MW:

--- $T2 > TEH2^\circ\text{C}$, the compressor running frequency decreases to the lower level every 20s.

When the frequency decreases to F2 and the T2 is still over $TEH2^\circ\text{C}$ for 3 minutes, the compressor will stop.

--- $T2 < 48^\circ\text{C}$ or $TEH2^\circ\text{C} < T2 < 48^\circ\text{C}$ for 6 minutes, the frequency will not be limited.

--- $T2 > 60^\circ\text{C}$, the compressor will stop and restart when $T2 < 48^\circ\text{C}$.

For other units: $T2 > 60^\circ\text{C}$, the compressor will stop and restart when $T2 \leq 54^\circ\text{C}$.

1.3.4 Auto-mode

This mode can be chosen with remote controller and the setting temperature can be changed between $17\sim 30^\circ\text{C}$.

In auto mode, the machine will choose cooling, heating or fan-only mode according to ΔT ($\Delta T = T1 - Ts$).

For 12K-18K units, MUE-24HRFN1-MW,MTB-24HRFN1-MW,MCD-24HRFN1-MW:

$\Delta T = T1 - Ts$	Running mode
$\Delta T > 1^\circ\text{C}$	Cooling
$-1 < \Delta T \leq 1^\circ\text{C}$	Fan-only
$\Delta T \leq -1^\circ\text{C}$	Heating

For other units:

$\Delta T = T_1 - T_s$	Running mode
$\Delta T \geq 2^\circ\text{C}$	Cooling
$-1 \leq \Delta T < 2^\circ\text{C}$	Fan-only
$\Delta T < -1^\circ\text{C}$	Heating

Indoor fan will run at auto fan of the relevant mode.

The louver operates same as in relevant mode.

If the machine switches mode between heating and cooling, the compressor will keep stopping for 15 minutes and then choose mode according to $T_1 - T_s$.

If the setting temperature is modified, the machine will choose running function again.

1.3.5 Drying mode

For 12K-18K units, MUE-24HRFN1-MW, MTB-24HRFN1-MW, MCD-24HRFN1-MW:

1.3.5.1 Indoor fan speed is fixed at low and can't be changed. The louver angle is the same as in cooling mode.

1.3.5.2 Low indoor room temperature protection

In drying mode, if room temperature is lower than 10°C , the compressor will stop and not resume until room temperature exceeds 12°C .

1.3.5.3 Evaporator anti-freezing protection, condenser high temperature protection and outdoor unit frequency limit are active and the same as that in cooling mode.

1.3.5.4 The outdoor fan operates the same as in cooling mode.

For other units:

Drying mode works the same as cooling mode in low speed.

All protections are active and the same as that in cooling mode.

1.3.6 Timer function

1.3.6.1 Timing range is 24 hours.

1.3.6.2 Timer on. The machine will turn on automatically when reaching the setting time.

1.3.6.3 Timer off. The machine will turn off automatically when reaching the setting time.

1.3.6.4 Timer on/off. The machine will turn on automatically when reaching the setting "on" time, and then turn off automatically when reaching the setting "off" time.

1.3.6.5 Timer off/on. The machine will turn off automatically when reaching the setting "off" time, and then turn on automatically when reaching the setting "on" time.

1.3.6.6 The timer function will not change the AC current operation mode. Suppose AC is off now, it will not start up firstly after setting the "timer off" function. And when reaching the setting time, the timer LED will be off and the AC running mode has not been changed.

1.3.6.7 The setting time is relative time.

1.3.7 Economy function

For console:

1.3.7.1 The economy function is available in cooling, heating or auto mode.

1.3.7.2. Operation process in sleep mode is as follow:

When cooling, the setting temperature rises 1°C (be lower than 30°C) every one hour, 2 hours later the setting temperature stops rising and the indoor fan is fixed at auto speed.

When heating, the setting temperature decreases 1°C (be higher than 17°C) every one hour, 2 hours later the setting temperature stops rising and indoor fan is fixed at auto speed. (Anti-cold wind function has the priority).

1.3.7.3 Operation time in sleep mode is 7 hours. After 7 hours the AC quits this mode and turns off

1.3.7.4 Shutdown, change the mode or speed setting will cancel the economic operation.

1.3.7.5 When user uses timer off function in sleep mode (or sleep function in timer off mode), if the timing is less than 7 hours, sleep function will be cancelled when reaching the setting time. If the timing is more than 7 hours, the machine will not stop until reaches the setting time in sleep mode.

For other units:

1.3.7.1 The economy function is available in cooling, heating or auto mode.

1.3.7.2. Operation process in sleep mode is as follow:

When cooling, the setting temperature rises 1°C (be lower than 30°C) every one hour, 2 hours later the setting temperature stops rising and the indoor fan is fixed at low speed.

When heating, the setting temperature decreases 1°C (be higher than 17°C) every one hour, 2 hours later the setting temperature stops rising and indoor fan is fixed at low speed. (Anti-cold wind function has the priority).

1.3.7.3 Operation time in sleep mode is 7 hours. After 7 hours the AC quits this mode and turns off

1.3.7.4 Timer setting is available

1.3.8 Auto-Restart function

The indoor unit is equipped with auto-restart function, which is carried out through an auto-restart module. In case of a sudden power failure, the module memorizes the setting conditions before the power failure. The unit will resume the previous operation setting (not including swing function) automatically after 3 minutes when power returns.

1.3.9 Drain pump control (For cassette)

Adopt the water-level switch to control the action of drain pump.

Main action under different condition :(every 5 seconds the system will check the water level one time)

1. When the A/C operates with cooling (including auto cooling), dehumidifying, and forced cooling mode, the pump will start running immediately and continuously, till stop cooling.

2. Once the water level increase and up to the control point, LED will alarm and the drain pump open and continue checking the water level. If the water level fall down and LED disarmed (drain pump delay close 1 minute) and operate with the last mode. Otherwise the entire system stop operating (including the pump) and LED remain alarming after 3 minutes,

1.3.10 Point Check Function (Excluding 12K &18K units &MOG-24HFN1-MT0W)

There is a check switch in outdoor PCB.

Press the switch SW1 to check the states of unit when the unit is running.

Press the switch N times it will display the content corresponding to No. N. After getting into the check function, it will display No. N with 1.5s, meanwhile the low bit decimal of digit display flashing, indicated to get into the check function display. After 1.5s, it will display the content corresponding to No. N. the digital display tube will display the follow procedure when push SW1 each time.


N	Display	Remark		
00	Normal display	Display running frequency, running state or malfunction code		
01	Indoor unit capacity demand code	Norm code *HP*10 If capacity demand code is higher than 99, the digital display tube will show single digit and tens digit. (For example, the digital display tube show "5.0",it means the capacity demand is 15. the digital display tube show "60",it means the capacity demand is 6.0)		
02	Amendatory capacity demand code			
03	The frequency after the capacity requirement transfer			
04	The frequency after the frequency limit			
05	The frequency of sending to 341			
06	Indoor unit evaporator outlet temp.(Cooling:T2, heating:T2B)	If the temp. is lower than 0 degree, the digital display tube will show "0".If the temp. is higher than 70 degree, the digital display tube will show "70".		
07	Condenser pipe temp.(T3)	If the temp. is lower than -9 degree, the digital display tube will show "-9".If the temp. is higher than 70 degree, the digital display tube will show "70". If the indoor unit is not connected, the digital display tube will show: "——"		
08	Outdoor ambient temp.(T4)			
09	Compressor discharge temp.(T5)	The display value is between 13~129 degree. If the temp. is lower than 13 degree, the digital display tube will show "13".If the temp. is higher than 99 degree, the digital display tube will show single digit and tens digit. (For example, the digital display tube show "0.5",it means the compressor discharge temp. is 105 degree. the digital display tube show "1.6",it means the compressor discharge temp. is 116 degree)		
10	AD value of current	The display value is hex number.		
11	AD value of voltage			
12	Indoor unit running mode code	Off:0, Fan only 1,Cooling:2, Heating:3		
13	Outdoor unit running mode code	Off:0, Fan only 1,Cooling:2, Heating:3, Forced cooling:4		
14	EXV open angle	Actual data/4. If the value is higher than 99, the digital display tube will show single digit and tens digit. For example ,the digital display tube show "2.0",it means the EXV open angle is $120 \times 4 = 480p$.)		
15	Frequency limit symbol	Bit7	Frequency limit caused by IGBT radiator	The display value is hex number. For example, the digital display tube show 2A,then Bit5=1, Bit3=1, Bit1=1. It means frequency limit caused by T4,T3 and current.
		Bit6	Frequency limit caused by PFC	
		Bit5	Frequency limit caused by T4.	
		Bit4	Frequency limit caused by T2.	
		Bit3	Frequency limit caused by T3.	
		Bit2	Frequency limit caused by T5.	
		Bit1	Frequency limit caused by current	
		Bit0	Frequency limit caused by voltage	
16	DC fan motor speed			
17	IGBT radiator temp.(Reserved)	The display value is between 30~120 degree. If the temp. is lower than 30 degree, the digital display tube will show "30".If		

		the temp. is higher than 99 degree, the digital display tube will show single digit and tens digit. (For example, the digital display tube show "0.5",it means the IGBT radiator temp. is 105 degree. the digital display tube show "1.6",it means the IGBT radiator temp. is 116 degree)
18	Indoor unit number	The indoor unit can communicate with outdoor unit well.
19	Condenser pipe temp. of 1# indoor unit	If the temp. is lower than 0 degree, the digital display tube will show "0".If the temp. is higher than 70 degree, the digital display tube will show "70". If the capacity demand is 0, , the digital display tube will show "0. If the indoor unit is not connected, the digital display tube will show: "——"
20	Condenser pipe temp. of 2# indoor unit	
21	Condenser pipe temp. of 3# indoor unit	
22	1# Indoor unit capacity demand code	Norm code *HP*10 If capacity demand code is higher than 99, the digital display tube will show single digit and tens digit. (For example, the digital display tube show "5.0",it means the capacity demand is 15. the digital display tube show "60",it means the capacity demand is 6.0). If the indoor unit is not connected, the digital display tube will show: "——"
23	2# Indoor unit capacity demand code	
24	3# Indoor unit capacity demand code	


2. Troubleshooting

2.1 Display board


2.1.1 Icon explanation on indoor display board (Super slim cassette 24K~48K).




2.1.2 Icon explanation on indoor display board (Compact cassette 12K~18K).




2.1.3 Icon explanation on indoor display board (Ceiling & Floor, 12K~18K)




2.1.4 Icon explanation on indoor display board (Ceiling & Floor, 24K~48K)




2.1.5 Icon explanation on indoor display board (A5 Duct)



2.1.6 Icon explanation on indoor display board (Console)



2.1.7 Display board of auto-lifting panel of 4 way cassette (24K~48K)



2.2 Indoor unit malfunction

For Console

NO.	Malfunction	Running lamp	Timer lamp	Defrosting lamp
1	Open or short circuit of T1 temperature sensor	☆	X	X
2	Open or short circuit of T2 temperature sensor	X	X	☆
3	Communication malfunction between indoor and outdoor units.	X	☆	X
4	Outdoor fan speed has been out of control	X	☆	O
5	Indoor EEPROM malfunction	☆	☆	X
6	IPM module protection	☆	X	☆
7	Open or short circuit of T3 or T4 temperature sensor or Outdoor unit EEPROM parameter error	☆	☆	☆
8	Over voltage or over low voltage protection	☆	☆	O
9	Top temperature protection of compressor	☆	O	X
10	Inverter compressor drive protection	☆	◎	X
11	Indoor fan Speed has been out of control.	☆	O	☆
O(light) X(off) ☆(flash at 5Hz) ◎(flash at 0.5Hz)				

For 12K & 18K units(excluding console), MUE-24HRFN1-MW,MTB-24HRFN1-MW,MCD-24HRFN1-MW

NO.	Malfunction	Running lamp	Timer lamp	Defrosting lamp	Alarm lamp	Display(nixie tube)
1	Open or short circuit of T1 temperature sensor	☆	X	X	X	E0
2	Open or short circuit of T2 temperature sensor	X	X	☆	X	E1
3	Communication malfunction between indoor and outdoor units.	X	☆	X	X	E2
4	Water-level alarm malfunction	X	X	X	☆	E3
5	Indoor EEPROM malfunction	☆	☆	X	X	E4
6	IPM module protection	☆	X	X	O	E5
7	Open or short circuit of T3 or T4 temperature sensor or outdoor EEPROM is malfunction	☆	O	X	X	E6
8	Outdoor fan speed has been out of control	☆	O	☆	X	E7
9	Refrigerant Leakage Detection	O	X	☆	☆	EC
10	Communication malfunction between main PCB and up-down panel PCB	☆	X	☆	☆	F0
11	Up-down panel malfunction	X	☆	☆	☆	F1
12	Indoor fan speed has been out of control	☆	O	O	X	F5
13	Outdoor unit voltage protection	☆	O	X	O	P0
14	Compressor top temperature protection	☆	X	O	X	P1
15	Outdoor unit over-current protection	☆	☆	☆	X	P2
16	Inverter compressor drive error	☆	◎	X	X	P4
O(light) X(off) ☆(flash at 2.5Hz) ◎(flash at 0.5Hz)						
F0,F1 is only available for super-slim cassette						

For 24K~48K Units(excluding MUE-24HRFN1-MW &MTB-24HRFN1-MW)

NO.	Malfunction	Defrosting lamp	Alarm lamp	Running lamp	Timer lamp	Display(digital tube)
1	Communication malfunction between indoor and outdoor units.	X	X	X	☆	E1
2	Open or short circuit of T1 temperature sensor	X	X	☆	X	E2
3	Open or short circuit of T2 temperature sensor	X	X	☆	X	E3
4	Open or short circuit of T2B temperature sensor	X	X	☆	X	E4
5	Indoor EEPROM malfunction	☆	X	X	X	E7
6	Indoor fan speed has been out of control	☆	☆	X	X	E8
7	Refrigerant leakage detection	☆	☆	O	X	EC
8	Outdoor unit malfunction	X	◎	X	X	Ed
9	Water-level alarm malfunction	X	☆	X	X	EE
10	Communication malfunction between main PCB and up-down panel PCB	☆	☆	☆	X	F0
11	Up-down panel malfunction	☆	☆	X	☆	F1
O (on) X(off) ☆(flash at 5Hz) ◎(flash at 0.5Hz) F0,F1 is only available for super-slim cassette						

2.3 Outdoor unit malfunction

For MOC-12HFN1-MS0W, MOC-12HFN1-MV0W, MOF-18HFN1-MS0W, MOF-18HFN1-MU0W, MOG-24HFN1-MT0W:

No.	Problems	Green	Red	IU display
1	standby for normal	O	X	
2	Operation normally	X	O	
3	IPM malfunction or IGBT over-strong current protection	☆	X	P0
4	Over voltage or too low voltage protection	O	O	P1
5	Inverter compressor drive error	X	☆	P4
6	Inverter compressor drive error	☆	O	P4
7	Communication malfunction between compressor driver board and outdoor main board	☆	☆	P4
8	Compressor driver board EEPROM malfunction	O	☆	E5

O (light) X (off) ☆ (2.5Hz flash)

For other models:


Display	Malfunction or Protection
E0	Outdoor EEPROM malfunction
E2	Communication malfunction between indoor and outdoor units
E3	Communication malfunction between IPM board and outdoor main board
E4	Open or short circuit of outdoor temperature sensors
E5	Voltage protection of compressor
E8	Outdoor fan speed has been out of control
P0	Top temperature protection of compressor
P1	High pressure protection(For 36K-48K)
P2	Low pressure protection(For 36K-48K)
P3	Current protection of compressor
P4	Discharge temperature protection of compressor
P5	High temperature protection of condenser
P6	IPM module protection
P7	High temperature protection of evaporator

In low ambient cooling mode, the LED displays “LC” or alternative displays between running frequency and “LC”(each displays 0.5s)


2.4 Solving steps for typical malfunction

2.4.1 For the indoor unit


2.4.1.1 Open or short circuit of temperature sensor



2.4.1.2. Outdoor unit malfunction




2.4.1.3. Indoor EEPROM malfunction



EEPROM: An electrically erasable programmable read-only memory whose contents can be erased and reprogrammed using a pulsed voltage.


2.4.1.4. Water-level alarm malfunction




2.4.1.5. Communication malfunction between indoor and outdoor units

The same as E2 in outdoor.

2.4.1.5. Indoor fan Speed has been out of control. (Only for the units used DC motor)




DC motor voltage input and output (control chip is inside the motor)



DC motor voltage input and output

NO.	Color	Signal	Voltage
1	Red	Vs/Vm	200~380V
2	---	---	---
3	Black	GND	0V
4	White	Vcc	13.5~16.5V
5	Yellow	Vsp	0~6.5V
6	Blue	FG	13.5~16.5V

2.4.1.6. Refrigerant Leakage Detection



2.4.1.7. Inverter compressor drive protection


Refer to the outdoor unit P6 malfunction part to solve this problem.

2.4.1.8 Communication malfunction between indoor and outdoor units


The same as E2 in outdoor.

2.4.2 For the super-slim cassette with up-down panel

2.4.2.1 Communication error between indoor unit and up-down panel




2.4.2.2 Up-down panel is defective




2.4.4 For the outdoor unit

2.4.4.2. E0 malfunction




EEPROM: An electrically erasable programmable read-only memory whose contents can be erased and reprogrammed using a pulsed voltage.


2.4.4.3. E2 malfunction(For 12-18K units, MUE-24HRFN1-MW, MTB-24HRFN1-MW, MCD-24HRFN1-MW):




2.4.4.4. E2 malfunction (For other units)




2.4.4.5. E3 malfunction



2.4.4.6. E4 malfunction




2.4.4.7. E5 malfunction




2.4.4.8. E8 malfunction

The same as E8 in indoor.


2.4.4.9. P0 malfunction




2.4.4.10. P1 malfunction (Only for 36K~48K)



2.4.4.11. P2 malfunction (Only for 36K~48K)




2.4.4.12. P3 malfunction




2.4.4.13. P4 malfunction

When compressor discharge temperature is higher than 115°C, the unit will stop, and unit runs again when compressor discharge temperature is lower than 90°C.




2.4.4.14. P5 malfunction

When condenser high temp. is more than 65°C, the unit will stop, and unit runs again when outdoor pipe temp. less than 52°C.




2.4.4.15. P6 malfunction

At first test the resistance between every two ports of U, V, W of IPM and P, N. If any result of them is 0 or close to 0, the IPM is defective. Otherwise, please follow the procedure below:



2.4.4.16. P7 malfunction



Appendix 1 Temperature Sensor Resistance Value Table (°C--K)

°C	K Ohm	°C	K Ohm	°C	K Ohm	°C	K Ohm
-20	115.266	20	12.6431	60	2.35774	100	0.62973
-19	108.146	21	12.0561	61	2.27249	101	0.61148
-18	101.517	22	11.5000	62	2.19073	102	0.59386
-17	96.3423	23	10.9731	63	2.11241	103	0.57683
-16	89.5865	24	10.4736	64	2.03732	104	0.56038
-15	84.2190	25	10.000	65	1.96532	105	0.54448
-14	79.3110	26	9.55074	66	1.89627	106	0.52912
-13	74.5360	27	9.12445	67	1.83003	107	0.51426
-12	70.1698	28	8.71983	68	1.76647	108	0.49989
-11	66.0898	29	8.33566	69	1.70547	109	0.48600
-10	62.2756	30	7.97078	70	1.64691	110	0.47256
-9	58.7079	31	7.62411	71	1.59068	111	0.45957
-8	56.3694	32	7.29464	72	1.53668	112	0.44699
-7	52.2438	33	6.98142	73	1.48481	113	0.43482
-6	49.3161	34	6.68355	74	1.43498	114	0.42304
-5	46.5725	35	6.40021	75	1.38703	115	0.41164
-4	44.0000	36	6.13059	76	1.34105	116	0.40060
-3	41.5878	37	5.87359	77	1.29078	117	0.38991
-2	39.8239	38	5.62961	78	1.25423	118	0.37956
-1	37.1988	39	5.39689	79	1.21330	119	0.36954
0	35.2024	40	5.17519	80	1.17393	120	0.35982
1	33.3269	41	4.96392	81	1.13604	121	0.35042
2	31.5635	42	4.76253	82	1.09958	122	0.3413
3	29.9058	43	4.57050	83	1.06448	123	0.33246
4	28.3459	44	4.38736	84	1.03069	124	0.32390
5	26.8778	45	4.21263	85	0.99815	125	0.31559
6	25.4954	46	4.04589	86	0.96681	126	0.30754
7	24.1932	47	3.88673	87	0.93662	127	0.29974
8	22.5662	48	3.73476	88	0.90753	128	0.29216
9	21.8094	49	3.58962	89	0.87950	129	0.28482
10	20.7184	50	3.45097	90	0.85248	130	0.27770
11	19.6891	51	3.31847	91	0.82643	131	0.27078
12	18.7177	52	3.19183	92	0.80132	132	0.26408
13	17.8005	53	3.07075	93	0.77709	133	0.25757
14	16.9341	54	2.95896	94	0.75373	134	0.25125
15	16.1156	55	2.84421	95	0.73119	135	0.24512
16	15.3418	56	2.73823	96	0.70944	136	0.23916
17	14.6181	57	2.63682	97	0.68844	137	0.23338
18	13.9180	58	2.53973	98	0.66818	138	0.22776
19	13.2631	59	2.44677	99	0.64862	139	0.22231

Appendix 2

Unit: °C---K				Discharge temp. sensor table			
-20	542.7	20	68.66	60	13.59	100	3.702
-19	511.9	21	65.62	61	13.11	101	3.595
-18	483	22	62.73	62	12.65	102	3.492
-17	455.9	23	59.98	63	12.21	103	3.392
-16	430.5	24	57.37	64	11.79	104	3.296
-15	406.7	25	54.89	65	11.38	105	3.203
-14	384.3	26	52.53	66	10.99	106	3.113
-13	363.3	27	50.28	67	10.61	107	3.025
-12	343.6	28	48.14	68	10.25	108	2.941
-11	325.1	29	46.11	69	9.902	109	2.86
-10	307.7	30	44.17	70	9.569	110	2.781
-9	291.3	31	42.33	71	9.248	111	2.704
-8	275.9	32	40.57	72	8.94	112	2.63
-7	261.4	33	38.89	73	8.643	113	2.559
-6	247.8	34	37.3	74	8.358	114	2.489
-5	234.9	35	35.78	75	8.084	115	2.422
-4	222.8	36	34.32	76	7.82	116	2.357
-3	211.4	37	32.94	77	7.566	117	2.294
-2	200.7	38	31.62	78	7.321	118	2.233
-1	190.5	39	30.36	79	7.086	119	2.174
0	180.9	40	29.15	80	6.859	120	2.117
1	171.9	41	28	81	6.641	121	2.061
2	163.3	42	26.9	82	6.43	122	2.007
3	155.2	43	25.86	83	6.228	123	1.955
4	147.6	44	24.85	84	6.033	124	1.905
5	140.4	45	23.89	85	5.844	125	1.856
6	133.5	46	22.89	86	5.663	126	1.808
7	127.1	47	22.1	87	5.488	127	1.762
8	121	48	21.26	88	5.32	128	1.717
9	115.2	49	20.46	89	5.157	129	1.674
10	109.8	50	19.69	90	5	130	1.632
11	104.6	51	18.96	91	4.849		
12	99.69	52	18.26	92	4.703		
13	95.05	53	17.58	93	4.562		
14	90.66	54	16.94	94	4.426		
15	86.49	55	16.32	95	4.294	B(25/50)=3950K	
16	82.54	56	15.73	96	4.167		
17	78.79	57	15.16	97	4.045	R(90°C)=5KΩ±3%	
18	75.24	58	14.62	98	3.927		
19	71.86	59	14.09	99	3.812		

Appendix 3

Normal voltage of P and N			
208-240V(1-phase,3-phase)			380-420V(3-phase)
In standby			
around 310VDC			around 530VDC
In operation			
With passive PFC module	With partial active PFC module	With fully active PFC module	/
>200VDC	>310VDC	>370VDC	>450VDC


Appendix 4:

°C	10	11	12	13	14	15	16	17	18	19	20	21	22
°F	48	50	52	54	56	58	60	62	64	66	68	70	72
°C	23	24	25	26	27	28	29	30	31	32	33	34	35
°F	74	76	78	80	82	84	86	88	90	92	94	96	98

3. Controller

3.1 Wireless Remote Controller

3.1.1 RG05F2/BGEU1




General Function for wireless remote controller:

Model	RG05F2/BGEU1
Rated voltage	3.0V(Dry batteries R03/LR03×2)
Min voltage for sending signal of CPU	2.4V
Effective receiving distance	8m
Operation condition	23°F~140°F(--5~60℃)

Buttons and functions

1. ON/OFF Button: Push this button to start the unit operation. Push the button again to stop the unit operation.

2. MODE: Once pressing, running mode will be selected in the following sequence:



NOTE: No heating mode for cool only type unit.

3. SLEEP Button: Active/Disable sleep function. It can maintain the most comfortable temperature and save energy. This function is available on COOL, HEAT or AUTO mode only .

NOTE: While the unit is running under SLEEP mode, it would be cancelled if MODE, FAN SPEED or ON/OFF button is pressed.

4. VERT SWING: Used to stop or start horizontal louver movement and set the desired up/down air flow direction. The louver changes 6 degree in angle for each press. If keep pushing more than 2 seconds, the louver will swing up and down automatically.


5. HORIZ SWING: Used to stop or start vertical louver movement and set the desired left/right air flow direction. The louver changes 6 degree in angle for each press. If keep pushing more than 2 seconds, the vertical louver swing feature is activated..

6. I FEEL /SELF CLEAN Function: Press this button less than 2 seconds will initiate I FEEL function. And if keep pressing this button more than 2 seconds, the SELF CLEAN function is initiated.

7. RESET Button: When the RESET button is pushed, all of the current settings are cancelled and the control will return to the initial settings.

8. LOCK Button: Push this button to lock in all the current settings. To release settings, push again.

9. FAN SPEED Button: Fan speed will be selected in following sequence once pressing this button:



10. UP Button: Push this button to increase setting temperature or to increase Hour during Clock time setting.

11. DOWN Button: Push this button to decrease setting temperature or to decrease Hour during Clock time setting.

NOTE: Press and hold UP and DOWN buttons together for 3 seconds will alternate the temperature display between the OC & OF scale.

12. TIME ON: Press this button to activate the Auto-on time setting. Each press will increase the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-on time setting, just press the button until the time setting is 0.0.

13. TIME OFF: Press this button to activate the Auto-off time setting. Each press will increase the time setting in 30 minutes increments, up to 10 hours, then at 1 hour increments up to 24 hours. To cancel the Auto-off time setting, just press the button until the time setting is 0.0.

14.TURBO: Active/Disable Turbo function. Turbo function enables the unit to reach the preset temperature in the shortest time. When press this button on heating mode(applicable to the unit adopts PTC only), the PTC will be energized and bring fast heating operation.


15.CLOCK Button: Used to set the remote clock.

16.LED Button: Disable/Active indoor screen Display.


3.2 Wired Remote Controller KJR-12B



Name and functions of buttons on the wire controller




1. Mode button: When press this button, the operation mode change as the following sequence:



Remark: For the cooling only model, the heating mode is skipped.


2. Timer on button: Press this button, timer on function is active. Then every press, the time increase 0.5h, after 10h, 1h increasement after each press. If cancel this Function, just set it to "0.0"
3. Timer off button: Press this button, timer off function is active. Then every press, the time increase 0.5h, after 10h, 1h increasement after each press. If cancel this function, just set it to "0.0" .
4. Follow me button: When under cool, heat and auto mode, press this button, follow me function is active. Press again, this function is ineffective.
5. Electrical heater button: If press this button in heat mode, electrical heater function become ineffective.
6. Reset button (hidden): Use a 1mm stick to press in the little hole , then the current setting is canceled . The wire controllers enter into original state.
7. ON/OFF button: When in off state, press this button, the indicator is on, the wire controller enter into on state, and send setting information to indoor PCB. When in on state, press this button, the indicator is off, and send instruction. If timer on or timer off has been set, it cancel this setting then send instruction to stop the machine.

8. Adjust button: Set indoor temperature up. If press and hold on, it will increase at 1degree per 0.5 second.
9. Adjust button: Set indoor temperature down. if press and hold on, it will decrease at 1degree per 0.5 Second.
10. Swing button: First press, start swing function; second press, stop swing. (Match to some model with swing function).
11. Economy operation button: press this button, the indoor unit operates in economy mode, press again, exit this mode (it may be ineffective for some models)
12. Fan speed button: press this button consecutively; the fan speed will circle as follow:



13. Lock button (hidden): When you push the LOCK button, all current settings are locked in and the wire controller does not accept any operation except that of the LOCK button. Use the lock mode when you want to prevent setting from being changed accidentally or play fully. Push the LOCK button again when you want to cancel the LOCK mode.

Name and function of LCD on the wire controller



1. Operation mode indication: When press" MODE" button, the following mode can be selected in circle.
Auto Cool Dry Heat Fan only Auto.
Auto→ Cool→ Dry →Heat→ Fan only →Auto
For cooling only model, heat mode is skipped.
2. Timer: When adjust setting on time or only on time is set, the "ON" is lighted. When adjust setting off time or only off time is set, the" OFF" is lighted. If on and off timer are both set, the "ON" and "OFF" are both lighted.
3. Follow me function: There is a temperature sensor inside the wire controller, after setting temperature, it will compare the two temperatures, and the space of wire controller will be the same as setting temperature. It is available under cooling, heating, auto mode.
4. ON/OFF indication: When it is on, the icon display, otherwise it is extinguished.
5. Fan speed indication: There are four fan modes: low, middle, high, auto. For some models, no middle fan then the middle fan is seen as high speed.
6. Lock: When the "LOCK" button is pressed, the icon appears and other buttons is unable, press again, the icon disappears.
7. Temperature display zone: Generally it displays setting temperature; it can be adjusted by press temperature button▲and▼ .But in fan mode, no display here.


Remark:

The wired controller will reset to factory setting with auto mode, auto fan and 24°C setting temperature when the air conditioner restarts after power failure.

And this may cause inconsistent displays on the wired controller and on the air conditioner. You need to readjust the running status through the wired controller.


Installation

Wiring Principle Sketch:



Installation Notice:

When the air conditioner needs the constant frequency wire Controller, be sure adding a Wire Joint with 5 terminal named A, B, C, D, E in indoor unit, and fixing a infrared emitter whose anode and cathode connecting with A and B near the receiver in the Indoor Unit Switch Board, then connecting the terminal +5v, GND, Run in the Switch Board to C,D,E respectively.



NOTE

- The connecting wire should be a little longer as to take away the switch board easily for maintenance.
- The connecting wire should be a little longer as to take away the controller easily for maintenance.