



## MULTI OUTDOOR UNITS

### SERVICE MANUAL

*Multi zone*

## CONDENSING UNITS

Revision B: ODMI-C1-1403



### Model Numbers:

**M2OC-18HFN1-M**

**M3OC-30HRFN1-M**

**M2OD-18HFN1-M**

**M4OC-36HRFN1-M**

**M3OD-27HRDN1-M**

### Table of Contents

1. Product Specifications
2. Indoor Unit Combination
3. Suggested Indoor Unit Model Numbers
4. Dimension Of Outdoor Unit
5. Refrigerant Cycle Diagram
6. Installation Details
7. Electronic Function
8. Wiring Diagrams And Electrical Trouble Shooting
9. Disassembly Instructions
10. Exploded View



### WARNING

- Installation MUST conform with local building codes or, in the absence of local codes, with the National Electrical Code NFPA70/ANSI C1-1993 or current edition and Canadian Electrical Code Part1 CSA C.22.1.
- The information contained in the manual is intended for use by a qualified service technician familiar with safety procedures and equipped with the proper tools and test instruments
- Installation or repairs made by unqualified persons can result in hazards to you and others.
- Failure to carefully read and follow all instructions in this manual can result in equipment malfunction, property damage, personal injury and/or death.



# CONTENTS

1. Indoor Unit Combination .....	4
2. Suggested Indoor Unit Model Numbers .....	6
3. Dimension Of Outdoor Unit .....	7
4. Refrigerant Cycle Diagram .....	8
5. Installation Details .....	9
6.1 Wrench torque sheet for installation .....	9
6.2 Connecting the cables .....	9
6.3 Pipe length and the elevation.....	9
6.4 Installation for the first time .....	9
6.5 Adding the refrigerant after running the system for many years .....	11
6.6 Re-installation while the indoor unit need to be repaired.....	11
6.7 Re-installation while the outdoor unit need to be repaired .....	12
6. Electronic Function .....	13
7.1 Abbreviation .....	13
7.2 Electric control working environment.....	13
7.3 Main Protection.....	13
7.4 Control and Functions .....	15
7. Wiring Diagrams.....	19
8. Troubleshooting.....	32
9.1 Safety .....	32
8.2 Indoor Unit Error Display.....	33
9.3 Outdoor Unit Display .....	36
9.4 Diagnosis and Solution .....	40
9.5 Trouble Criterion Of Main Parts. ....	89
9. Disassembly Instructions .....	100
➤ <b>Model: M2OC-18HFN1-M, M2OD-18HFN1-M (W210 metal plate)</b> .....	100

➤ <b>Model: M3OD-27HRDN1-M (W210 metal plate)</b> .....	106
➤ <b>Model: M3OC-30HRFN1-M (W310 metal plate)</b> .....	113
➤ <b>Model: M4OC-36HRFN1-M (W520 metal plate)</b> .....	121

# 1. Indoor Unit Combination

Multi DC Outdoor Unit	Nominal capacity	Suggested Combination	Limit
1drive 2(M2OC)	5.2kW	7	None
		9	
		12	
		7+9	
		7+12	
		9+9	
		9+12	

Multi DC Outdoor Unit	Nominal capacity	Suggested Combination	Limit
1drive 2(M2OD)	5.2kW	7	None
		9	
		12	
		7+9	
		7+12	
		9+9	
		9+12	
		12+12	

Multi DC Outdoor Unit	Nominal capacity	Suggested Combination	Limit
1 drive 3(27K)	7.5kW	7	The 18k indoor unit should not be Floor Ceiling or Duct unit; There should be only one Floor Ceiling, Oasis or Duct unit;
		9	
		12	
		18	
		7+7	
		7+9	
		7+12	
		7+18	
		9+9	
		9+12	
		9+18	
		12+12	
		12+18	
		7+7+7	
		7+7+9	

		7+9+12	
		7+9+18	
		7+12+12	
		9+9+9	
		9+9+12	

Multi DC Outdoor Unit	Nominal capacity	Suggested Combination	Limit
1 drive 3(30K)	8.0kW	7	There should be only one Floor Ceiling or Duct unit;
		9	
		12	
		18	
		7+7	
		7+9	
		7+12	
		7+18	
		9+9	
		9+12	
		9+18	
		12+12	
		12+18	
		18+18	
		7+7+7	
		7+7+9	
		7+7+12	
		7+7+18	
		7+9+9	
		7+9+12	
7+9+18			
7+12+12			
7+12+18			
9+9+9			
9+9+12			
9+9+18			
9+12+12			
9+12+18			
12+12+12			

Multi DC Outdoor Unit	Nominal capacity	Suggested Combination	Limit
1 drive 4(36K)	10.5kW	7	None
		9	
		12	
		18	

		7+7	
		7+9	
		7+12	
		7+18	
		9+9	
		9+12	
		9+18	
		12+12	
		12+18	
		18+18	
		7+7+7	
		7+7+9	
		7+7+12	
		7+7+18	
		7+9+9	
		7+9+12	
		7+9+18	
		7+12+12	
		7+12+18	
		9+9+9	
		9+9+12	
		9+9+18	
		9+12+12	
		9+12+18	
		9+18+18	
		12+12+12	
		12+12+18	
		12+18+18	
		7+7+7+7	
		7+7+7+9	
		7+7+7+12	
		7+7+7+18	
		7+7+9+9	
		7+7+9+12	
		7+7+9+18	
		7+9+9+9	
		7+9+9+12	
		7+9+9+18	
		7+9+12+12	
		7+9+12+18	
		7+12+12+12	
		7+12+12+18	
		9+9+9+9	
		9+9+9+12	
		9+9+9+18	
		9+9+12+12	

		9+9+12+18	
		9+12+12+12	
		9+12+12+18	
		12+12+12+12	

### 3. Suggested Indoor Unit Model Numbers

		SUGGESTED INDOOR
M20C-18HRFN1-M	7K	MS9AI-07HRDN1-M
	9K	MS9AI-09HRDN1-M(A)
		MSV1I-09HRDN1-M
	12K	MSV1I-12HRDN1-M
		MS9AI-12HRDN1-M
		MTBI-12HWDN1-M
		MTBU-12HRDN1-M
		MFAI-12HRDN1-M
		MFAU-12HRFN1-M
		MCA2I-12HRDN1-M
		MCA2U-12HRFN1-M
		MUBI-12HRDN1-M
		MUBU-12HRFN1-M



		SUGGESTED INDOOR
M20D-18HRFN1-M	7K	MS9AI-07HRDN1-M
	9K	MS9AI-09HRDN1-M(A)
		MSV1I-09HRDN1-M
		MS11M-09HRFN1-MX4W
		MS11M-09HRFN1-MX4W
	12K	MSV1I-12HRDN1-M
		MS9AI-12HRDN1-M
		MS11M-12HRFN1-MV0W
		MTBI-12HWDN1-M
		MTBU-12HRDN1-M
		MFAI-12HRDN1-M
		MFAU-12HRFN1-M
		MCA2I-12HRDN1-M
		MCA2U-12HRFN1-M
		MUBI-12HRDN1-M
		MUBU-12HRFN1-M
		MS11M-12HRFN1-MW0W
		MS11M-12HRFN1-MV0W

		SUGGESTED INDOOR
M30D-27HRDN1-M	7K	MS9AI-07HRDN1-M
	9K	MS9AI-09HRDN1-M(A)
		MSV1I-09HRDN1-M
	12K	MSV1I-12HRDN1-M
		MS9AI-12HRDN1-M
		MTBI-12HWDN1-M
		MTBU-12HRDN1-M
		MFAI-12HRDN1-M
		MFAU-12HRFN1-M
		MCA2I-12HRDN1-M
		MCA2U-12HRFN1-M
		MUBI-12HRDN1-M
		MUBU-12HRFN1-M
		18K
	MS9AI-18HRDN1-M	
	MCA2I-18HRDN1-M	
	MCA2U-18HRFN1-M	

		SUGGESTED INDOOR
M30C-30HRFN1-M	7K	MS9AI-07HRDN1-M
	9K	MS9AI-09HRDN1-M(A)
		MSV1I-09HRDN1-M
		MS11M-09HRFN1-MX4W
		MS11M-09HRFN1-MW0W
	12K	MSV1I-12HRDN1-M
		MS9AI-12HRDN1-M
		MS11M-12HRFN1-MV0W
		MS11M-12HRFN1-MW0W
		MTBI-12HWDN1-M
		MTBU-12HRDN1-M
		MFAI-12HRDN1-M
		MFAU-12HRFN1-M
		MCA2I-12HRDN1-M
		MCA2U-12HRFN1-M
		MUBI-12HRDN1-M
		MUBU-12HRFN1-M
		MSV1I-18HRDN1-M
		MS9AI-18HRDN1-M
		MS11M-18HRFN1-MU0W
		MTBI-18HWDN1-M
	MTBU-18HRDN1-M	
	MCA2I-18HRDN1-M	
	MCA2U-18HRFN1-M	
	MUBI-18HRDN1-M	
	MUBU-18HRFN1-M	

		SUGGESTED INDOOR
M40C-36HRFN1-M	7K	MS9AI-07HRDN1-M
	9K	MS9AI-09HRDN1-M(A)
		MSV1I-09HRDN1-M
		MS11M-09HRFN1-MX4W
		MS11M-09HRFN1-MW0W
	12K	MSV1I-12HRDN1-M
		MS9AI-12HRDN1-M
		MS11M-12HRFN1-MV0W
		MS11M-12HRFN1-MW0W
		MTBI-12HWDN1-M
		MTBU-12HRDN1-M
		MFAI-12HRDN1-M
		MFAU-12HRFN1-M
		MCA2I-12HRDN1-M
		MCA2U-12HRFN1-M
		MUBI-12HRDN1-M
		MUBU-12HRFN1-M
	18K	MSV1I-18HRDN1-M
		MS9AI-18HRDN1-M
		MS11M-18HRFN1-MU0W
		MTBI-18HWDN1-M
		MTBU-18HRDN1-M
		MCA2I-18HRDN1-M
		MCA2U-18HRFN1-M
		MUBI-18HRDN1-M
		MUBU-18HRFN1-M


## 4. Dimension Of Outdoor Unit




Model	Dimension (mm(in.))					
	W	D	H	W1	A	B
M2OC-18HFN1-M	845(33.3)	320(12.6)	700(27.6)	908(35.7)	560(22)	335(13.2)
M2OD-18HFN1-M						
M3OD-27HRDN1-M						
M3OC-30HRFN1-M	900(35.4)	315(12.4)	860(33.9)	980(38.6)	590(23.2)	333(13.1)
M4OC-36HRFN1-M	990(39)	345(13.6)	965(38)	1075(42.3)	624(24.6)	366(14.4)

# 5. Refrigerant Cycle Diagram


## 5.1 Refrigeration circuit drawing of inverter dual zone



## 5.2 Refrigeration circuit drawing of inverter tri-zone



## 5.3 Refrigeration circuit drawing of inverter qua-zone





## 6. Installation Details

### 6.1 Wrench torque sheet for installation

Outside diameter		Torque	Additional tightening torque
mm	inch	N.cm	N.cm
Φ6.35	1/4	1500(153kgf.cm)	1600(163kgf.cm)
Φ9.52	3/8	2500(255kgf.cm)	2600(265kgf.cm)
Φ12.7	1/2	3500(357kgf.cm)	3600(367kgf.cm)

### 6.2 Connecting the cables

The power cord connection should be selected according to the following specifications sheet.

Unit	AWG
Dual-zone(18K outdoor unit)	14
Tri-zone (27K/30K outdoor unit).	14
Quad-zone(36K outdoor unit)	12

For indoor unit and outdoor unit connection line, 16AWG is ok for all.

### 6.3 Pipe length and the elevation

#### Maximum piping length and height difference

	1 drive 2	1 drive 3	1 drive 4	
Max. length for all rooms (m)	30(98ft)	45(150ft)	60(200ft)	
Max. length for one IU (m)	20(65.6ft)	25(82ft)	30(98ft)	
Max. height difference between IU and OU (m)	OU higher than IU	10(33ft)	10(33ft)	10(33ft)
	OU lower than IU	15(49.2ft)	15(49.2ft)	15(49.2ft)
Max. height difference between IUs (m)	10(33ft)	10(33ft)	10(33ft)	

#### Additional refrigerant charge

	1 drive 2	1 drive 3	1 drive 4	
Chargeless pipe length (m)	15(49.2ft)	22.5(73.8ft)	30(98.4ft)	
Additional refrigerant charge	g	15 x (length for all rooms - 15)	15 x (length for all rooms - 22.5)	15 x (length for all rooms - 30)
	oz	(.0.161 x(length for all rooms - 49.2))	(.0.161 x(length for all rooms - 73.8))	(.0.161x(length for all rooms - 98.4))

Caution:

- Refrigerant pipe diameter is different according to indoor unit to be connected.

When using the extension pipe, refer to the tables below.

- When refrigerant pipe diameter is different from that of outdoor unit union (for 18K indoor unit), additional transfer connector needs to be used on outdoor unit union.

Indoor unit		Extension pipe diameter (mm/inch)	
Model	Pipe diameter (mm/inch)		
9K	Liquid	6.35(1/4)	Liquid 6.35(1/4)
	Gas	9.52(3/8)	Gas 9.52(3/8)
12K 18K	Liquid	6.35(1/4)	Liquid 6.35(1/4)
	Gas	12.7(1/2)	Gas 12.7(1/2)
Outdoor unit union diameter (mm/inch)			
Indoor unit A/B/C/D		Liquid	6.35(1/4)
		Gas	9.52(3/8)

### 6.4 Installation for the first time

Air and moisture in the refrigerant system have undesirable effects as below:



- Pressure in the system rises.
- Operating current rises.
- Cooling or heating efficiency drops.
- Moisture in the refrigerant circuit may freeze and block capillary tubing.
- Water may lead to corrosion of parts in the refrigerant system.

Therefore, the indoor units and the pipes between indoor and outdoor units must be leak tested and evacuated to remove gas and moisture from the system.

Gas leak check (Soap water method):

Apply soap water or a liquid neutral detergent on the indoor unit connections or outdoor unit connections by a soft brush to check for leakage of the connecting points of the piping. If bubbles come out, the pipes have leakage.

#### 1. Air purging with vacuum pump



1. Completely tighten the flare nuts of the indoor and outdoor units, confirm that both the 2-way and 3-way valves are set to the closed position.
2. Connect the charge hose with the push pin of handle lo to the 3-way valves gas service port..
3. Connect the charge hose of handle hi connection to the vacuum pump.
4. Fully open the handle Lo of the manifold valve.
5. Operate the vacuum pump to evacuate.
6. Make evacuation for 30 minutes and check whether the compound meter indicates -0.1Mpa(14.5Psi). If the meter does not indicate -0.1Mpa(14.5Psi) after pumping 30 minutes, it should be pumped 20 minutes more. If the pressure can't achieve -0.1Mpa(14.5Psi) after pumping 50 minutes, please check if there are some leakage points. Fully close the handle Lo valve of the manifold valve and stop the operation of the vacuum pump. Confirm that the gauge needle does not move (approximately 5 minutes after turning off the vacuum pump).
7. Turn the flare nut of the 3-way valves about 45° counterclockwise for 6 or 7seconds after the gas coming out, then tighten the flare nut again. Make sure the pressure display in the pressure indicator is a little higher than the atmosphere pressure. Then remove the charge hose from the 3 way valve.
8. Fully open the 2 way valve and 3 way valve and securely tighten the cap of the 3 way valve.

## 2. Air purging by refrigerant

### Procedure:

- 1). Confirm that both the 2-way and 3-way valves are set to the closed position.
- 2). Connect the charge set and a charging cylinder to the service port of the 3-way valve.
- 3). Air purging.

Open the valves on the charging cylinder and the charge set. Purge the air by loosening the flare nut on the 2-way valve approximately 45' for 3 seconds then closing it for 1 minute; repeat 3 times.


After purging the air, use a torque wrench to tighten the flare nut on the 2-way valve.

- 4). Check the gas leakage.  
Check the flare connections for gas leakage.
- 5). Discharge the refrigerant.

Close the valve on the charging cylinder and discharge the refrigerant by loosening the flare nut on the 2-way valve approximately 45' until the gauge indicates 0.3Mpa(43.5Psi) to 0.5 Mpa(72.5Psi)..

- 6). Disconnect the charge set and the charging cylinder, and set the 2-way and 3-way valves to the open position.  
Be sure to use a hexagonal wrench to operate the valve stems.
- 7). Mount the valve stems nuts and the service port cap.  
Be sure to use a torque wrench to tighten the service port cap to a torque 18N·m.  
Be sure to check the gas leakage.


### 3. Adding refrigerant if the pipe length exceeds chargeless pipe length



### Procedure:

- 1). Connect the charge hose to the charging cylinder, open the 2-way valve and the 3-way valve.  
Connect the charge hose which you disconnected from the vacuum pump to the valve at the bottom of the cylinder. If the refrigerant is R410A, make the cylinder bottom up to ensure the liquid charge.
- 2). Purge the air from the charge hose.  
Open the valve at the bottom of the cylinder and press the check valve on the charge set to purge the air (be careful of the liquid refrigerant).
- 3) Put the charging cylinder onto the electronic scale and record the weight.
- 4) Operate the air conditioner at the cooling mode.
- 5) Open the valves (Low side) on the charge set and charge the system with liquid refrigerant.
- 6).When the electronic scale displays the proper weight (refer to the table), disconnect the charge hose from the 3-way valve's service port immediately and turn off the air conditioner
- 7). Mount the valve stems nuts and the service port cap.  
Be sure to use a torque wrench to tighten the service port cap to a torque 18N·m.  
Be sure to check the gas leakage.

## 6.5 Adding the refrigerant after running the system for many years




### Procedure

- 1). Connect the charge hose to the 3-way service port, open the 2-way valve and the 3-way valve.  
Connect the charge hose to the valve at the bottom of the cylinder. If the refrigerant is R410A, make the cylinder bottom up to ensure liquid charge.
- 2). Purge the air from the charge hose.  
Open the valve at the bottom of the cylinder and press the check valve on the charge set to purge the air (be careful of the liquid refrigerant).
- 3) Put the charging cylinder onto the electronic scale and record the weight.
- 4) Operate the air conditioner at the cooling mode.
- 5) Open the valves (Low side) on the charge set and charge the system with liquid refrigerant.
- 6).When the electronic scale displays the proper weight (refer to the gauge and the pressure of the low side), disconnect the charge hose from the 3-way valve's service port immediately and turn off the air conditioner before disconnecting the hose.
- 7). Mount the valve stem caps and the service port cap  
Use torque wrench to tighten the service port cap to a torque of 18N.m.

Be sure to check for gas leakage.


## 6.6 Re-installation while the indoor unit need to be repaired

### 1. Collecting the refrigerant into the outdoor unit



## Procedure

- 1). Confirm that both the 2-way and 3-way valves are set to the opened position  
Remove the valve stem caps and confirm that the valve stems are in the opened position.  
Be sure to use a hexagonal wrench to operate the valve stems.
- 2). Connect the charge hose with the push pin of handle lo to the 3-way valves gas service port.
- 3). Air purging of the charge hose.  
Open the handle Lo valve of the manifold valve slightly to purge air from the charge hose for 5 seconds and then close it quickly.
- 4). Set the 2-way valve to the close position.
- 5). Operate the air conditioner at the cooling cycle and stop it when the gauge indicates 0.1Mpa(14.5Psi)..
- 6). Set the 3-way valve to the closed position immediately  
Do this quickly so that the gauge ends up indicating 0.3Mpa(43.5Psi) to 0.5 Mpa(72.5Psi)..  
Disconnect the charge set, and tighten the 2-way and 3-way valve's stem nuts.  
Use a torque wrench to tighten the 3-way valves service port cap to a torque of 18N.m.  
Be sure to check for gas leakage.



## Procedure:

- 1). Confirm that both the 2-way and 3-way valves are set to the closed position.
- 2). Connect the charge set and a charging cylinder

to the service port of the 3-way valve  
Leave the valve on the charging cylinder closed.

3). Air purging.  
Open the valves on the charging cylinder and the charge set. Purge the air by loosening the flare nut on the 2-way valve approximately 45' for 3 seconds then closing it for 1 minute; repeat 3 times.

After purging the air, use a torque wrench to tighten the flare nut on the 2-way valve.

4). Check the gas leakage

Check the flare connections for gas leakage.

5). Discharge the refrigerant.

Close the valve on the charging cylinder and discharge the refrigerant by loosening the flare nut on the 2-way valve approximately 45' until the gauge indicates 0.3Mpa(43.5Psi) to 0.5 Mpa(72.5Psi)..

6). Disconnect the charge set and the charging cylinder, and set the 2-way and 3-way valves to the open position

Be sure to use a hexagonal wrench to operate the valve stems.


7). Mount the valve stems nuts and the service port cap

Be sure to use a torque wrench to tighten the service port cap to a torque 18N.m.

Be sure to check the gas leakage.

## 6.7 Re-installation while the outdoor unit need to be repaired

### 1. Evacuation for the whole system




## Procedure:

- 1). Confirm that both the 2-way and 3-way valves are set to the opened position.
- 2). Connect the vacuum pump to 3-way valve's service port.
- 3). Evacuation for approximately one hour. Confirm that the compound meter indicates -0.1Mpa (14.5Psi).
- 4). Close the valve (Low side) on the charge set,

turn off the vacuum pump, and confirm that the gauge needle does not move (approximately 5 minutes after turning off the vacuum pump).

- 5). Disconnect the charge hose from the vacuum pump.

## 2. Refrigerant charging



### Procedure:

- 1). Connect the charge hose to the charging cylinder, open the 2-way valve and the 3-way valve  
Connect the charge hose which you disconnected from the vacuum pump to the valve at the bottom of the cylinder. If the refrigerant is R410A, make the cylinder bottom up to ensure liquid charge.
- 2). Purge the air from the charge hose  
Open the valve at the bottom of the cylinder and press the check valve on the charge set to purge the air (be careful of the liquid refrigerant).
- 3) Put the charging cylinder onto the electronic scale and record the weight.
- 4). Open the valves (Low side) on the charge set and charge the system with liquid refrigerant  
If the system cannot be charge with the specified amount of refrigerant, or can be charged with a little at a time (approximately 150g each time) , operating the air conditioner in the cooling cycle; however, one time is not sufficient, wait approximately 1 minute and then repeat the procedure.
- 5).When the electronic scale displays the proper weight, disconnect the charge hose from the 3-way valve's service port immediately  
If the system has been charged with liquid refrigerant while operating the air conditioner, turn off the air conditioner before disconnecting the hose.
- 6). Mounted the valve stem caps and the service port. Use torque wrench to tighten the service port cap to a torque of 18N.m. Be sure to check for gas leakage.

## 7. Electronic Function

### 7.1 Abbreviation

T1: Indoor ambient temperature

T2: Coil temperature of indoor heat exchanger middle.

T2B: Coil temperature of indoor heat exchanger outlet.

T3: Pipe temperature of outdoor heat exchanger

T4: Outdoor ambient temperature

Tp: Compressor discharge temperature

### 7.2 Electric control working environment.

7.2.1 Input voltage: 230V.

7.2.2 Input power frequency:60Hz.

7.2.3 Indoor fan normal working amp. is less than 1A.

7.2.4 Outdoor fan. Normal working amp. is less than 1.5A.

7.2.5 Four-way valve normal working amp. is less than 1A.

### 7.3 Main Protection

#### 7.3.1 Three Minutes Delay at restart for compressor.

---- 1min delay for the 1<sup>st</sup> time start-up and 3 minutes delay for others.

#### 7.3.2 Temperature protection of compressor discharge.

When the compressor discharge temp. is getting higher, the running frequency will be limited as below rules:

----If  $102^{\circ}\text{C} < T_p < 115^{\circ}\text{C}$ , decrease the frequency to the lower level every 2 minutes till to F1.

---If  $T_p > 115^{\circ}\text{C}$  for 10 seconds, the compressor will stop and restart till  $T_p < 90^{\circ}\text{C}$ .


#### 7.3.3 Fan Speed is out of control(DC fan motor).

---- When outdoor fan speed is lower than 300RPM or higher than 2400RPM for 60 second, the whole unit stops and LED displays failure.

### 7.3.4 Inverter module Protection.

----Inverter module protection itself has a protection function against current, voltage and temperature. If these protections happened, the corresponding code will display on indoor unit LED and A/C will stop. The unit will recover 3min delay after the protection disappeared.

### 7.3.5 Low voltage protection



Note: if the low voltage protection occurs and not resumes within 3min, it will keep the protection always after restart the machine.

### 7.3.6 Compressor current limit protection

If the compressor current exceeds the current limit value for 10 seconds, the compressor frequency will be limited as below table.

#### Cooling mode:

Current frequency(Hz)	Current limit value(A)	Frequency limit
COOL_F16	ICOOLLMT12	Decrease the frequency to COOL_F4 and run at COOL_F4 for 3 minutes.
COOL_F15	ICOOLLMT11	
COOL_F14	ICOOLLMT10	After that, the frequency will be adjusted according to the capacity demand and rise to the upper level every 3 minutes (When the frequency>COOL_F4 via capacity demand).
COOL_F13	ICOOLLMT9	
COOL_F12	ICOOLLMT8	
COOL_F11	ICOOLLMT7	
COOL_F10	ICOOLLMT6	
COOL_F9	ICOOLLMT5	
COOL_F8	ICOOLLMT4	
COOL_F7	ICOOLLMT3	
COOL_F6	ICOOLLMT2	

COOL_F5	ICOOLLMT1	
If the current frequency is lower than COOL_F4, the frequency will not be limited. After 10s of the compressor start, if the current>ICOOL, the AC will display the failure for 30 seconds and stop. The AC will restart 3 minutes later.		

#### Heating mode:

Current frequency(Hz)	Current limit value(A)	Frequency limit
HEAT_F16	IHEATLMT12	Decrease the frequency to HEAT_F4 and run at HEAT_F4 for 3 minutes.
HEAT_F15	IHEATLMT11	
HEAT_F14	IHEATLMT10	After that, the frequency will be adjusted according to the capacity demand and rise to the upper level every 3 minutes (When the frequency>Heat_F4 via capacity demand).
HEAT_F13	IHEATLMT9	
HEAT_F12	IHEATLMT8	
HEAT_F11	IHEATLMT7	
HEAT_F10	IHEATLMT6	
HEAT_F9	IHEATLMT5	
HEAT_F8	IHEATLMT4	
HEAT_F7	IHEATLMT3	
HEAT_F6	IHEATLMT2	
HEAT_F5	IHEATLMT1	

If the current frequency is lower than HEAT\_F4, the frequency will not be limited.  
After 10s of the compressor start, if the current>IHEAT, the AC will display the failure for 30 seconds and stop. The AC will restart 3 minutes later.

### 7.3.7 Indoor / outdoor units communication protection

If the indoor units cannot receive the feedback signal from the outdoor units for 2 minutes, the AC will stop and display the failure.

### 7.3.8 High condenser coil temp. protection.

When T3>65°C for 3 seconds, the compressor will stop while the indoor fan and outdoor fan will continue.

When T3<52°C, the protection will release and the compressor will restart after 3 minutes.

### 7.3.9 Outdoor unit anti-freezing protection


When T2B<0°C for 250 seconds, the indoor unit capacity demand will be zero and resume to normal when T2B>10°C.

### 7.3.10 Oil return

Running rules:

1.If the compressor frequency keeps lower than RET\_OIL\_FREQ1\_ADD for RET\_OIL\_TIME1\_ADD,the AC will rise the frequency to RET\_OIL\_FREQ2\_ADD for RET\_OIL\_TIME2\_ADD and then resume to former frequency.

2.During the oil return process, the EXV will keep 300p while the indoor units will keep the current running mode.



### 7.3.11 Compressor preheating functions

----Preheating permitting condition:

If  $T_4$ (outdoor ambient temperature) $<3^{\circ}\text{C}$  and newly powered on or if  $T_4<3^{\circ}\text{C}$  and compressor has stopped for over 3 hours, the compressor heating cable will work.

----Preheating mode:

A weak current flow through the coil of compressor from the wiring terminal of compressor, then the compressor is heated without operation.

----Preheating release condition:

If  $T_4>5^{\circ}\text{C}$  or the capacity demand isn't zero, preheating function will stop.

### 7.3.12 Compressor crankcase heater

----Preheating permitting condition:

- ① When  $T_4<3^{\circ}\text{C}$  within 5 seconds of being plugged in, the crankcase heater will be active.
- ② When  $T_4<3^{\circ}\text{C}$  and the compressor is not running for 3 hours, the crankcase heater will be active.

----Preheating release condition:

When  $T_4\geq 5^{\circ}\text{C}$  or the indoor has capacity demand, the crankcase heater will stop work.

## 7.4 Control and Functions

### 7.4.1 Capacity Request Calculation

Total capacity Request= $\sum(\text{Norm code} \times \text{HP}) / 10 \times \text{modify rate} + \text{correction}$

**Cooling mode:**

Capacity area	a	b	c	d	e	f
Norm code (N)	3	2	1.5	1	0.5	0

Model	9K	12K	18K
HP	1.0	1.2	1.5

**Note: The final result is integer.**

Plus all the indoor capacity request together, then modify it by  $T_4$

When there's only one indoor unit

Cooling	Outdoor temperature ( $T_4$ )		
	$>29^{\circ}\text{C}$	$18^{\circ}\text{C} \sim 29^{\circ}\text{C}$	$<17^{\circ}\text{C}$
Modify rate	100%	60%	40%

When there're more than one indoor unit

Cooling	Outdoor temperature ( $T_4$ )		
	$>25^{\circ}\text{C}$	$17^{\circ}\text{C} \sim 25^{\circ}\text{C}$	$<17^{\circ}\text{C}$
Modify rate	100%	80%	40%


**Note: The final result is integer.**

In low ambient cooling mode, modify rate is fixed as 40%.


**According to the final capacity request to confirm the operating frequency, as following table.**

Frequency (Hz)	0	COO L_F1	COO L_F2	...	COOL _F15	COO L_F1 6
Amendatory capacity demand.	0	1	2	...	15	16

Meanwhile the maximum running frequency will be adjusted according to the outdoor ambient temp.



### Heating mode



Capacity area	a	b	c	d	e	f
Norm code (N)	3	2	1.5	1	0.5	0

Model	9K	12K	18K
HP	1.0	1.2	1.5

Plus all the indoor capacity request together, then modify it by T4

When there's only one indoor unit

Heating	Outdoor temperature (T4)			
	<0°C	<12°C	12°C ~ 17°C	≥17°C
Modify rate	120%	80%	40%	20%


When there're more than one indoor unit

Heating	Outdoor temperature (T4)			
	<0°C	<12°C	12°C ~ 17°C	≥17°C
Modify rate	120%	100%	80%	60%

**Note: The final result is integer.**

**Then modify it according to T2 average(correction):**

Note: Average value of T2: Sum T2 value of all indoor units)/(indoor units number



**According to the final capacity request to confirm the operating frequency, as following table.**

Frequency (Hz)	0	HEAT_F1	HEAT_F2	...	HEAT_F15	HEAT_F16
Amendatory capacity demand.	0	1	2	...	15	16

### Heating capacity improved in low ambient heating

In heating mode, when  $T2 < T2\_ExitT4LowFre\_ADD$ , and  $T4 < -4$  °C, there's frequency elevation:

$$\text{elevated frequency} = \text{Recent frequency} * 110\%$$

When  $T2 > T2\_ExitT4LowFre\_ADD - 2$  and  $T4 > -6$ , the highest frequency can't exceed F17

When  $T2 > T2\_ExitT4LowFre\_ADD - 4$  and  $T4 > -8$ , the highest frequency can't exceed F18

When  $T2 > T2\_ExitT4LowFre\_ADD - 6$  and  $T4 > -10$ , the highest frequency can't exceed F19




In the other conditions, the highest frequency is F20

## 7.4.2 Defrosting control

### Condition of defrosting:

$T3 \leq \text{TempEnterDefrost\_ADD } ^\circ\text{C}$  and lasts for 40 minutes.

### Defrosting action:



### Condition of ending defrosting:


If any one of following items is satisfied, defrosting will stop and the machine will turn to normal heating mode.

- ①  $T3 > \text{TempQuitDefrost\_ADD } ^\circ\text{C}$ ;
- ② The defrosting time achieves 10min.
- ③ Turn to other modes or off.


## 7.4.3 Outdoor fan control

### 7.4.3.1 Cooling mode


For M3OD-27HRDN1-M:



When low ambient cooling is valid:




For M2OC-18HFN1-M, M2OD-18HFN1-M, M3OC-30HFN1-M, M4OC-36HFN1-M:



Outdoor fan speed control logical (low ambient cooling)


When  $T4 < 15 ^\circ\text{C}$  and  $T3 < 30 ^\circ\text{C}$ , the unit will enter into low ambient cooling mode. The outdoor fan will choose speed according to  $T3$ .

When  $T3 \geq 38 ^\circ\text{C}$  or when  $T4 \geq 20 ^\circ\text{C}$ , the outdoor fan will choose the speed according to  $T4$  again.




### 7.4.3.2 Heating mode

For M3OD-27HRDN1-M:



For M2OC-18HFN1-M, M2OD-18HFN1-M, M3OC-30HFN1-M, M4OC-36HFN1-M:



### 7.4.4 Electronic Expansion Valve (EXV) Control

1. EXV will be fully closed when turning on the power. Then EXV will be standby with 350P open and will open to target angle after compressor starts.

2. EXV will close with -160P when compressor stops. Then EXV will be standby with 350P open

and will open to target angle after compressor starts.

3. The action priority of the EXVs is A-B-C-D.

4. Compressor and outdoor fan start operation only after EXV is initialized.

#### 7.4.4.1 Cooling mode

The initial open angle of EXV is 250P, adjustment range is 100-350p. When the unit start to work for 3 minutes, the outdoor will receive indoor units( of capacity demand) T2B information and calculate the average of them. After comparing each indoor's T2B with the average, the outdoor gives the following modification commands:

If the  $T2B > \text{average}$ , the relevant valve needs more 16p open;

If the  $T2B = \text{average}$ , the relevant valve's open range remains;

If the  $T2B < \text{average}$ , the relevant valve needs more 16p close.

This modification will be carried out every 2 minutes.

#### 7.4.4.2 Heating mode

The initial open angle of EXV is 250P, adjustment range is 100-350p.. When the unit start to work for 3minutes, the outdoor will receive indoor units( of capacity demand) T2 information and calculate the average of them. After comparing each indoor's T2 with the average, the outdoor gives the following modification commands:

If the  $T2 > \text{average} + 2$ , the relevant valve needs more 16p close;

If  $\text{average} + 2 \geq T2 \geq \text{average} - 2$ , the relevant valve's open range remains;

If the  $T2 < \text{average} - 2$ , the relevant valve needs more 16p open.

This modification will be carry out every 2 minutes.


#### 7.4.5 Four-way valve control

In heating mode, four-way valve is opened. In defrosting, four-way valve operates in according to defrosting action. In other modes, four-way valve is closed. When the heating mode to other modes, the four-way valve is off after compressor is off for 2 minutes. Failure or protection (not including discharge temperature protection, high and low pressure protection), four-way valve immediately shuts down.


# 8. Wiring Diagrams

## 8.1 Wiring diagram of 1 drive 2 outdoor M2OC-18HFN1-M, M2OD-18HFN1-M


202057090167



# PCB board of M2OC-18HFN1-M, M2OD-18HFN1-M




# IPM board of M2OC-18HFN1-M



**IPM board of M2OD-18HFN1-M**


## 8.2 Wiring diagram of 1 drive 3 outdoor

M3OD-27HRDN1-M




M3OC-30HRFN1-M

202057190197




# PCB board of M3OC-30HRFN1-M







# IPM board of M3OC-30HRFN1-M



# PCB board of M30D-27HRDN1-M




# IPM board of M3OD-27HRD1-M




### 8.3 Wiring diagram of 1 drive 4 outdoor M4OC-36HRFN1-M


202057190185




# PCB board of M4OC-36HRFN1-M



# IPM board of M4OC-36HRFN1-M



# PFC board of M4OC-36HRFN1-M




## 9. Troubleshooting

### 9.1 Safety

Because of there are capacitors in PCB and relative circuit in outdoor unit, even shut down the power supply, electricity power still are kept in capacitors, do not forget to discharge the electricity power in capacitor.

The value of resistance is about 1500 ohm to 2000 ohm



Electrolytic Capacitors

(HIGH VOLTAGE! CAUTION!)

Bulb (25-40W)

The voltage in P3 and P4 in outdoor PCB is high voltage about 310V

The voltage in P5 and P6 in outdoor PCB is high voltage about 310V



## 9.2 Indoor Unit Error Display

### Vertu series & Luna series:

Display	Failure	ODU Error code
E0	Indoor EEPROM malfunction	---
E1	Communication malfunction between indoor and outdoor units	E2
E2	Zero-crossing signal error	---
E3	Indoor fan speed has been out of control	---
E5	Open circuit or short circuit of outdoor temperature sensor or outdoor EEPROM malfunction	E0,E4
E6	Open circuit or short circuit of T1 or T2 temperature sensor	---
P0	IPM module protection or IGBT over-strong current protection	P6
P1	Voltage protection	E5
P2	Temperature protection of compressor top	P0
P3	Outdoor temperature is lower than -15°C (optional function)	---
P4	Inverter compressor drive protection	---
P5	Mode conflict	---

### Console series

Operation	Timer	De-frost	Failure
★	X	X	Open or short circuit of T1 temperature sensor
X	X	★	Open or short circuit of T2 temperature sensor
X	★	X	Communication malfunction between indoor and outdoor units
★	★	X	Indoor EEPROM malfunction
X	★	●	Outdoor fan speed has been out of control
★	X	★	IPM module protection
★	★	★	Open or short circuit of T3 or T4 temperature sensor or Outdoor unit EEPROM parameter error
★	●	X	Temperature protection of compressor top
★	◎	X	Inverter compressor drive protection
★	X	●	Mode conflict
★	●	★	Indoor fan speed has been out of control
★ flash at 5Hz, ● light, X extinguished, ◎flash at 0.5Hz			

**For MCA2I-12HRDN1-M, MCA2I-18HRDN1-M, MUBI-12HRDN1-M, MUBI-18HRDN1-M:**

Operation	Timer	De-frost	Alarm	Failure
★	X	X	X	Open or short circuit of T1 temperature sensor
X	X	★	X	Open or short circuit of T2 temperature sensor
X	★	X	X	Communication malfunction between indoor and outdoor units
X	X	X	★	Full-water malfunction
★	★	X	X	Indoor EEPROM malfunction
★	X	X	●	IPM module protection
★	●	X	X	Open or short circuit of T3 or T4 temperature sensor
★	●	X	●	Voltage protection
★	★	★	★	Temperature protection of compressor top.
★	X	●	●	Mode conflict
★	●	●	X	Inverter compressor drive protection

★ flash (For cassette, flash at 5Hz)(for ceiling&floor, flash 2.5Hz), ● light, X extinguished,

**For MTBI-12HWDN1-M, MTBI-18HWDN1-M:**

Operation	Timer	De-frost	Alarm	Failure	Display	ODU Error code
★	X	X	X	Open or short circuit of T1 temperature sensor	E0	—
X	X	★	X	Open or short circuit of T2 temperature sensor	E1	—
X	★	X	X	Communication malfunction between indoor and outdoor units	E2	E2
X	X	X	★	Full-water malfunction	E3	—
★	★	X	X	Indoor EEPROM malfunction	E4	—
★	X	X	●	IPM module protection	E5	P6
★	●	X	X	Open or short circuit of T3 or T4 temperature sensor or outdoor EEPROM malfunction	E6	E0,E4
★	●	★	X	Outdoor fan has been out of control	E7	E8
★	●	X	●	Voltage protection	P0	E5
★	★	★	★	Temperature protection of compressor top.	P3	P0
★	◎	X	X	Inverter compressor drive protection	P4	—
★	X	●	X	Mode conflict	P5	—

★ flash at 2.5Hz, ● light, X extinguished ◎flash at 1Hz

**For MTBU-12HRDN1-M, MTBU-18HRDN1-M, MCA2U-12HRFN1-M, MCA2U-18HRFN1-M, MUBU-12HRFN1-M, MUBU-18HRFN1-M:**

Operation	Timer	De-frost	Alarm	Failure	Display	ODU Error code
★	X	X	X	Open or short circuit of T1 temperature sensor	E0	—
X	X	★	X	Open or short circuit of T2 temperature sensor	E1	—
X	★	X	X	Communication malfunction between indoor and outdoor units	E2	E2
X	X	X	★	Full-water malfunction	E3	—
★	★	X	X	Indoor EEPROM malfunction	E4	—
★	X	X	●	IPM module protection	E5	P6
★	●	X	X	Open or short circuit of T3 or T4 temperature sensor or outdoor EEPROM malfunction	E6	E0,E4
★	●	★	X	Outdoor fan has been out of control	E7	E8
★	●	●	X	Indoor fan speed has been out of control	F5	—
★	●	X	●	Voltage protection	P0	E5
★	X	●	X	Temperature protection of compressor top.	P1	P0
★	★	★	X	Outdoor unit over-current protection	P2	P3
★	◎	X	X	Inverter compressor drive protection	P4	—
★	X	●	●	Mode conflict	P5	—

★ flash at 2.5Hz, ● light, X extinguished, ◎ flash at 0.5Hz  
 Note: Digital display is only available for duct type.

**Oasis series:**

Operation lamp	Timer lamp	Display	LED STATUS	ODU Error
★ 1 time	X	E0	Indoor EEPROM malfunction	—
★ 2 times	X	E1	Communication malfunction between indoor and outdoor units	E2
★ 4 times	X	E3	Indoor fan speed malfunction.	—
★ 5 times	X	E4	Indoor room temperature sensor open or short circuit.	—
★ 6 times	X	E5	Evaporator coil temperature sensor open or short circuit.	—
★ 2 times	●	F1	Outdoor temperature sensor open or short circuit.	E4
★ 3 times	●	F2	Condenser coil temperature sensor open or short circuit.	E4
★ 4 times	●	F3	Compressor discharge pipe sensor open or short circuit.	E4
★ 5 times	●	F4	Outdoor EEPROM malfunction	E0
★ 6 times	●	F5	Outdoor fan has been out of control	E8
★ 7 times	●	F6	Indoor unit coil outlet temp. sensor open or short circuit.	E4


★ 1 times	★	P0	Inverter module (IPM) malfunction or IGBT over-strong current protection	P6
★ 2 times	★	P1	Voltage(High voltage or low voltage ) protection.	E5
★ 3 times	★	P2	High temperature protection of compressor top (only for M3OD-27HRDN1-M)	P0
★ 5 times	★	P4	Compressor drive error	--
★ 6 times	★	P5	Mode conflict	--
★ flash , ● light, X extinguished				

## 9.3 Outdoor Unit Display

### 9.3.1 Outdoor unit point check function

There is a check switch in outdoor PCB.

Push the switch SW1 to check the states of unit when the unit is running. The digital display tube will display the follow procedure when push SW1 each time.



	Display	Remark										
0	Normal display	Display running frequency, running state or malfunction code										
1	No. of indoor units in good connection	Actual data <table border="1" style="margin-left: 40px;"> <thead> <tr> <th>Display</th> <th>Number of indoor unit</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>1</td> </tr> <tr> <td>2</td> <td>2</td> </tr> <tr> <td>3</td> <td>3</td> </tr> <tr> <td>4</td> <td>4</td> </tr> </tbody> </table>	Display	Number of indoor unit	1	1	2	2	3	3	4	4
Display	Number of indoor unit											
1	1											
2	2											
3	3											
4	4											
2	Outdoor unit running mode code	Off:0,Fan only 1, Cooling:2, Heating:3, Forced cooling:4										
3	A indoor unit capacity	The capacity unit is horse power. If the indoor unit is not connected, the digital display tube will show: "____" (9K:1HP,12K:1.2HP,18K:1.5HP)										
4	B indoor unit capacity											
5	C indoor unit capacity											
6	D indoor unit capacity											
7	E indoor unit capacity											
8	A Indoor unit capacity demand code	Norm code*HP (9K:1HP,12K:1.2HP,18K:1.5HP)										
9	B Indoor unit capacity demand code											
10	C Indoor unit capacity demand code											
11	D Indoor unit capacity demand code											
12	E Indoor unit capacity demand code											
13	Outdoor unit amendatory capacity demand code	Forced cooling:7										
14	The frequency corresponding to the total indoor units amendatory capacity demand											
15	The frequency after the frequency limit											
16	The frequency sending to compressor control chip											
17	A indoor unit evaporator outlet temp.(T <sub>2B</sub> A)	If the temp. is lower than -9 degree, the digital display tube will show "-9".If the temp. is higher than 70 degree, the digital display tube will show "70". If the indoor unit is not connected, the digital display tube will show: "____"										
18	B indoor unit evaporator outlet temp.(T <sub>2B</sub> B)											
19	C indoor unit evaporator outlet temp.(T <sub>2B</sub> C)											
20	D indoor unit evaporator outlet temp.(T <sub>2B</sub> D)											
21	E indoor unit evaporator outlet temp.(T <sub>2B</sub> E)											
22	A indoor unit room temp.(T <sub>1</sub> A)	If the temp. is lower than 0 degree, the digital display tube will show "0".If the temp. is higher than 50 degree, the digital display tube will show "50". If the indoor unit is not connected, the digital display tube will show: "____"										
23	B indoor unit room temp.(T <sub>1</sub> B)											
24	C indoor unit room temp.(T <sub>1</sub> C)											
25	D indoor unit room temp.(T <sub>1</sub> D)											
26	E indoor unit room temp.(T <sub>1</sub> E)											
27	A indoor unit evaporator temp.(T <sub>2</sub> A)	If the temp. is lower than -9 degree, the digital display tube will show "-9".If the temp. is higher than 70 degree, the digital display tube will show "70". If the indoor unit is not connected, the digital display tube will show: "____"										
28	B indoor unit evaporator temp.(T <sub>2</sub> B)											
29	C indoor unit evaporator temp.(T <sub>2</sub> C)											
30	D indoor unit evaporator temp.(T <sub>2</sub> D)											
31	E indoor unit evaporator temp.(T <sub>2</sub> E)											
32	Condenser pipe temp.(T <sub>3</sub> )											
33	Outdoor ambient temp.(T <sub>4</sub> )											
34	Compressor discharge temp.(T <sub>p</sub> )		The display value is between 30~129 degree. If the temp. is lower than 30 degree, the digital display tube will show "30".If the temp. is higher than 99 degree, the digital display tube will show single digit and tens digit. For example, the digital display tube show "0.5",it means the compressor discharge temp. is 105 degree.)									

35	AD value of current	The display value is hex number. For example ,the digital display tube show "Cd", it means AD value is 205.		
36	AD value of voltage			
37	EXV open angle for A indoor unit	Actual data/4. If the value is higher than 99, the digital display tube will show single digit and tens digit. For example ,the digital display tube show "2.0",it means the EXV open angle is 120x4=480p.)		
38	EXV open angle for B indoor unit			
39	EXV open angle for C indoor unit			
40	EXV open angle for D indoor unit			
41	EXV open angle for E indoor unit			
42	Frequency limit symbol	Bit7	Frequency limit caused by IGBT radiator	The display value is hex number. For example, the digital display tube show 2A,then Bit5=1, Bit3=1, Bit1=1. It means frequency limit caused by T4,T3 and current.
		Bit6	Frequency limit caused by PFC	
		Bit5	Frequency limit caused by T4.	
		Bit4	Frequency limit caused by T2.	
		Bit3	Frequency limit caused by T3.	
		Bit2	Frequency limit caused by Tp.	
		Bit1	Frequency limit caused by current	
		Bit0	Frequency limit caused by voltage	
43	Average value of T2	(Sum T2 value of all indoor units)/( number of indoor units in good connection)		
44	Outdoor unit fan motor state	Off:0, High speed:1, Med speed:2, Low speed:3 Breeze:4, Super breeze:5		
45	The last error or protection code	00 means no malfunction and protection		

### 9.3.2 Outdoor unit's digital display tube

There is a digital display tube in outdoor PCB.

Digital display tube display function

- In standby , the LED displays "- -"
- In compressor operation, the LED display the running frequency,
- In defrosting mode, The LED displays "dF" or alternative displays between running frequency and "dF"(each displays 0.5s)
- In compressor pre-heating, The LED displays "PH" or alternative displays between running frequency and "PH"(each displays 0.5s)
- During the oil return process, The LED displays "RO" or alternative displays between running frequency and "RO"(each displays 0.5s)
- In low ambient cooling mode, the LED displays "LC" or alternative displays between running frequency and "LC"(each displays 0.5s)
- In forced cooling mode, the LED displays "FC" or alternative displays between running frequency and "FC"(each displays 0.5s)
- When PFC module protection occurs three times within 15 minutes, the LED displays "E6" or alternative displays between running frequency and "E6"(each displays 0.5s)
- In protection or malfunction, the LED displays error code or protection code.

### 9.3.3 Outdoor unit error display

Display	LED STATUS	IDU Error (Vertu/Luna)	IDU Error (Oasis)	IDU Error (MTBI(MTBU))
E0	Outdoor EEPROM malfunction	E5	F4	E6
E2	Communication malfunction between indoor and outdoor units	E1	E1	E2
E3	Communication malfunction between IPM board and outdoor main board	---	---	---
E4	Open or short circuit of outdoor temperature sensor(T3、 T4、 TP、 T2B)	E5	F2	E6
E5	Voltage protection	P1	P1	P0
E6	PFC module protection(Only for M4OC-36HRFN1-M)	---	---	---
E8	Outdoor fan speed has been out of control(Only for DC fan motor models)	---	F5	---
F1	No A Indoor unit coil outlet temp. sensor or connector of sensor is defective	---	---	---
F2	No B Indoor unit coil outlet temp. sensor or connector of sensor is defective	---	---	---
F3	No C Indoor unit coil outlet temp. sensor or connector of sensor is defective	---	---	---
F4	No D Indoor unit coil outlet temp. sensor or connector of sensor is defective	---	---	---
P0	Temperature protection of compressor top (Only for M3OD-27HRDN1-M)	P2	P2	P3(P1)
P1	High pressure protection (Only for M4OC-36HRFN1-M)	---	---	---
P2	Low pressure protection(Only for M4OC-36HRFN1-M)	---	---	---
P3	Current protection of compressor	---	---	---(P2)
P4	Temperature protection of compressor discharge	---	---	---
P5	High temperature protection of condenser	---	---	---
P6	IPM module protection	P0	P0	E5


## 9.4 Diagnosis and Solution

### 9.4.1 Indoor unit trouble shooting

#### 9.4.1.1 Indoor EEPROM malfunction diagnosis and solution.

<b>Malfunction decision conditions</b>	PCB main chip does not receive feedback from EEPROM chip
	<ul style="list-style-type: none"><li>● Installation mistake</li><li>● PCB faulty</li></ul>

#### Trouble shooting:



#### Supposed causes


EEPROM: a read-only memory whose contents can be erased and reprogrammed using a pulsed voltage. For the location of EEPROM chip, please refer to the below photos.




### 9.4.1.2 Communication malfunction between indoor and outdoor units diagnosis and solution.

<b>Malfunction decision conditions</b>	Indoor unit does not receive the feedback from outdoor unit during 120 seconds.
<b>Supposed causes</b>	<ul style="list-style-type: none"><li>● Wiring mistake</li><li>● Indoor or outdoor PCB faulty</li></ul>

**Trouble shooting:**





Pic 1: Use a multimeter to test the DC voltage between L2 port and S port of outdoor unit. The red pin of multimeter connects with L2 port while the black pin is for S port.

When AC is normal running, the voltage will move alternately between positive value and negative value.




Pic 2: :IPM (for dual/tri/qua-zone)


Power (some modes)

Self-Check OK

Operating



PIC3 :Main board LED when power on and unit standby.



PIC 4: Check point button, press 1 time for check how many indoor units are connected.(for M2OC-18HFN1-M, M2OD-18HFN1-M,M3OD-27HRDN1-M,M3OC-30HRFN1-M,M4OC-36HRFN1-M)

Check point button, press 18 times for check how many indoor units are connected.(for M2OC-18HRDN1-M,M3OC-27HRDN1-M,M4OC-36HRDN1-M)

### 9.4.1.3 zero-crossing signal error diagnosis and solution.


#### Malfunction decision conditions

When PCB does not receive zero crossing signal feedback for 4 minutes or the zero crossing signal time interval is abnormal.

#### Supposed causes

- Connection mistake
- PCB faulty

#### Trouble shooting:



### 9.4.1.4 Indoor fan speed has been out of control diagnosis and solution.


#### Malfunction decision conditions

When indoor fan speed keeps too low (300RPM) for certain time, the unit will stop and the LED will display the failure.

#### Supposed causes

- Wiring mistake
- Fan ass'y faulty
- Fan motor faulty
- PCB faulty


#### Trouble shooting:



Index 1:

### 1. Indoor AC fan motor

Measure the resistance value of each winding by using the tester.




For the definite value of the resistance, refer to 9.5 Trouble Criterion Of Main Parts

### ➤ 2. Indoor DC fan motor(control chip is inside fan motor)



Measure the resistance value of each winding by using the tester. If any resistance value is zero, the fan motor must have problems and need to be replaced.

For console:



NO.	Color
1	Red
2	---
3	White
4	Blue
5	Yellow
6	Black

For other models:




NO.	Color
1	Red
2	---
3	Black
4	White
5	Yellow
6	Blue

Index2:

#### 1: Indoor AC fan motor

Power on and set the unit running in fan mode at high fan speed. After running for 15 seconds, measure the voltage of pin1 and pin2. If the value of the voltage is less than 100V(208~240V power supply)or 50V(115V power supply), the PCB must have problems and need to be replaced.





#### 2. Indoor DC fan motor(control chip is inside fan motor)


Power on and when the unit is in standby, measure the voltage of pin1-pin3, pin4-pin3 in fan motor connector. If the value of the voltage is not in the range showing in below table, the PCB must have problems and need to be replaced.

For other models:





For console:



DC motor voltage input and output

For light commercial(except console):

NO.	Color	Signal	Voltage
1	Red	Vs/Vm	192V~380V
2	---	---	---
3	Black	GND	0V
4	White	Vcc	13.5-16.5V
5	Yellow	Vsp	0~6.5V
6	Blue	FG	15V



For console:

NO.	Color	Signal	Voltage
1	Red	VDC	310V
2	---	---	---
3	White	Vcc	15V
4	Blue	FG	15V
5	Yellow	Vsp	0-7.5V
6	Black	GND	0V

### 9.4.1.5 open or short circuit of temperature sensor diagnosis and solution.

<b>Malfunction decision conditions</b>	If the sampling voltage is lower than 0.06V or higher than 4.94V, the LED will display the failure.
<b>Supposed causes</b>	<ul style="list-style-type: none"><li>● Wiring mistake</li><li>● Sensor faulty</li><li>● PCB faulty</li></ul>

#### Trouble shooting:



#### 9.4.1.6 IPM module or IGBT over-strong current protection diagnosis and solution.


##### Malfunction decision conditions

When the voltage signal that IPM send to compressor drive chip is abnormal, the display LED will show “P6” and AC will turn off.


##### Supposed causes

- Wiring mistake
- IPM malfunction
- Outdoor fan ass’y faulty
- Compressor malfunction
- Outdoor PCB faulty

**Trouble shooting:**



### 9.4.1.7 Over voltage or too low voltage protection diagnosis and solution.




### 9.4.1.8 Temperature protection of compressor top diagnosis and solution.

#### Malfunction decision conditions

If the sampling voltage is not 5V, the LED will display the failure.

#### Supposed causes

- Wiring mistake
- Over load protector faulty
- System block
- Outdoor PCB faulty



### 9.4.1.9 Inverter compressor drive error diagnosis and solution

The trouble shooting is same with one of IPM module protection(P0).


#### 9.4.1.10 Full-water malfunction diagnosis and solution(For cassette/A5 duct)

##### Malfunction decision conditions

If the sampling voltage is not 5V, the LED will display the failure.

##### Supposed causes

- Wiring mistake
- Water-level switch faulty
- Water pump faulty
- Indoor PCB faulty



#### 9.4.1.11 Mode conflict.

<b>Error Code</b>	<b>P5</b>
<b>Malfunction decision conditions</b>	The indoor units cannot work cooling mode and heating at same time. Heating mode has a priority.
<b>Unit action</b>	<ul style="list-style-type: none"><li>● Suppose Indoor unit A working in cooling mode or fan mode, and indoor unit B is set to heating mode, then A will change to off and B will work in heating mode.</li><li>● Suppose Indoor unit A working in heating mode, and indoor unit B is set to cooling mode or fan mode, then B will change to stand by and A will be no change.</li></ul>

	Cooling mode	Heating Mode	Fan	Off
Cooling mode	No	Yes	No	No
Heating Mode	Yes	No	Yes	No
Fan	No	Yes	No	No
Off	No	No	No	No

No: No mode conflict;

Yes: Mode conflict




## 9.4.2 Outdoor unit trouble shooting

### 9.4.2.1 E0(Outdoor EEPROM malfunction) error diagnosis and solution


<b>Error Code</b>	<b>E0</b>
<b>Malfunction decision conditions</b>	PCB main chip does not receive feedback from EEPROM chip
<b>Supposed causes</b>	<ul style="list-style-type: none"><li>● Installation mistake</li><li>● PCB faulty</li></ul>

Trouble shooting:



EEPROM: a read-only memory whose contents can be erased and reprogrammed using a pulsed voltage.

For the location of EEPROM chip, please refer to the below photos.





Outdoor PCB(M30C-30HRFN1-M)

#### 9.4.2.2 E2(Communication malfunction between indoor and outdoor units) error diagnosis and solution.

<b>Error Code</b>	<b>E2</b>
<b>Malfunction decision conditions</b>	Indoor unit does not receive the feedback from outdoor unit during 120 seconds or outdoor unit does not receive the feedback from any one indoor unit during 180 seconds.
<b>Supposed causes</b>	<ul style="list-style-type: none"><li>● Wiring mistake</li><li>● Indoor or outdoor PCB faulty</li></ul>


**Trouble shooting:**






Pic 1: Use a multimeter to test the DC voltage between L2 port and S port of outdoor unit. The red pin of multimeter connects with L2 port while the black pin is for S port.

When AC is normal running, the voltage will move alternately between positive value and negative value.




Pic 2: :IPM (For dual/tri-zone)



Pic 2: :IPM (For qua-zone)



PIC3 :Main board LED when power on and unit standby.





PIC 4: Check point button, press 1 time for check how many indoor units are connected.

9.4.2.3 E3(Communication malfunction between IPM board and outdoor main board) error diagnosis and .

<b>Error Code</b>	<b>E3</b>
<b>Malfunction decision conditions</b>	PCB main chip does not receive feedback from IPM module during 60 seconds.
<b>Supposed causes</b>	<ul style="list-style-type: none"> <li>● Wiring mistake</li> <li>● PCB faulty</li> </ul>

**Trouble shooting:**







**Remark:**

Use a multimeter to test the DC voltage between black pin and white pin of signal wire. The normal value should be around 5V.



Use a multimeter to test the DC voltage between black pin and red pin of signal wire. The normal value should be around 12V.



9.4.2.4E4(open or short circuit of outdoor temperature sensor) diagnosis and solution  
F1/F2/F3/F4/F5 (open or short circuit of indoor coil temperature sensor) diagnosis and solution.

<b>Error Code</b>	<b>E4/F1/F2/F3/F4/F5</b>
<b>Malfunction decision conditions</b>	If the sampling voltage is lower than 0.06V or higher than 4.94V, the LED will display the failure.
<b>Supposed causes</b>	<ul style="list-style-type: none"><li>● Wiring mistake</li><li>● Sensor faulty</li><li>● PCB faulty</li></ul>

**Trouble shooting:**







### 9.4.2.5 E5(Voltage protection) error diagnosis and solution.


<b>Error Code</b>	<b>E5</b>
<b>Malfunction decision conditions</b>	An abnormal voltage rise or drop is detected by checking the specified voltage detection circuit.
<b>Supposed causes</b>	<ul style="list-style-type: none"> <li>● Power supply problems.</li> <li>● System leakage or block</li> <li>● PCB faulty</li> </ul>

#### Trouble shooting:







IPM (for dual/tri-zone)



IPM (for qua-zone)




P-N (for dual/tri-zone)




P-N (for qua-zone)



bridge rectifier  
(for dual/tri-zone)



bridge rectifier  
(for qua-zone)




**Remark:**

Measure the DC voltage between + and - port. The normal value should be 190V~250V.

### 9.4.2.6 E6(PFC module protection) error diagnosis and solution. (Only for M4OC-36HRFN1-M)


<b>Error Code</b>	<b>E6</b>
<b>Malfunction decision conditions</b>	When the voltage signal that PFC sends to main control board is abnormal, the display LED will show “E6” and AC will turn off.
<b>Supposed causes</b>	<ul style="list-style-type: none"> <li>● Wiring mistake</li> <li>● Outdoor PCB faulty</li> <li>● Inductance of PFC module faulty</li> <li>● PFC module malfunction</li> </ul>

#### Trouble shooting:






Inductance



Two ports of the inductance






9.4.2.7 E8(Outdoor fan speed has been out of control) diagnosis and solution(Only for DC fan motor models).

<b>Error Code</b>	<b>E8</b>
<b>Malfunction decision conditions</b>	When outdoor fan speed keeps too low (300RPM) or too high(2400RPM) for certain time, the unit will stop and the LED will display the failure.
<b>Supposed causes</b>	<ul style="list-style-type: none"> <li>● Wiring mistake</li> <li>● Fan ass'y faulty</li> <li>● Fan motor faulty</li> <li>● PCB faulty</li> </ul>



**Trouble shooting:**



Index 1:

1. DC fan motor(control chip is inside fan motor)

Measure the resistance value of each winding by using the tester. If any resistance value is zero, the fan motor must have problems and need to be replaced.





NO.	Color
1	Red
2	---
3	Black
4	White
5	Yellow
6	Blue

Index2:

1. DC fan motor(control chip is inside fan motor)


Power on and when the unit is in standby, measure the voltage of pin1-pin3, pin4-pin3 in fan motor connector. If the value of the voltage is not in the range showing in below table, the PCB must have problems and need to be replaced.




# DC motor voltage input and output

NO.	Color	Signal	Voltage
1	Red	Vs/Vm	140~380V(M4OC-36HRFN1-M) 263~400V(M2OC-18HFN1-M) M2OD-18HFN1-M) 192~380V(M3OC-30HRFN1-M)
2	---	---	---
3	Black	GND	0V
4	White	Vcc	13.5~16.5V
5	Yellow	Vsp	0~6.5V
6	Blue	FG	15V


**Vs**




**Vcc**



**Vsp**




**FG**





9.4.2.8 P0(Temperature protection of compressor top) error diagnosis and solution. (Only for M3OD-27HRDN1-M)

Error Code	P0
Malfunction decision conditions	If the sampling voltage is not 5V, the LED will display the failure.
Supposed causes	<ul style="list-style-type: none"> <li>● Wiring mistake</li> <li>● Over load protector faulty</li> <li>● System block</li> <li>● Outdoor PCB faulty</li> </ul>

**Trouble shooting:**








### 9.4.2.9 P1(High pressure protection) error diagnosis and solution. (Only for M4OC-36HRFN1-M)

<b>Error Code</b>	<b>P1</b>
<b>Malfunction decision conditions</b>	If the sampling voltage is not 5V, the LED will display the failure.
<b>Supposed causes</b>	<ul style="list-style-type: none"> <li>● Wiring mistake</li> <li>● Over load protector faulty</li> <li>● System block</li> <li>● Outdoor PCB faulty</li> </ul>

#### Trouble shooting:








### 9.4.2.10 P2(Low pressure protection) error diagnosis and solution. (Only for M4OC-36HRFN1-M)

<b>Error Code</b>	<b>P2</b>
<b>Malfunction decision conditions</b>	If the sampling voltage is not 5V, the LED will display the failure.
<b>Supposed causes</b>	<ul style="list-style-type: none"> <li>● Wiring mistake</li> <li>● Over load protector faulty</li> <li>● System block</li> <li>● Outdoor PCB faulty</li> </ul>

#### Trouble shooting:








### 9.4.2.11 P3(Current protection of compressor) error diagnosis and solution.

<b>Error Code</b>	<b>P3</b>
<b>Malfunction decision conditions</b>	If the compressor current exceeds the current limit value for 10 seconds, the LED will display the failure.
<b>Supposed causes</b>	<ul style="list-style-type: none"> <li>● Wiring mistake</li> <li>● Over load protector faulty</li> <li>● System block</li> <li>● Outdoor PCB faulty</li> </ul>

#### Trouble shooting:






### 9.4.2.12 P4(Temperature protection of compressor discharge) error diagnosis and solution.

<b>Error Code</b>	<b>P4</b>
<b>Malfunction decision conditions</b>	When the compressor discharge temperature( $T_p$ ) is more than $115^{\circ}\text{C}$ for 10 seconds, the compressor will stop and restart till $T_p$ is less than $90^{\circ}\text{C}$ .
<b>Supposed causes</b>	<ul style="list-style-type: none"> <li>● Refrigerant leakage</li> <li>● Wiring mistake</li> <li>● The discharge temperature sensor faulty</li> <li>● Outdoor PCB faulty</li> </ul>


#### Trouble shooting:



### 9.4.2.13 P5(High temperature protection of condenser) error diagnosis and solution.

<b>Error Code</b>	<b>P5</b>
<b>Malfunction decision conditions</b>	When outdoor pipe temperature is more than 65°C, the unit will stop, and unit runs again when outdoor pipe temperature is less than 52°C
<b>Supposed causes</b>	<ul style="list-style-type: none"> <li>● The condenser temperature sensor faulty</li> <li>● Heat exchanger dirty</li> <li>● System block</li> </ul>


#### Trouble shooting:



#### 9.4.2.14 P6(IPM module protection) error diagnosis and solution.

<b>Error Code</b>	<b>P6</b>
<b>Malfunction decision conditions</b>	When the voltage signal that IPM send to compressor drive chip is abnormal, the display LED will show “P6” and AC will turn off.
<b>Supposed causes</b>	<ul style="list-style-type: none"><li>● Wiring mistake</li><li>● IPM malfunction</li><li>● Outdoor fan ass’y faulty</li><li>● Compressor malfunction</li><li>● Outdoor PCB faulty</li></ul>

**Trouble shooting:**



**9.4.2.15 The cooling operation or heating operation does not operate.**

**Supposed causes**

- 4-way valve faulty

**Check of 4-way, please refer to part 5 in 9.5 Trouble Criterion Of Main Parts.**

**9.4.2.16 When cooling, heat exchanger of non-operating indoor unit frosts.**

**When heating, non-operating indoor unit get warm.**

**Supposed causes**

- EXV faulty
- Wire and tubing connected in reverse.

**Check of EXV, please refer to part 6 in 9.5 Trouble Criterion Of Main Parts.**



## 9.5 Trouble Criterion Of Main Parts.


Spec.

<b>Indoor unit</b>				
Model	9k Vertu	12k Vertu	18k Vertu	
Indoor fan motor	RPG20B	RPG20B	RPG28H	
Model	7k Luna	9k Luna	12k Luna	18k Luna
Indoor fan motor	RPG20B	RPG20B	RPG20B	RPG28H
Model	9k Oasis	12k Oasis	18k Oasis	
Indoor fan motor	WZDK20-38G	WZDK20-38G	WZDK58-38G	
Model	MTBI-12HWDN1-M	MTBI-18HWDN1-M	MTBU-12HRDN1-M	MTBU-18HRDN1-M
Indoor fan motor	YSK27-4G	YSK68-4B	YSK27-4G	YSK68-4B
Model	MCA2I-12HRDN1-M	MCA2I-18HRDN1-M	MCA2U-12HRFN1-M	MCA2U-18HRFN1-M
Indoor fan motor	YDK45-6B	YDK45-6B	WZDK37-38G	WZDK37-38G
Model	MUBI-12HRDN1-M	MUBI-18HRDN1-M	MUBU-12HRFN1-M	MUBU-18HRFN1-M
Indoor fan motor	YSK25-6L	YSK25-6L	WZDK55-38GS-W	WZDK55-38GS-W
Model	MFAI-12HRDN1-M	MFAU-12HRFN1-M		
Indoor fan motor	RD-280-20-8A	RD-280-20-8A		
<b>Outdoor unit</b>				
Model	M2OC-18HFN1-M M2OD-18HFN1-M	M3OD-27HRDN1-M	M3OC-30HRFN1-M	M4OC-36HRFN1-M
Compressor	DA130S1C-20FZ	DA150S1C-20FZ	DA250S2C-30MT	TNB306FPGMC-L
Outdoor fan motor	WZDK50-38G	YDK53-6FB(B)	WZDK72-38G	WZDK180-38G

1.

## 1. Temperature sensor checking

Disconnect the temperature sensor from PCB, measure the resistance value with a tester.



Tester

Temperature Sensors.

Room temp.(T1) sensor,

Indoor coil temp.(T2) sensor,

Outdoor coil temp.(T3) sensor,

Outdoor ambient temp.(T4) sensor,

Compressor discharge temp.(Tp) sensor.

Measure the resistance value of each winding by using the multi-meter.

**Appendix 1 Temperature Sensor Resistance Value Table (°C--K)**

°C	K Ohm	°C	K Ohm	°C	K Ohm	°C	K Ohm
-20	115.266	20	12.6431	60	2.35774	100	0.62973
-19	108.146	21	12.0561	61	2.27249	101	0.61148
-18	101.517	22	11.5000	62	2.19073	102	0.59386
-17	96.3423	23	10.9731	63	2.11241	103	0.57683
-16	89.5865	24	10.4736	64	2.03732	104	0.56038
-15	84.2190	25	10.0000	65	1.96532	105	0.54448
-14	79.3110	26	9.55074	66	1.89627	106	0.52912
-13	74.5360	27	9.12445	67	1.83003	107	0.51426
-12	70.1698	28	8.71983	68	1.76647	108	0.49989
-11	66.0898	29	8.33566	69	1.70547	109	0.48600
-10	62.2756	30	7.97078	70	1.64691	110	0.47256
-9	58.7079	31	7.62411	71	1.59068	111	0.45957
-8	56.3694	32	7.29464	72	1.53668	112	0.44699
-7	52.2438	33	6.98142	73	1.48481	113	0.43482
-6	49.3161	34	6.68355	74	1.43498	114	0.42304
-5	46.5725	35	6.40021	75	1.38703	115	0.41164
-4	44.0000	36	6.13059	76	1.34105	116	0.40060
-3	41.5878	37	5.87359	77	1.29078	117	0.38991
-2	39.8239	38	5.62961	78	1.25423	118	0.37956
-1	37.1988	39	5.39689	79	1.21330	119	0.36954
0	35.2024	40	5.17519	80	1.17393	120	0.35982
1	33.3269	41	4.96392	81	1.13604	121	0.35042
2	31.5635	42	4.76253	82	1.09958	122	0.3413
3	29.9058	43	4.57050	83	1.06448	123	0.33246
4	28.3459	44	4.38736	84	1.03069	124	0.32390
5	26.8778	45	4.21263	85	0.99815	125	0.31559
6	25.4954	46	4.04589	86	0.96681	126	0.30754
7	24.1932	47	3.88673	87	0.93662	127	0.29974
8	22.5662	48	3.73476	88	0.90753	128	0.29216
9	21.8094	49	3.58962	89	0.87950	129	0.28482
10	20.7184	50	3.45097	90	0.85248	130	0.27770
11	19.6891	51	3.31847	91	0.82643	131	0.27078
12	18.7177	52	3.19183	92	0.80132	132	0.26408
13	17.8005	53	3.07075	93	0.77709	133	0.25757
14	16.9341	54	2.95896	94	0.75373	134	0.25125
15	16.1156	55	2.84421	95	0.73119	135	0.24512
16	15.3418	56	2.73823	96	0.70944	136	0.23916
17	14.6181	57	2.63682	97	0.68844	137	0.23338
18	13.9180	58	2.53973	98	0.66818	138	0.22776
19	13.2631	59	2.44677	99	0.64862	139	0.22231

**Appendix 2**


		Unit: °C---K		Discharge temp. sensor table			
-20	542.7	20	68.66	60	13.59	100	3.702
-19	511.9	21	65.62	61	13.11	101	3.595
-18	483	22	62.73	62	12.65	102	3.492
-17	455.9	23	59.98	63	12.21	103	3.392
-16	430.5	24	57.37	64	11.79	104	3.296
-15	406.7	25	54.89	65	11.38	105	3.203
-14	384.3	26	52.53	66	10.99	106	3.113
-13	363.3	27	50.28	67	10.61	107	3.025
-12	343.6	28	48.14	68	10.25	108	2.941
-11	325.1	29	46.11	69	9.902	109	2.86
-10	307.7	30	44.17	70	9.569	110	2.781
-9	291.3	31	42.33	71	9.248	111	2.704
-8	275.9	32	40.57	72	8.94	112	2.63
-7	261.4	33	38.89	73	8.643	113	2.559
-6	247.8	34	37.3	74	8.358	114	2.489
-5	234.9	35	35.78	75	8.084	115	2.422
-4	222.8	36	34.32	76	7.82	116	2.357
-3	211.4	37	32.94	77	7.566	117	2.294
-2	200.7	38	31.62	78	7.321	118	2.233
-1	190.5	39	30.36	79	7.086	119	2.174
0	180.9	40	29.15	80	6.859	120	2.117
1	171.9	41	28	81	6.641	121	2.061
2	163.3	42	26.9	82	6.43	122	2.007
3	155.2	43	25.86	83	6.228	123	1.955
4	147.6	44	24.85	84	6.033	124	1.905
5	140.4	45	23.89	85	5.844	125	1.856
6	133.5	46	22.89	86	5.663	126	1.808
7	127.1	47	22.1	87	5.488	127	1.762
8	121	48	21.26	88	5.32	128	1.717
9	115.2	49	20.46	89	5.157	129	1.674
10	109.8	50	19.69	90	5	130	1.632
11	104.6	51	18.96	91	4.849		
12	99.69	52	18.26	92	4.703		
13	95.05	53	17.58	93	4.562		
14	90.66	54	16.94	94	4.426		
15	86.49	55	16.32	95	4.294	B(25/50)=3950K	
16	82.54	56	15.73	96	4.167		
17	78.79	57	15.16	97	4.045	R(90°C)=5KΩ±3%	
18	75.24	58	14.62	98	3.927		
19	71.86	59	14.09	99	3.812		

### Appendix 3:

°C	10	11	12	13	14	15	16	17	18	19	20	21	22
°F	48	50	52	54	56	58	60	62	64	66	68	70	72
°C	23	24	25	26	27	28	29	30	31	32	33	34	35
°F	74	76	78	80	82	84	86	88	90	92	94	96	98

## 2. Compressor check

Measure the resistance value of each winding by using the tester.



Position	Resistance Value			
		DA130S1C-20FZ	DA150S1C-20FZ	DA250S2C-30MT
Blue - Red	0.95Ω(20°C)	0.95Ω(20°C)	0.55Ω(20°C)	0.53Ω(20°C)




### 3. IPM continuity check

Turn off the power, let the large capacity electrolytic capacitors discharge completely, and dismantle the IPM. Use a digital tester to measure the resistance between P and UVWN; UVW and N.

Digital tester		Normal resistance value	Digital tester		Normal resistance value
(+)Red	(-)Black		(+)Red	(-)Black	
P	N	$\infty$ (Several M $\Omega$ )	U	N	$\infty$ (Several M $\Omega$ )
	U		V		
	V		W		
	W		(+)Red		


### 4. AC Fan Motor.

Measure the resistance value of each winding by using the tester.



Position	Resistance Value			
	RPG20B		RPG28H	
Black - Red	381 $\Omega$ ±8% (20°C) (Brand: Weiling)	342 $\Omega$ ±8% (20°C) (Brand: Dayang)	183.6 $\Omega$ ±8% (20°C) (Brand: Weiling)	180 $\Omega$ ±8% (20°C) (Brand: Wolong)
White - Black	267 $\Omega$ ±8% (20°C) (Brand: Weiling)	253 $\Omega$ ±8% (20°C) (Brand: Dayang)	206 $\Omega$ ±8% (20°C) (Brand: Weiling)	190 $\Omega$ ±8% (20°C) (Brand: Wolong)

Measure the resistance value of each winding by using the tester.




Position	Resistance Value						
	YDK70-6FB	YDK180-8GB	YSK27-4G	YSK68-4B	YDK45-6B	YSK25-6L	YDK53-6FB(B)
Black - Red	56Ω±8% (20°C)	24.5Ω±8% (20°C)	317Ω±8% (20°C)	145Ω±8% (20°C)	345Ω±8% (20°C)	627Ω±8% (20°C)	88.5Ω±8% (20°C)
Red - Yellow	76Ω±8% (20°C)	19Ω±8% (20°C)	252Ω±8% (20°C)	88Ω±8% (20°C)	150Ω±8% (20°C)	374.3Ω±8% (20°C)	138Ω±8% (20°C)
Yellow - Blue	76Ω±8% (20°C)	19Ω±8% (20°C)	252Ω±8% (20°C)	88Ω±8% (20°C)	150Ω±8% (20°C)	374.3Ω±8% (20°C)	138Ω±8% (20°C)


## 5.4-way valve

1. Power on, use a digital tester to measure the voltage, when the unit operates in cooling, it is 0V. When the unit operates in heating, it is about 230VAC.

If the value of the voltage is not in the range, the PCB must have problems and need to be replaced.




2 Turn off the power, use a digital tester to measure the resistance. The value should be 1.8~2.5 KΩ.





## 6.EXV check

**Disconnect the connectors.**









**Resistance to EXV coil**


Color of lead wire	Normal Value
Red- Blue	About 50Ω
Red - Yellow	
Brown-Orange	
Brown-White	




Red- Blue



Red - Yellow



Brown-Orange




Brown-White

## 10. Disassembly Instructions

➤ Model: M2OC-18HFN1-M, M2OD-18HFN1-M (W210 metal plate)


No.	Part name	Procedures	Remarks
1	Panel plate	<p>How to remove the panel plate.</p> <ol style="list-style-type: none"> <li>1) Stop operation of the air conditioner and turn "OFF" the power breaker.</li> <li>2) Remove the screws of top cover, and remove the top cover. (9 screws)</li> <li>3) Remove the screws of right front side panel, and remove the right front side panel (2 screws)</li> <li>4) Remove the screws of front panel, and remove the front panel. (9 screws)</li> </ol>	<p>The 'Remarks' column contains three photographs illustrating the disassembly steps. The top photo shows the outdoor unit with red arrows pointing to screws on the top cover, front panel, and right front side panel. The middle photo shows the top cover removed, with red arrows pointing to screws on the top cover, right-rear panel, and front panel. The bottom photo shows the right front side panel removed, with red arrows pointing to screws on the front panel.</p>

- 5) Remove the screws of big handle, and remove the big handle.(4 screws)
- 6) Remove two screws of terminal board, four screws of water collector and fourteen screws of right-rear panel, and remove the right-rear panel.



2 Fan ass'y



- How to remove the fan ass'y.
- 1) Remove the top cover, right front side panel and front panel from item 1.step 1~4
  - 2) Remove the hex nut fixing the fan.
  - 3) Remove the fan.



4) Remove the electrical control box cover.

5) Disconnect the fan motor connector CN37(5p,white) from the PCB board.

6) Remove the fan motor after unfastening four fixing screws.



3 Electrical parts

How to remove the electrical parts.



1) Perform work of item 1,2.

2) Remove the ten screws fixing the IPM board.

3) Unfasten the connector of the reactor.

4) Unfasten the connector of the compressor.

5) Disconnect following 5 pieces of connection wires and connectors between IPM and PCB.




CN38(2p,white)

CN21(5p,white)


CN39(2p,blue)

L-OUT(red)

N-OUT(blue)



6) Remove the IPM board.



7) Disconnect the connectors and wires connected from PCB and other parts.

**Connectors:**

CN17:T3/T4 temp. sensor  
(2p/2p,white)

CN7: Tdischarge temp. sensor  
(2p,white)

CN15:T2B-A,B temp. sensor  
(2p/2p,white)

CN18/CN19: Electronic expansive  
valve A,B (6p/6p,red/red)

CN25/CN23: S-A,S-B  
(3p/3p,white/white)


**Wires:**

CN1/CN2: 4-way valve (blue-blue)


CN5/CN6: Crankcase heating cable  
(red-red)

CN3:L-IN (red)

CN4:N-IN (black)





- 8) Disconnect the grounding wire (yellow-green) after removing the big handle and the right-rear panel.
- 9) Remove the PCB board.






4 Compressor

How to remove the compressor.

- 1) Perform work of item 1,2,3.
- 2) Remove the electrical control box and partition plate.
- 3) Extract refrigerant gas.
- 4) Remove the sound insulation material and crankcase heating cable.
- 5) Remove terminal cover of compressor, and disconnect wires of compressor thermo and compressor from the terminal.
- 6) Remove the discharge pipe and suction pipe with a burner.
- 7) Remove the hex nuts and washers fixing the compressor to bottom plate.
- 8) Lift the compressor.






5	Reactor	<p>How to remove the reactor</p> <ol style="list-style-type: none"> <li>1) Perform work of item 1,2</li> <li>2) Unfasten the connector between IPM and reactor.</li> <li>3) Remove two screws of cover of inductance, and remove the cover of inductance</li> <li>4) Disconnect two pieces of wires connected from the cover of inductance.</li> <li>5) Remove two screws of reactor, and remove the reactor.</li> </ol>	
6	The 4-way valve	<p>How to remove the 4-way valve</p> <ol style="list-style-type: none"> <li>1) Perform work of item 1,2.</li> <li>2) Extract refrigerant gas.</li> <li>3) Remove the electrical parts from item 3.</li> <li>4) Remove fixing screw of the coil, and remove the coil.</li> <li>5) Detach the welded parts of 4-way valve and pipe.</li> </ol>	
7	The expansion valve	<p>How to remove the expansion valve</p> <ol style="list-style-type: none"> <li>1) Perform work of item 1,2.</li> <li>2) Remove the electrical parts from item 3..</li> <li>3) Remove the coils.</li> <li>4) Detach the welded parts of expansion valves and pipes.</li> </ol>	

➤ **Model: M3OD-27HRDN1-M (W210 metal plate)**

No.	Part name	Procedures	Remarks
1	Panel plate	<p>How to remove the panel plate.</p> <ol style="list-style-type: none"> <li>1) Stop operation of the air conditioner and turn "OFF" the power breaker.</li> <li>2) Remove the screws of top cover, and remove the top cover. (9 screws)</li> <li>3) Remove the screws of right front side panel, and remove the right front side panel (2 screws)</li> <li>4) Remove the screws of front panel, and remove the front panel. (9 screws)</li> <li>5) Remove the screws of big handle, and remove the big handle.(4 screws)</li> <li>6) Remove two screws of terminal board, two screws of water collector and twelve screws of right-rear panel, and remove the right-rear panel.</li> </ol>	<p>The diagrams illustrate the removal of the panel plate in three stages:</p> <ul style="list-style-type: none"> <li><b>Top Diagram:</b> Shows the removal of the top cover (9 screws) and the right front side panel (2 screws).</li> <li><b>Middle Diagram:</b> Shows the removal of the front panel (9 screws) and the right-rear panel (12 screws).</li> <li><b>Bottom Diagram:</b> Shows the removal of the big handle (4 screws) and the terminal board and water collector (2 screws each).</li> </ul>




2

Fan ass'y

How to remove the fan ass'y.



- 1) Remove the top cover, right front side panel and front panel from item 1.step 1~4
- 2) Remove the hex nut fixing the fan.
- 3) Remove the fan.
- 4) Remove the electrical control box cover.



5) Disconnect the fan motor connector CN11(5p,white) from the PCB board.

6) Remove the fan motor after unfastening six fixing screws.

Note: There are two kinds of screws. Please pay attention to it when install the fan motor.



3 Electrical parts


How to remove the electrical parts.

1) Perform work of item 1,2.

2) Remove the ten screws fixing the IPM board.


3) Unfasten the connector of the reactor.

4) Unfasten the connector of the compressor.



IPM board

PCB board




5) Disconnect following 3 pieces of connection wires and connectors between IPM and PCB.

CN21(5p,white)

L-OUT(red)

N-OUT(blue)



6) Remove the IPM board.



7) Disconnect the connectors and wires connected from PCB and other parts.

Connectors:

CN17:T3/T4 temp. sensor (2p/2p,white)

CN7: Tdischarge temp. sensor (2p,white)

CN12:Ttop temp. sensor(2p,white)

CN15:T2B-A,B,C temp. sensor (2p/2p/2p,white)

CN18/CN19/CN22: Electronic expansive

valve A,B,C (6p/6p/6p,red/red/red)


CN25/CN23/CN20: S-A,S-B,S-C (3p/3p/3p,white/white/white)

Wires:

CN1/CN2: 4-way valve (blue-blue)

CN5/CN6: Crankcase heating cable (red-red)


CN3:L1-IN (red)



CN4:L2-IN (black)

8) Disconnect the grounding wire (yellow-green) after removing the big handle and the right-rear panel.


9) Remove the PCB board.







4 Compressor

How to remove the compressor.

- 1) Perform work of item 1,2,3.
- 2) Remove the electrical control box and partition plate.
- 3) Extract refrigerant gas.
- 4) Remove the sound insulation material and crankcase heating cable.
- 5) Remove terminal cover of compressor, and disconnect wires of compressor thermo and compressor from the terminal.
- 6) Remove the discharge pipe and suction pipe with a burner.
- 7) Remove the hex nuts and






		<p>washers fixing the compressor to bottom plate.</p> <p>8) Lift the compressor.</p>	
5	Reactor	<p>How to remove the reactor</p> <ol style="list-style-type: none"> <li>1) Perform work of item 1,2</li> <li>2) Unfasten the connector between IPM and reactor.</li> <li>3) Remove two screws of cover of inductance, and remove the cover of inductance</li> <li>4) Disconnect two pieces of wires connected from the cover of inductance.</li> <li>5) Remove two screws of reactor, and remove the reactor.</li> </ol>	 <p>Screws of cover of inductance</p> <p>Screws of reactor</p>
6	The 4-way valve	<p>How to remove the 4-way valve</p> <ol style="list-style-type: none"> <li>1) Perform work of item 1,2.</li> <li>2) Extract refrigerant gas.</li> <li>3) Remove the electrical parts from item 3.</li> <li>4) Remove fixing screw of the coil, and remove the coil.</li> <li>5) Detach the welded parts of 4-way valve and pipe.</li> </ol>	 <p>Coil</p> <p>Welded parts</p>

7	The expansion valve	<p>How to remove the expansion valve</p> <ol style="list-style-type: none"><li>1) Perform work of item 1,2.</li><li>2) Remove the electrical parts from item 3.</li><li>3) Remove the coils.</li><li>4) Detach the welded parts of expansion valves and pipes.</li></ol>	 <p>Expansion valves</p> <p>Coils</p>
---	---------------------	--	--




➤ **Model: M3OC-30HRFN1-M (W310 metal plate)**

No.	Part name	Procedures	Remarks
1	Panel plate	<p>How to remove the panel plate.</p> <ol style="list-style-type: none"> <li>1) Stop operation of the air conditioner and turn "OFF" the power breaker.</li> <li>2) Remove the screws of top cover, and remove the top cover. (7 screws)</li> <li>3) Remove the screws of right front side panel, and remove the right front side panel (2 screws)</li> <li>4) Remove the screws of front panel, and remove the front panel. (10 screws)</li> <li>5) Remove the screws of big handle, and remove the big handle.(2 screws)</li> <li>6) Remove two screws of terminal board and eleven screws of right-rear panel, and remove the right-rear panel.</li> </ol>	<p>Screws of top cover</p> <p>Screws of right front side panel</p> <p>Screws of terminal board</p> <p>Screws of right-rear panel</p> <p>Screws of water collector</p>




<p>2</p>	<p>Fan ass'y</p>	<p>How to remove the fan ass'y.</p> <ol style="list-style-type: none"> <li>1) Remove the top cover, right front side panel and front panel from item 1.step 1~4</li> <li>2) Remove the hex nut fixing the fan.</li> <li>3) Remove the fan.</li> <li>4) Remove the electrical control box cover.</li> <li>5) Disconnect the fan motor connector CN37(5p,white) from the PCB board.</li> <li>6) Remove the fan motor after unfastening six fixing screws.</li> </ol>	
<p>3</p>	<p>Electrical parts</p>	<p>How to remove the electrical parts.</p> <ol style="list-style-type: none"> <li>1) Perform work of item 1,2..</li> <li>2) Remove the ten screws fixing the IPM board.</li> <li>3) Unfasten the connector of the reactor.</li> <li>4) Unfasten the connector of the compressor.</li> </ol>	

5) Disconnect following 5 pieces of connection wires and connectors between IPM and PCB.



L-OUT(red)


N-OUT(blue)




CN38(2p,white)

CN21(5p,white)

CN39(2p,blue)



6) Remove the IPM board.



7) Disconnect the connectors and wires connected from PCB and other parts.

Connectors:

CN17: T3/T4 temp. sensor  
(2p/2p, white)

CN7: Tdischarge temp. sensor  
(2p, white)

CN15: T2B-A,B,C temp. sensor  
(2p/2p/2p, white)

CN18/CN19/CN22: Electronic  
expansive valve A,B,C  
(6p/6p/6p, red/red/red)

CN25/CN23/CN20: S-A,S-B,S-C  
(3p/3p/3p, white/white/white)

Wires:

CN1/CN2: 4-way valve (blue-blue)



CN5/CN6: Crankcase heating cable  
(red-red)



CN3: L1-IN (red)




CN4: N-IN (black)


8) Disconnect the  
grounding wire (yellow-green)  
after removing the big handle  
and the right-rear panel.

9) Remove the PCB board.




			
4	Compressor	<p>How to remove the compressor.</p> <ol style="list-style-type: none"> <li>1) Perform work of item 1,2,3.</li> <li>2) Remove the electrical control box and partition plate.</li> <li>3) Extract refrigerant gas.</li> <li>4) Remove the sound insulation material and crankcase heating cable.</li> <li>5) Remove terminal cover of compressor, and disconnect wires of compressor thermo and compressor from the terminal.</li> <li>6) Remove the discharge pipe and suction pipe with a burner.</li> <li>7) Remove the hex nuts and washers fixing the compressor to bottom plate.</li> <li>8) Lift the compressor.</li> </ol>	



5	Reactor	<p>How to remove the reactor</p> <ol style="list-style-type: none"> <li>1) Perform work of item 1,2</li> <li>2) Unfasten the connector between IPM and reactor.</li> <li>3) Remove four screws of cover of inductance, and remove the cover of inductance</li> <li>4) Disconnect two pieces of wires connected from the cover of inductance.</li> <li>5) Remove two screws of reactor, and remove the reactor.</li> </ol>	<p style="text-align: center;">Screws of cover of inductance</p>   <p style="text-align: center;">Screws of reactor</p>
6	The 4-way valve	<p>How to remove the 4-way valve</p> <ol style="list-style-type: none"> <li>1) Perform work of item 1,2.</li> <li>2) Extract refrigerant gas.</li> <li>3) Remove the electrical parts from item 3.</li> <li>4) Remove fixing screw of the coil, and remove the coil.</li> <li>5) Detach the welded parts of 4-way valve and pipe.</li> </ol>	 <p style="text-align: right;">Coil</p> <p style="text-align: right;">Welded parts</p>

7	The expansion valve	<p>How to remove the expansion valve</p> <ol style="list-style-type: none"><li>1) Perform work of item 1,2.</li><li>2) Remove the electrical parts from item 3.</li><li>3) Remove the coils.</li><li>4) Detach the welded parts of expansion valves and pipes.</li></ol>	 <p>Expansion valves</p> <p>. Coils</p>
---	---------------------	--	--



➤ **Model: M4OC-36HRFN1-M (W520 metal plate)**



No.	Part name	Procedures	Remarks
1	Panel plate	<p>How to remove the panel plate.</p> <ol style="list-style-type: none"> <li>1) Stop operation of the air conditioner and turn "OFF" the power breaker.</li> <li>2) Remove the screws of top cover, and remove the top cover. (8 screws)</li> <li>3) Remove the screws of right front side panel, and remove the right front side panel (2 screws)</li> <li>4) Remove the screws of front panel, and remove the front panel. (10 screws)</li> <li>5) Remove the screws of big handle, and remove the big handle.(4 screws)</li> <li>6) Remove two screws of terminal board, two screws of water collector and thirteen screws of right-rear panel, and remove the right-rear panel.</li> </ol>	 <p>Screws of top cover</p> <p>Screws of front panel</p> <p>Screws of right front side panel</p> <p>Screws of top cover</p> <p>Screws of right-rear panel</p> <p>Screws of front panel</p>



2	Fan ass'y	<p>How to remove the fan ass'y.</p> <ol style="list-style-type: none"> <li>1) Remove the top cover, right front side panel and front panel from item 1.step 1~4 .</li> <li>2) Remove the hex nut fixing the fan.</li> <li>3) Remove the fan.</li> <li>4) Remove the electrical control box cover after remove 5 screws.</li> <li>5) Disconnect the fan motor connector CN25(5p,white) on the PCB board.</li> <li>6) Remove the fan motor after unfastening four fixing screws.</li> </ol>	
---	-----------	---	--

3	Electrical parts	<p>How to remove the electrical parts.</p> <ol style="list-style-type: none"> <li>1) Perform work of item 1, 2.</li> <li>2) Disconnect the following connection wires and connectors on the IPM. <ul style="list-style-type: none"> <li>P: (+, red), connected to P2 on PCB.</li> <li>N: (-, blue), connected to P4 on PCB.</li> <li>UVW: (blue-red-black), connected to compressor.</li> <li>CN1: (5p, white),connected to CN7 on PCB.</li> <li>CN202:(2p, white),connected to CN8 on PFC.</li> <li>CN3: (2p, white), connected to CN34 on PCB.</li> </ul> </li> <li>3) Remove the IPM board after removing the two screws.</li> </ol>	
---	------------------	---	--

- 4) Disconnect following connection wires and connectors on the PFC.
  - C and CN12: (yellow-yellow), connected to PFC inductance.
  - R and CN12: (blue-red), connected to rectifier.
  - + and - : (red-blue), connected to P1 and P3 on PCB.
  - CN7: (4p,red), connected to CN11 on PCB.
  - CN8: (2p,white), connected to CN202 on IPM.
- 5) Remove the PFC board after remove the two screws.
- 6) Disconnect four wires (red-blue from PFC and black-red from PCB), then the rectifier can be removed.



7) Disconnect following connection wires and connectors between PCB and other components.

P4: (blue), connected to N on IPM.

P2: (red), connected to P on IPM.

P1: (red), connected to + on PFC.

P3: (blue), connected to – on PFC.

RY4: (red), connected to rectifier.

CN34: (2p, white), connected to CN3 on IPM.

CN6/CN22: (blue/blue), connected to 4 way valve.

CN3/CN40: (red/red), connected to crankcase heating cable.

CN11: (4p, red), connected to CN7 on PFC.

CN13: T2B-A,B,C,D temp. sensor (2p/2p/2p/2p, white)

CN33: Tdischarge temp. sensor (2p, white)

CN8: T3/T4/T3/T4 temp. sensor (2p/2p, white)





CN9: High and low pressure switch (2p/2p, white)

CN18/CN19/CN20/CN21: electronic expansive valve A,B,C,D (6p/6p/6p/6p, red/red/red/red)

CN27/CN28/CN29/CN30: S-A,B,C,D (3p/3p/3p/3p, white/white/white/white)


CN1-CN2: (red-black), connected to power terminal

P-1/P-2: (yellow-green/yellow-green),




grounding wires of PCB.

8) Remove the PCB board.



CN1 CN2



4



Compressor

How to remove the compressor.

- 1) Perform work of item 1,2,3
- 2) Remove the electrical control box and partition plate.
- 3) Extract refrigerant gas.
- 4) Remove the sound insulation material and crankcase heating cable.
- 5) Remove terminal cover of compressor, and disconnect wires of compressor thermo and compressor from the terminal.
- 6) Remove the discharge pipe and suction pipe with a burner.
- 7) Remove the hex nuts and washers fixing the compressor to bottom plate.
- 8) Lift the compressor.



⑦

5	The 4-way valve	<p>How to remove the 4-way valve</p> <ol style="list-style-type: none"><li>1) Perform work of item 1,2.</li><li>2) Extract refrigerant gas.</li><li>3) Remove the electrical parts from item 3.</li><li>4) Remove fixing screw of the coil, and remove the coil.</li><li>5) Detach the welded parts of 4-way valve and pipe.</li></ol>	 <p>Coil</p> <p>Welded parts</p>
6	The expansion valve	<p>How to remove the expansion valve</p> <ol style="list-style-type: none"><li>1) Perform work of item 1,2.</li><li>2) Remove the electrical parts from item 3..</li><li>3) Remove the coils.</li><li>4) Detach the welded parts of expansion valves and pipes.</li></ol>	 <p>Expansion valves</p> <p>Coils</p>

