

SDi Decades Extreme Service Manual

Inverter Ducted Split 3&5 Ton R-410A Heat Pump



All phases of this installation must comply with National, State and Local Codes.

IMPORTANT

These instructions do not cover all variations in systems or provide for every possible contingency to be met in connection with installing and servicing. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to local distributor.

Contents

1.	Safety Precautions	4
	1.1 Precautions	4
	1.2 Information servicing	5
2.	Model Reference & External Appearance	10
	2.1 Model Reference	10
	2.2 External Appearance	10
3.	Indoor Unit	11
	3.1 Indoor Unit - Air Handler Type	11
4.	Outdoor Unit	24
	4.1 Dimensional Drawings	24
	4.2 Service Space	25
	4.3 Capacity Correction Factor for Height Difference	26
	4.4 Noise Criterion Curves	27
	4.5 Refrigerant Cycle Diagrams	28
	4.6 Electrical Wiring Diagrams	29
5.	Installation	36
6.	Maintenance	60
7.	Product Features	67
8.	Troubleshooting	77
	8.1 Safety Caution	77
	8.2 General Troubleshooting	78
	8.3 Outdoor Unit Point Check Function	81
	8.4 Information Inquiry	83
	8.5 Error Diagnosis and Troubleshooting Without Error Code	87
	8.6 Quick Maintenance by Error Code	93
	8.7 Troubleshooting by Error Code	95
	8.8 Check Procedures	125

9.	Indo	oor Unit Disassembly	130
	9.1 Ir	ndoor Unit - Air Handler Type	130
10.	Outo	loor Unit Disassembly	138
11.	Арр	endix	151
	i)	Temperature Sensor Resistance Value Table for T1,T2,T3 and T4 ($^\circ\!C-K$)	152
	ii)	Temperature Sensor Resistance Value Table for TP(for some units) ($^{\circ}C - K$)	153
	iii)	Pressure On Service Port	154

1. Safety Precautuions

1.1 Precautions

To prevent personal injury, or property or unit damage, adhere to all precautionary measures and instructions outlined in this manual. Before servicing a unit, refer to this service manual and its relevant sections.

Failure to adhere to all precautionary measures listed in this section may result in personal injury, damage to the unit or to property, or in extreme cases, death.

- (I) WARNING indicates a potentially hazardous situation which if not avoided could result in serious personal injury, or death.
- CAUTION indicates a potentially hazardous situation which if not avoided could result in minor or moderate personal injury, or unit damage.

1.1.1 In case of Accidents or Emergency

- If a gas leak is suspected, immediately turn off the gas and ventilate the area if a gas leak is suspected before turning the unit on.
- If strange sounds or smoke is detected from the unit, turn the breaker off and disconnect the power supply cable.
- If the unit comes into contact with liquid, contact an authorized service center.
- If liquid from the batteries makes contact with skin or clothing, immediately rinse or wash the area well with clean water.
- Do not insert hands or other objects into the air inlet or outlet while the unit is plugged in.
- Do not operate the unit with wet hands.
- Do not use a remote controller that has previously been exposed to battery damage or battery leakage.

- Clean and ventilate the unit at regular intervals when operating it near a stove or near similar devices.
- Do not use the unit during severe weather conditions. If possible, remove the product from the window before such occurrences.

1.1.2 Pre-Installation and Installation

WARNING

- Use this unit only on a dedicated circuit.
- Damage to the installation area could cause the unit to fall, potentially resulting in personal injury, prop- erty damage, or product failure.
- Only qualified personnel should disassemble, install, remove, or repair the unit.
- Only a qualified electrician should perform electrical work. For more information, contact your dealer, seller, or an authorized service center.

• While unpacking be careful of sharp edges around the unit as well as the edges of the fins on the con- denser and evaporator.

1.1.3 Operation and Maintenance

N WARNING

- Do not use defective or under-rated circuit breakers.
- Ensure the unit is properly grounded and that a dedicated circuit and breaker are installed.
- Do not modify or extend the power cable. Ensure the power cable is secure and not damaged during operation.
- Do not unplug the power supply plug during operation.
- Do not store or use flammable materials near the unit.

- Do not open the inlet grill of the unit during operation.
- Do not touch the electrostatic filter if the unit is equipped with one.
- Do not block the inlet or outlet of air flow to the unit.
- Do not use harsh detergents, solvents, or similar items to clean the unit. Use a soft cloth for cleaning.
- Do not touch the metal parts of the unit when removing the air filter as they are very sharp.
- Do not step on or place anything on the unit or outdoor units.
- Do not drink water drained from the unit
- Avoid direct skin contact with water drained from the unit.

- Do not install or operate the unit for an extended period of time in areas of high humidity or in an environment directly exposing it to sea wind or salt spray.
- Do not install the unit on a defective or damaged installation stand, or in an unsecure location.
- Ensure the unit is installed at a level position
- Do not install the unit where noise or air discharge created by the outdoor unit will negatively impact the environment or nearby residences.
- Do not expose skin directly to the air discharged by the unit for prolonged periods of time.
- Ensure the unit operates in areas water or other liquids.
- Ensure the drain hose is installed correctly to ensure proper water drainage.
- When lifting or transporting the unit, it is recommended that two or more people are used for this task.
- When the unit is not to be used for an extended time, disconnect the power supply or turn off the breaker.

1.2 Information servicing(For flammable materials)

1.2.1 Checks to the area

- Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized.
- For repair to the refrigerating system, the following precautions shall be complied with prior to conducting work on the system.

1.2.2 Work procedure

• Work shall be undertaken under a controlled procedure so as to minimise the risk of a flammable gas or vapour being present while the work is being performed.

1.2.3 Work procedure

- All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out.
- · Work in confined spaces shall be avoided.
- The area around the work space shall be sectioned off. Ensure that the conditions within the area have been made safe by control of flammable material.

1.2.4 Checking for presence of refrigerant

- The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres.
- Ensure that the leak detection equipment being used is suitable for use with flammable refrigerants.

1.2.5 Presence of fire extinguisher

- If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand.
- Have a dry powder or CO2 fire extinguisher adjacent to the charging area.

1.2.6 No ignition sources

- No person carrying out work in relation to a refrigeration system which involves exposing any pipe work that contains or has contained flammable refrigerant shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion.
- All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which flammable refrigerant can possibly be released to the surrounding space.
- Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks.
- NO SMOKING signs shall be displayed.

1.2.7 Ventilated area

• Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

1.2.8 Checks to the refrigeration equipment

- Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt consult the manufacturer's technical department for assistance. The following checks shall be applied to installations using flammable refrigerants:
 - the charge size is in accordance with the room size within which the refrigerant containing parts are installed;
 - the ventilation machinery and outlets are operating adequately and are not obstructed;
 - if an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant; marking to the equipment continues to be visible and legible.
 - · markings and signs that are illegible shall be corrected;
 - refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently

resistant to being corroded or are suitably protected against being so corroded.

1.2.9 Checks to electrical devices

- Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised. Initial safety checks shall include:
- that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- that there no live electrical components and wiring are exposed while charging, recovering or purging the system;
- that there is continuity of earth bonding.

1.2.10 Repairs to sealed components

- During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation.
- Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.

- · Ensure that apparatus is mounted securely.
- Ensure that seals or sealing materials have not degraded such that they no longer serve the purpose of preventing the ingress of flammable atmospheres. Replacement parts shall be in accordance with the manufacturer's specifications.

NOTE: The use of silicon sealant may inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

1.2.11 Repair to intrinsically safe components

• Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use. Intrinsically safe components are the only types that can be worked on while live

in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating.

• Replace components only with parts specified by the manufacturer. Other parts may result in ignition of refrigerant in the atmosphere from a leak.

1.2.12 Cabling

• Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

1.2.13 Detection of flammable refrigerants

• Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

1.2.14 Leak detection methods

• The following leak detection methods are deemed acceptable for systems containing flammable refrigerants. Electronic leak detectors shall be used to detect flammable refrigerants, but the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25 % maximum) is confirmed. Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine

may react with the refrigerant and corrode the copper pipe-work.

- If a leak is suspected, all naked flames shall be removed or extinguished.
- If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the systemremote from the leak. Oxygen free nitrogen (OFN) shall then be purged through the system both before and during the brazing process.

1.2.15 Removal and evacuation

- When breaking into the refrigerant circuit to make repairs or for any other purpose, conventional procedures shall be used. However, it is important that best practice is followed since flammability is a consideration.
- · The following procedure shall be adhered to:
 - · remove refrigerant;
 - purge the circuit with inert gas; evacuate, then purge again with inert gas;
 - open the circuit by cutting or brazing.
- When breaking into the refrigerant circuit to make repairs or for any other purpose, conventional procedures shall be used. However, it is important that best practice is followed since flammability is a consideration.
- The refrigerant charge shall be recovered into the correct recovery cylinders. The system shall be flushed with OFN to render the unit safe. This process may need to be repeated several times. Compressed air or oxygen shall not be used for this task. Flushing shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum. This process shall be repeated until no refrigerant is within the system. When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.
- Ensure that the outlet for the vacuum pump is not close to any ignition sources and there is ventilation available.

1.2.16 Charging procedures

- In addition to conventional charging procedures, the following requirements shall be followed:
 - Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
 - Cylinders shall be kept upright.
 - Ensure that the refrigeration system is earthed prior to charging the system with refrigerant.
 - Label the system when charging is complete (if not already). Extreme care not to overfill the refrigeration system.
 - Prior to recharging the system it shall be pressure tested with OFN. The system shall be leak tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

1.2.17 Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken.

It is essential that electrical power is available before the task is commenced.

- Become familiar with the equipment and its operation. Isolate system electrically.
- Before attempting the procedure ensure that:
 - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - all personal protective equipment is available and being used correctly;
 - the recovery process is supervised at all times by a competent person;
 - recovery equipment and cylinders conform to the appropriate standards.
- Pump down refrigerant system, if possible.
- If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- Make sure that cylinder is situated on the scales before recovery takes place.
- Start the recovery unit and operate in accordance with manufacturer's instructions.
- Do not overfill cylinders. (No more than 80 % volume liquid charge).
- Do not exceed the maximum working pressure of the cylinder, even temporarily.
- When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

1.2.18 Labelling

• Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. Ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

1.2.19 Recovery

- When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.
- When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct numbers of cylinders for holding the total system charge are available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure relief valve and associated shut-off valves in good working order.
- Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.
- The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order.

- Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery
 machine, check that it is in satisfactory working order, has been properly maintained and that any associated
 electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if
 in doubt.
- The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant Waste Transfer Note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.
- If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant.

The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely

2. Model Reference

2.1 Model Reference

Refer to the following table to determine the specific indoor and outdoor unit model number of your purchased equipment.

	Capacity (Btu/h)	Indoor Unit Model	Outdoor Unit Model	Power Supply
	36k	EAHAEC-36	ESCA16H-36	1Db 208/220\/a, 60Hz
ſ	60k	EAHAEC-60	ESCA16H-60	1Ph, 208/230V~, 60Hz

2.2 External Appearance

2.2.1 Indoor Unit (Air Handler)



2.2.2 Outdoor Unit (Double Fan)



3. Indoor Unit-Air Handler

3.1 Feature

Full Multi-position installation

• This AHU is capable of upflow, downflow, horizontal left, or horizontal right configurations.

Installation Convenience

• It simplifies the airflow volume adjustment process and saves lots of installation efforts. The traditional adjustment method needs the installers to manually set the motor speed, according to the installation instruction and ducting design. It takes lots of time if this thing doesn't go well and decreases the marginal profits.

Easy Fault Code Checking

- Thanks to advanced mutual data communication technology, the AHU system can intelligently selfdetecting the failure cause and generate a corresponding code.
- Installer or user can easily check the fault code displayed on the electric function board by just opening the lid.
- It helps you proactively determine the failure cause, prepare for repairing parts ahead of field maintenance work, greatly improve the work efficiency.


Nitrogen Charge and Leakage Check Valve

• Ecoer AHU indoor unit is standard with Nitrogen injection to maintain positive pressure of the indoor unit. It is easy to check from the check valve whether there is leakeage in the evaporator or not.

Automatic Airflow Adjustment

• During the operation, when the dust filter or evaporator is clogged with dust, the load of the system and motor torque increases. The MPU(microprocessor) on the unit can detect this change and adjust the fan speed to keep the CFM stable.


3.2 Dimensional Drawings




	Model	36	ik	60)k
NO.	Dimensions	inch	mm	inch	mm
А	Model Height	49	1245	53	1346
В	Model Width	21	534	24-1/2	622
С	Supply Air Opening Width	19-1/8	486	22-5/8	575
D	Return Air Opening Width	18-5/8	473	22-1/8	562
E	E Model Depth		534	21	534
F	Supply Air Opening Depth	10-1/4	260	10-1/4	260
G	Return Air Opening Depth	18-3/4	476	18-3/4	476
н	Supply Air Opening Clearance		24	15/16	24
I	Return Air Opening Side Clearance		32	1-1/8	28
J	Return Air Opening Front Clearance	1-5/8	41	1-5/8	41
к	Return Air Opening Back Clearance	5/8	16	3/4	19

Manufacturer reserves the right to change specifications or designs without notice.

3.3 Part names



3.4 Service Place



3.5 Accessories

The air conditioning system comes with the following accessories. Use all of the installation parts and accessories to in-stall the air conditioner. Improper installation may result in water leakage, electrical shock and fire, or equipment failure.


Name		Shape	Quantity
Ma	nual	Minjut	3
Remote	controller		1
Ва	ttery	ø	2
Transfer	connector		2
Wired remo	ote controller		1
Fasten belt			2
Sponge			4
Flare nut			2
	Drain joint		1
Packed with the outdoor unit Transfer connector		\bigcirc	1
			2


Note:The remote control is only used to adjust the parameters.

Installation of Electric Auxiliary Heat Module(for some models)(not supplied)

Name	Shape	Quantity
Owner's manual& Installation manual	Manual	2
Seal sponge		1
Screw		7
Rubber cap		1
Electric auxiliary heating wiring diagram	/	1
Air switch label	/	1


3.6 Fan Performance





Manufacturer reserves the right to change specifications or designs without notice.

3.7 Noise Criterion Curves



Notes:

-Sound measured at 1.5m/4.92ft away from the center of the unit.


-Data is valid at free field condition

-Data is valid at nominal operation condition

-Reference acoustic pressure 0dB = 20µPa

-Sound level will vary depending on a range of factors such as the construction -(acoustic absorption coefficient) of particular room in which the equipment is installed.

-The operating conditions are assumed to be standard.



3.8 Electrical Characteristics


Capacity	Capacity (Btu/h)		60k hyper Heat
	Phase	1	1
Power (indoor)	Frequency And Volt	208/230V,60Hz	
	Phase	1	1
Power (Outdoor)	Frequency And Volt	208/230	/,60Hz
	Indoor unit(A)	15	15
Max. Fuse	Outdoor unit(A)	50	60
	Line quantity	3	3
Indoor unit Power line	Line diameter(AWG)	16/1.5mm ²	16/1.5mm²
	Line quantity	3	3
Outdoor unit Power line	Line diameter(AWG)	8/8.0mm²	8/8.0mm²
	Line quantity	2	2
Outdoor-indoor Signal line	Line diameter(AWG)	20/0.5mm ²	20/0.5mm ²
	Line quantity		
Thermostat Signal line	Line diameter(AWG)	18/1.0mm ²	18/1.0mm ²

3.9 Electrical Wiring Diagrams

IDU Capacity (Btu/h)	IDU Wiring Diagram
36k/60k	16023000011626

Abbreviation	Paraphrase	
Y/G	Yellow-Green Conductor	
CAP	Indoor Fan Capacitor	
FAN	Indoor Fan Motor	
ECM	Indoor ECM Motor	
TO CCM Comm.Bus	Central Controller	
T1 Indoor Room Temperature Sense		
T2A	Indoor Coil Inlet Temperature Sensor	
T2B	Indoor Coil Outlet Temperature Sensor	
T2	Indoor Coil Temperature Sensor	

Indoor Unit Wiring Diagram



3.10 Electrical Wiring Diagrams

3.10.1 Micro-Switch Introduce:




A ALARM terminal port CN33:

1.Provide the terminal port to connect ALARM, but no voltage of the terminal port, the power from the ALARM system (not from the unit).


2.Although design voltage can support higher voltage, but we strongly ask you connect the power less than 24V, current less than 0.5A.

3. When the unit occurs the problem , the relay would be closed , then ALARM works.



JDQ-SS-112V/5A-O-T85-P35-B-02

3.10.1 Micro-Switch Introduce:




B.For remote control (ON-OFF) terminal port CN2 and short connector of JR1

- 1. Remove the short connector of JR1 when you use ON-OFF function;
- 2. When remote switch off (OPEN); the unit would be off;
- 3. When remote switch on (CLOSE); the unit would be on;
- 4. When close/open the remote switch, the unit would be responded the demand within 2 seconds;

5. When the remote switch on, you can use remote controller/ wire controller to select the mode what you want; when the remote switch off, the unit would not respond the demand from remote controller/wire controller.

when the remote switch off, but the remote controller/wire controller are on, CP code would be shown on the display board.

6. The voltage of the port is 12V DC, design Max. current is 5mA.



3.10.2 Micro-Switch Introduce:



FOR SETTING NETADDRESS				
S1+S2	€ ^{F07} ,23 S S S C C C C C C C C C C C C C C C C	UN US 00 00 00 00 00 00 00 00 00 00 00 00 00	¢F 0 7,3 ON OS 06,4 OF 0,8 L 0,9 C 0,0 C 0	₩ 00 00 00 00 00 00 00 00 00 00 00 00 00
CODE	0~F	0~F	0~F	0~F
NETADDRESS	0~15	16~31	32~47	48~63
FACTORY SETTING				

A. Micro-switch S1 and dial-switch S2 are for address setting when you want to control this unit by a central

controller. Range: 00-63

4F010	5
6812	
STATENOIS STATE	

FOR SETTING POWER(DC MOTOR MODEL ONLY)				
ENC1	13450 50084 80084	4500 4500 4500 4500 4500 4500 4500 4500		
CODE	8	А		
POWER	105	160		
FACTORY SETTING ACCORDING TO RELATED MODEL.				

B. Dial-switch ENC1: The indoor PCB is universal designed for whole series units(36K & 60K). This ENC1 setting will tell the main program what size the unit is.

NOTE: Usually there is glue on it because the switch position cannot be changed at random unless you want to use this PCB as a spare part to use in another unit. Then you have to select the right position to match the size of the unit.

"105" means 10.5kW(36K), "160" means 16kW(60K)

234	56189 189			2 3 4	ON 806	SH4	DN SCE 1 2 3 4
		24\/	THERMOSTATS	SETTING			
	S3 83 68 L9	SW1 0N 1 2 3 4	SW2 ON 1 2 3 4	SW3 0N 1 2 3 4	SW4 0N 1 2 3 4	S4	
CODE	0~F	ON~OFF	ON~OFF	ON~OFF	ON~OFF	ON~OFF	
FACTORY SETTING				\checkmark	\checkmark	\checkmark	

C. Function DIP Switch Settings

Dial code	Features	ON	OFF(default)	
S3(ENC 2)	Electric heating turns on outdoor T4 temperature	0 means that the temperature protection is not turned on, 1-F is -20-8°C (-4-46°F) respectively, and each scale represents 2°C(3.6°F)		
SW1-1	Whether 24V control selection	Yes	No	
SW1-2	Cold wind protection option	No	Yes	
SW1-3	Single cooling / heating and cooling options	Cooling	heating and cooling	
SW1-4	Set machine/single internal machine selection	Indoor unit	Kit	

Manufacturer reserves the right to change specifications or designs without notice.

SW2-1	The first group controls the electric heating to turn on the temperature difference	1.8°F	3.6 °F
SW2-2	Whether the electric heating is delayed	Yes	No
SW2-3	Electric auxiliary heating delay start time	30min	15min
SW2-4	Electric heating/compressor allow opening limit	Compressor allowed to operate to low limit set by ENC 2	Electric heating allowed to operate to high limit set by ENC
SW3-1	Continuous running time when the set temperature of 1.8°F is not reached	E-square value(0.5 hour)	1.5 hours
SW3-2	Cooling and heating Y2 signal setting temperature adjustment value A	1.8°F	3.6 °F
SW3-3	Hysteresis of the second group of electric heating	3.6 °F	5.4 °F
SW3-4	Reserve	/	/
S4-1	Default ON	Short circuit W1 and W2	W1, W2 separate
S4-2	Default ON	DH is off by default	DH on

SW4-1	000 is the default
SW4-2	000/001/010/011/100/101/110/111, internal machines
SW4-3	with different abilities, electric heating and PSC classification for use

NOTICE: The SW4 DIP switch is only for Certified service technicians to debug and use, please do not touch it.


4. Outdoor Unit

4.1 Dimensional Drawings

Please check the corresponding dimensional drawing according to the panel plate.


ODU Model	Panel Plate
36K	E30
60K	E30

Panel Plate E30



	Outdoor Unit Dimension						Mounting Dimension			
Model	w			н		D	A		В	
	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch
36K	952	37-1/2	1333	52-1/2	415	16-11/32	634	24-35/36	404	15-29/32
60K	952	37-1/2	1333	52-1/2	415	16-11/32	634	24-35/36	404	15-29/32

4.2 Service Place




4.3 Capacity Correction Factor for Height Difference

Capacity (Btu/h)	36k		Pipe Length (m/ft)					
	Cooling		7.5/24.6	15/49.2	25/82	35/114.8	50/164	65/213.3
		30/98.4				0.889	0.850	0.812
	Indoor	20/65.6			0.924	0.898	0.859	0.820
	Upper than	10/32.8		0.959	0.933	0.907	0.868	0.828
Height	Outdoor	5/16.4	0.995	0.969	0.942	0.916	0.876	0.837
difference H		0	1.000	0.974	0.947	0.921	0.881	0.841
(m)		-5/-16.4	1.000	0.974	0.947	0.921	0.881	0.841
	Outdoor	-10/-32.8		0.974	0.947	0.921	0.881	0.841
	Upper than	-20/-65.6			0.947	0.921	0.881	0.841
	Indoor	-30/-98.4				0.921	0.881	0.841
	Heating		7.5/24.6	15/49.2	25/82	35/114.8	50/164	65/213.3
		30/98.4				0.964	0.945	0.927
	Indoor Upper	20/65.6			0.976	0.964	0.945	0.927
	than	10/32.8		0.988	0.976	0.964	0.945	0.927
Height	Outdoor	5/16.4	1.000	0.988	0.976	0.964	0.945	0.927
difference H		0	1.000	0.988	0.976	0.964	0.945	0.927
(m)		-5/-16.4	0.992	0.980	0.968	0.956	0.938	0.920
	Outdoor Upper than	-10/-32.8		0.972	0.960	0.948	0.930	0.912
		-20/-65.6			0.952	0.941	0.923	0.905
	Indoor	-30/-98.4				0.933	0.915	0.898
Capacity (Btu/h)	60k				Pipe Len	gth (m/ft)		
	60k Cooling		7.5/24.6	15/49.2	Pipe Len 25/82		50/164	65/213.3
	Cooling	30/98.4	7.5/24.6	15/49.2			50/164 0.823	65/213.3 0.775
	Cooling	30/98.4 20/65.6	7.5/24.6	15/49.2		35/114.8		
	Cooling Indoor Upper		7.5/24.6	15/49.2	25/82	35/114.8 0.870	0.823	0.775
(Btu/h) Height	Cooling	20/65.6	7.5/24.6	\leq	25/82 0.911	35/114.8 0.870 0.879	0.823 0.831	0.775 0.783
(Btu/h) Height difference H	Cooling Indoor Upper than	20/65.6 10/32.8		0.953	25/82 0.911 0.920	35/114.8 0.870 0.879 0.888	0.823 0.831 0.840	0.775 0.783 0.791
(Btu/h) Height	Cooling Indoor Upper than Outdoor	20/65.6 10/32.8 5/16.4	0.995	0.953 0.962	25/82 0.911 0.920 0.930	35/114.8 0.870 0.879 0.888 0.897	0.823 0.831 0.840 0.848	0.775 0.783 0.791 0.799
(Btu/h) Height difference H	Cooling Indoor Upper than Outdoor	20/65.6 10/32.8 5/16.4 0	0.995	0.953 0.962 0.967	25/82 0.911 0.920 0.930 0.934	35/114.8 0.870 0.879 0.888 0.897 0.902	0.823 0.831 0.840 0.848 0.852	0.775 0.783 0.791 0.799 0.803
(Btu/h) Height difference H	Cooling Indoor Upper than Outdoor Outdoor Upper	20/65.6 10/32.8 5/16.4 0 -5/-16.4	0.995	0.953 0.962 0.967 0.967	25/82 0.911 0.920 0.930 0.934 0.934	35/114.8 0.870 0.879 0.888 0.897 0.902 0.902	0.823 0.831 0.840 0.848 0.852 0.852	0.775 0.783 0.791 0.799 0.803 0.803
(Btu/h) Height difference H	Cooling Indoor Upper than Outdoor	20/65.6 10/32.8 5/16.4 0 -5/-16.4 -10/-32.8	0.995	0.953 0.962 0.967 0.967	25/82 0.911 0.920 0.930 0.934 0.934 0.934	35/114.8 0.870 0.879 0.888 0.897 0.902 0.902 0.902	0.823 0.831 0.840 0.848 0.852 0.852 0.852	0.775 0.783 0.791 0.799 0.803 0.803 0.803
(Btu/h) Height difference H	Cooling Indoor Upper than Outdoor Upper than	20/65.6 10/32.8 5/16.4 0 -5/-16.4 -10/-32.8 -20/-65.6	0.995	0.953 0.962 0.967 0.967	25/82 0.911 0.920 0.930 0.934 0.934 0.934	35/114.8 0.870 0.879 0.888 0.897 0.902 0.902 0.902 0.902	0.823 0.831 0.840 0.848 0.852 0.852 0.852 0.852	0.775 0.783 0.791 0.799 0.803 0.803 0.803 0.803
(Btu/h) Height difference H	Cooling Indoor Upper than Outdoor Upper than	20/65.6 10/32.8 5/16.4 0 -5/-16.4 -10/-32.8 -20/-65.6	0.995	0.953 0.962 0.967 0.967	25/82 0.911 0.920 0.930 0.934 0.934 0.934	35/114.8 0.870 0.879 0.888 0.897 0.902 0.902 0.902 0.902	0.823 0.831 0.840 0.848 0.852 0.852 0.852 0.852	0.775 0.783 0.791 0.799 0.803 0.803 0.803 0.803
(Btu/h) Height difference H	Cooling Indoor Upper than Outdoor Upper than Indoor Heating	20/65.6 10/32.8 5/16.4 0 -5/-16.4 -10/-32.8 -20/-65.6	0.995 1.000 1.000	0.953 0.962 0.967 0.967 0.967	25/82 0.911 0.920 0.930 0.934 0.934 0.934 0.934	35/114.8 0.870 0.879 0.888 0.897 0.902 0.902 0.902 0.902 0.902	0.823 0.831 0.840 0.848 0.852 0.852 0.852 0.852 0.852	0.775 0.783 0.791 0.799 0.803 0.803 0.803 0.803 0.803
(Btu/h) Height difference H	Cooling Indoor Upper than Outdoor Upper than Indoor Heating Indoor	20/65.6 10/32.8 5/16.4 0 -5/-16.4 -10/-32.8 -20/-65.6 -30/-98.4	0.995 1.000 1.000	0.953 0.962 0.967 0.967 0.967	25/82 0.911 0.920 0.930 0.934 0.934 0.934 0.934	35/114.8 0.870 0.879 0.888 0.897 0.902 0.902 0.902 0.902 0.902 0.902	0.823 0.831 0.840 0.848 0.852 0.852 0.852 0.852 0.852 0.852	0.775 0.783 0.791 0.799 0.803 0.803 0.803 0.803 0.803 0.803
(Btu/h) Height difference H	Cooling Indoor Upper than Outdoor Upper than Indoor Heating	20/65.6 10/32.8 5/16.4 0 -5/-16.4 -10/-32.8 -20/-65.6 -30/-98.4 30/98.4	0.995 1.000 1.000	0.953 0.962 0.967 0.967 0.967	25/82 0.911 0.920 0.930 0.934 0.934 0.934 0.934 0.934	35/114.8 0.870 0.879 0.888 0.897 0.902 0.902 0.902 0.902 0.902 0.902 35/114.8 0.955	0.823 0.831 0.840 0.848 0.852 0.852 0.852 0.852 0.852 0.852 0.852	0.775 0.783 0.791 0.799 0.803 0.803 0.803 0.803 0.803 0.803 0.803 0.803
(Btu/h) Height difference H (m) Height	Cooling Indoor Upper than Outdoor Upper than Indoor Heating Indoor Upper	20/65.6 10/32.8 5/16.4 0 -5/-16.4 -10/-32.8 -20/-65.6 -30/-98.4 20/65.6	0.995 1.000 1.000	0.953 0.962 0.967 0.967 0.967 15/49.2	25/82 0.911 0.920 0.930 0.934 0.934 0.934 0.934 25/82 0.970	35/114.8 0.870 0.879 0.888 0.897 0.902 0.902 0.902 0.902 0.902 0.902 35/114.8 0.955 0.955	0.823 0.831 0.840 0.848 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852	0.775 0.783 0.791 0.799 0.803 0.803 0.803 0.803 0.803 0.803 65/213.3 0.909 0.909
(Btu/h) Height difference H (m) Height difference H	Cooling Indoor Upper than Outdoor Upper than Indoor Heating Indoor Upper than	20/65.6 10/32.8 5/16.4 0 -5/-16.4 -10/-32.8 -20/-65.6 -30/-98.4 30/98.4 20/65.6 10/32.8	0.995 1.000 1.000 7.5/24.6	0.953 0.962 0.967 0.967 0.967 15/49.2 0.985	25/82 0.911 0.920 0.930 0.934 0.934 0.934 0.934 0.934 0.934 0.934 0.934	35/114.8 0.870 0.879 0.888 0.897 0.902 0.902 0.902 0.902 0.902 35/114.8 0.955 0.955	0.823 0.831 0.840 0.848 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852	0.775 0.783 0.791 0.799 0.803 0.803 0.803 0.803 0.803 0.803 0.803 0.803 0.803 0.803 0.803
(Btu/h) Height difference H (m) Height	Cooling Indoor Upper than Outdoor Upper than Indoor Heating Indoor Upper than Outdoor	20/65.6 10/32.8 5/16.4 0 -5/-16.4 -10/-32.8 -20/-65.6 -30/-98.4 20/65.6 10/32.8 5/16.4	0.995 1.000 1.000 7.5/24.6 1.000	0.953 0.962 0.967 0.967 0.967 15/49.2 0.985 0.985	25/82 0.911 0.920 0.930 0.934 0.934 0.934 0.934 0.934 25/82 0.970 0.970 0.970	35/114.8 0.870 0.879 0.888 0.897 0.902 0.902 0.902 0.902 0.902 0.902 35/114.8 0.955 0.955 0.955	0.823 0.831 0.840 0.848 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.932 0.932	0.775 0.783 0.791 0.799 0.803 0.803 0.803 0.803 0.803 0.803 65/213.3 0.909 0.909 0.909 0.909
(Btu/h) Height difference H (m) Height difference H	Cooling Indoor Upper than Outdoor Upper than Indoor Heating Heating Indoor Upper than Outdoor	20/65.6 10/32.8 5/16.4 0 -5/-16.4 -10/-32.8 -20/-65.6 -30/-98.4 20/65.6 10/32.8 5/16.4 0	0.995 1.000 1.000 7.5/24.6 1.000 1.000	0.953 0.962 0.967 0.967 0.967 15/49.2 0.985 0.985 0.985	25/82 0.911 0.920 0.930 0.934 0.934 0.934 0.934 0.934 0.934 0.934 0.934 0.970 0.970 0.970 0.970 0.970	35/114.8 0.870 0.879 0.888 0.897 0.902 0.902 0.902 0.902 0.902 0.902 35/114.8 0.955 0.955 0.955 0.955	0.823 0.831 0.840 0.848 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.932 0.932 0.932 0.932 0.932	0.775 0.783 0.791 0.799 0.803 0.803 0.803 0.803 0.803 0.803 0.803 0.803 0.803 0.803 0.803 0.909 0.909 0.909 0.909 0.909
(Btu/h) Height difference H (m) Height difference H	Cooling Indoor Upper than Outdoor Upper than Indoor Heating Indoor Upper than Outdoor	20/65.6 10/32.8 5/16.4 0 -5/-16.4 -10/-32.8 -20/-65.6 -30/-98.4 20/65.6 10/32.8 5/16.4 0 -5/-16.4	0.995 1.000 1.000 7.5/24.6 1.000 1.000	0.953 0.962 0.967 0.967 0.967 15/49.2 15/49.2 0.985 0.985 0.985 0.977	25/82 0.911 0.920 0.930 0.934 0.934 0.934 0.934 0.934 25/82 0.970 0.970 0.970 0.970 0.970 0.970 0.970	35/114.8 0.870 0.879 0.888 0.897 0.902 0.902 0.902 0.902 0.902 0.902 0.902 0.902 0.905 0.955 0.955 0.955 0.955 0.955	0.823 0.831 0.840 0.848 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.852 0.932 0.932 0.932 0.932 0.932 0.932	0.775 0.783 0.791 0.799 0.803 0.803 0.803 0.803 0.803 0.803 65/213.3 0.909 0.909 0.909 0.909 0.909 0.909

Manufacturer reserves the right to change specifications or designs without notice.

4.4 Noise Criterion Curves



1.0m/3.28ft

Note: $H= 0.5 \times height of outdoor unit$

Notes:

-Sound measured at 1.0m/3.25ft away from the center of the unit.


-Data is valid at free field condition

-Data is valid at nominal operation condition

-Reference acoustic pressure 0dB=20µPa


-Sound level will vary depending on arrange of factors such as the construction (acoustic absorption coefficient) of particular room in which the equipment is installed.

-The operating conditions are assumed to be standard.



Manufacturer reserves the right to change specifications or designs without notice.

4.5 Refrigerant Cycle Diagrams




Model No.	Pipe Size(Dia mm(inch	,	Piping length(m/ft)		Elevation(m/ft)		Additional Refrigerant
Model No.	Gas	Liquid	Rated	Max.	Rated	Max.	· · · · · · · · · · · · · · · · · · ·
36K	19(3/4)	9.52(3/8)	7.5/24.6	65/213	0	30/98.4	
60K	22(7/8)	9.52(3/8)	7.5/24.6	65/213	0	30/98.4	65g/m(0.69oz/ft)


4.6 Electrical Wiring Diagrams

ODU Model	ODU Wiring Diagram	
36K	16022000036969	
60K		

ODU Model	ODU Main Printed Circuit Board	Inverter Module Printed Board	24V Printed Board	
36K	4740000007004	4740000040040	17122000054047	
60K	17122000037804	17122000042012		


Outdoor Unit Wiring Diagram





Outdoor Unit Main Printed Circuit Board Diagram


No.	Name	CN#	Meaning
1	Power Supply	CN1	L1_in: connect to L1-line (230V AC input)
		CN3	L2_in: connect to L2-line (230V AC input)
2	TP	CN8	Exhaust temp. sensor TP
3	TESTPORT	CN35	Used for testing
4	HEAT1	CN19/CN20	Connect to chassis heater, 208-230V AC when is ON
5	HEAT2	CN24/CN25	Connect to compressor heater, 208-230V AC when is ON
6	RV(4-WAY)	CN17/CN18	Connect to Reversing valve(4 way valve), 208-230V AC when is ON.
7	AC-FAN2	CN31/CN36/CN28	Connect to AC fan2
8	AC-FAN1	CN27/CN34/CN32	Connect to AC fan1
9	H-PRO/L-PRO	CN10	Connect to low&high pressure switch
10	Compressor Top	CN14	Connect to compressor top temperature sensor
11	T2B	CN11	Connect to pipe temp. sensor T2B
12	T4 T3	CN9	Connect to pipe temp. sensor T3, ambient temp. sensor T4
13	PMV	CN15/CN23/CN26/ CN30/CN33/CN38	Connect to Electric Expansion Valve(A~F)
14	/	CN6	Connect to IPM&PFC board CN9
15	PQE	CN22	Communication to indoor unit



Outdoor Unit Inverter Module Printed Board Diagram

No.	Name	CN#	Meaning
1	Power Supply	CN3	connect to main board L-Out
		CN2	connect to main board N-Out
2	/	CN9	connect to main board CN6
3	FAN_DC	FAN_1/FAN_2	connect to outdoor DC fan 1& DC fan 2
		U1	
4	CN_COMP	V1	connect to compressor
		W1	

Note: This section is for reference only. Please take practicality as standard.




Outdoor Unit 24V Printed Board Diagram

No.	Name	CN#	Meaning
1	/	CN5	connect to one-way solenoid valve
2	/	CN9	connect to pressure sensor (5VDC)
3	/	CN28	connect to electric expansion valve (12VDC)
4	TESTPORT	CN45	used for testing (5VDC)
5	/	CN11	connect to suction temp. sensor, cold plate temp. sensor (5VDC)
6	H-PRO	CN38	connect to high pressure switch (5VDC)
7	Power Supply	CN3	connect to main board L-Out
		CN4	connect to main board N-Out

Note: This section is for reference only. Please take practicality as standard.

5. Installation

5.1 Installation Overview





Perform a test run


5.2 Location selection

5.2.1 Unit location selection can refer to installation manual

5.2.2 DO NOT install the unit in the following locations:

- Where oil drilling or fracking is taking place.
- Costal areas with high salt content in the air.
- Areas with caustic gases in the air, such as near hot springs.
- · Areas with power fluctuations, such as factories.
- Enclosed spaces, such as cabinets.
- Rooms with high humidity, such as bathrooms or laundry rooms.
- Areas with strong electromagnetic waves and areas that store flammable materials or gas.
- If possible, DO NOT install the unit where it is exposed to direct sunlight.


5.2.3 The minimum distance between the outdoor unit and walls described in the installation guide does not apply to airtight rooms. Be sure to keep the unit unobstructed in at least two of the three directions (M, N, P)




5.2.4 Rows of series installation

The relations between H, A and L are as follows.

	L	А	
L≤H	L ≤ 1/2H	25 cm / 9.8" or more	
LSH	1/2H < L ≤ H	30 cm / 11.8" or more	
L>H	Can not be installed		






DO NOT install the rows of series like above figure.

5.2.5 If the unit is exposed to heavy wind:

• Install unit so that air outlet fan is at a 90° angle to the direction of the wind. If needed, build a barrier in front of the unit to protect it from extremely heavy winds.




5.2.6 If the unit is frequently exposed to heavy rain or snow:

Build a shelter above the unit to protect it from the rain or snow. Be careful not to obstruct air flow around the unit.

5.2.7 If the unit is frequently exposed to salty air (seaside):

Use outdoor unit that is specially designed to resist corrosion.

5.3 Indoor Unit Installation(AHU)




Vertical installation

When installed vertically (upward or downward), the lower end of the air outlet needs to be connected to the L-shaped metal air duct and fastened by screws.




5.3.2 Installation place





5.3.3 Install the main body

The unit may be installed in one of the upflow, downflow, horizontal left or horizontal right orientations.

Vertical installation







Horizontal installation



NOTE: For installation, an drain pan(not supplied) must be installed.

At least 18in(46cm)



Note: Vertical up and horizontal left installation does not need to change the direction of evaporator.

Regular installation instructions


Please follow these steps to perform Vertical up installation and Horizontal left installation:

- 1. Open the upper cover.
- 2. Open the cover of the electronic control box.
- 3. Connect the wire according to the wiring diagram.
- 4. Connect the pipes.
- 5. Install the drainage pipes

Reversing installation instructions


For the Horizontal left installation and vertical down installation, the direction of the evaporator should be changed and the drain pan should be removed first. Please do it according to the following steps:


1. Remove the fixed plate of the filter ,then take the filter off.



2. Remove the upper cover assembly.

3. Remove evaporator cover plate.






4. Unplug temperature sensors T1,T2,T2A,T2B and electronic expansion valve(EEV) from the control board.

T1: Room temperature sensor


T2: Evaporator central temperature sensor

T2A: Evaporator input temperature sensor(only available for some models)

T2B: Evaporator output temperature sensor(only available for some models)




6. Take out the evaporator and drain pan and rotate 180°.




7. Adjust the position of the mounting parts.

5. Remove T1,T2,T2A,T2B sensor,EEV wire ties.




8. Reinstall the evaporator and drain pan.



Note: The wire body needs to pass through the wire groove from the drain pan and be stuck on the hook of the drain pan. 10. The evaporator is assembled in place.


42/157

www.ecoer.com







Replace foam gasket over wires.




11. Reinstall evaporator cover plate.



- 12. Connect the wire according to the wiring diagram.
- 13. Reassemble the upper cover.



- 14. Reinstall the filter and filter cover plate.
- 15. Connect the pipes.
- 16. Install the drainage pipes.



5.3.4 Install the Electric Auxiliary Heat Module

Name	Shape	Quantity
Manual	Manual	2
Foam gasket		1
Screws		7
Silicone breaker cover	et la la	1
Electric auxiliary heating wiring diagram	/	1
Circuit breaker label	/	1

Accessories

NOTE:

Installation must be performed by an authorized dealer or specialist. Please make necessary protection when installing the unit.

Specification series of electric auxiliary heat module: 8kW,10kW, 15kw, 20kW.

The electric auxiliary heat module is only used for installation on the AHU indoor unit.


If the unit needs to be equipped with electric auxiliary heat module, please check the electric auxiliary heat module specification that can be matched with the unit first to avoid unnecessary consequences caused by improper matching.

Selection and matching of internal machine and electric auxiliary heating components.


MODEL (Btu./h)	8kW	10kW	15kW	20kW
36K	Y	Y	Y	Y
60K	-	Y	Y	Y

Electric Auxiliary Heat Module installation and wiring operation:


1. Remove the upper cover and use professional tools to remove the knock-out holes of the upper cover.




2. Remove the terminal block and power cord, loosen the screws, and remove the electric auxiliary heating cover.




3. Install the electric auxiliary heating assembly into the chassis shell from the front, and note that the front end needs to be inserted into the shell assembly hole.



4. Tighten the mounting screws.



- 5. Wiring according to the wiring nameplate.
- 6. Tape the wiring diagram to the inside cover wiring is completed for future reference and maintenance.
- 7. Install the upper cover.
- 8. Install circuit breaker cover.



9. After installing the electric auxiliary heat module, apply the circuit breaker label near the silicone breaker cover that was just applied.

After the electric heating wiring is connected, please confirm before power on:

- · Check all wiring and ensure reliable connection of wire body.
- · Check the electric heating fixing screw, and the screw is fixed reliably.
- The size selection of power wire meets the power supply requirements.

Specifications	Number of circuit breakers	Number of relays	Number of power cord groups	Number of power cord grouding screws
8kW	1	2	2	2
10kW	1	2	2	2
15kW	2	3	3	3
20kW	2	4	3	3

NOTE:


- Electric auxiliary heating wiring diagram packed with the accessories.
- If branch circuit wire length exceeds 100 ft, consult NEC 210-19a to determine maximum wire length. Use 2% voltage drop.

Auxiliary Heater Electrical Data


Heater part	Heater	Internal	CIRCUIT 1		CIRCUIT 2		CIRCUIT 3				
No.	kW	Circuit Protection	Heater Amps	MCA (1)	MOCP (2)	Heater Amps	MCA (1)	MOCP (2)	Heater Amps	MCA (1)	MOCP (2)
EAH- 08B(UL)	8	Ckt Bkr	28.8/32.0	37.0/42.0	40.0/45.0	/	/	/	/	/	/
EAH- 10B(UL)	10	Ckt Bkr	36.0/40.0	46.0/53.0	50.0/60.0	/	/	/	/	/	/
EAH- 15B(UL)	15	Ckt Bkr	18.0/20.0	23.0/27.0	25.0/30.0	36.0/40.0	46.0/53.0	50.0/60.0	/	/	/
EAH- 20B(UL)	20	Ckt Bkr	36.0/40.0	46.0/53.0	50.0/60.0	36.0/40.0	46.0/53.0	50.0/60.0	/	/	/

5.4 Outdoor Unit Installation


5.4.1 Service space for outdoor unit




5.4.2 Bolt pitch



5.4.3 Install Outdoor Unit





Caution

Since the gravity center of the unit is not at its physical center, so please be careful when lifting it with a sling.

Never hold the inlet of the outdoor unit to prevent it from deforming.

Do not touch the fan with hands or other objects.

Do not lean it more than 45, and do not lay it sidelong.

Make concrete foundation according to the specifications of the outdoor units.

Fasten the feet of this unit with bolts firmly to prevent it from collapsing in case of earthquake or strong wind.

5.5 Drainage Pipe Installation

Install the drainage pipe as shown below and take measures against condensation. Improperly installation could lead to leakage and eventually wet furniture and belongings.

5.5.1 Installation principle

- · Ensure at least 1/100 slope of the drainage pipe
- · Adopt suitable pipe diameter
- Adopt nearby condensate water discharge

5.5.2 Key points of drainage water pipe installation

- 1. Considering the pipeline route and elevation.
 - Before installing condensate water pipeline, determine its route and elevation to avoid intersection with other pipelines and ensure slope is straight.
- 2. Drainage pipe selection
 - · The drainage pipe diameter shall not small than the drain hose of indoor unit.
 - According to the water flowrate and drainage pipe slope to choose the suitable pipe, the water flow- rate is decided by the capacity of indoor unit.

Relationship between water flowrate and capacity of indoor unit

Capacity (kBtu/h)	Water flowrate (I/h)
36	8
60	14

According to the left table to calculate the total water flowrate for the confluence pipe selection.

PVC pipe	Reference value of inner diameter of pipe		wable iter flowrate(l/h)	Remark
	(mm)	Slope 1/50	Slope 1/100	
PVC25	20	39	27	
PVC32	25	70	50	For branch pipe
PVC40	31	125	88	
PVC50	40	247	175	Could be used for confluence pipe
PVC63	51	473	334	

For horizontal drainage pipe (The following table is for reference)


Attention: Adopt PVC40 or bigger pipe to be the main pipe.

For Vertical drainage pipe (The following table is for reference)


PVC pipe	Reference value of inner diameter of pipe (mm)	Allowable maximum water flowrate (l/h)	Remark	
PVC25	20	220	E. J. J. J. J. J.	
PVC32	25	410	For branch pipe	
PVC40	31	730		
PVC50	40	1440	Could be used for	
PVC63	51	2760	Could be used for confluence pipe	
PVC75	67	5710		
PVC90	77	8280		

Attention: Adopt PVC40 or bigger pipe to be the main pipe.

- 3. Individual design of drainage pipe system
 - The drainage pipe of air conditioner shall be installed separately with other sewage pipe, rainwater pipe and drainage pipe in building.
 - The drainage pipe of the indoor unit with water pump should be apart from the one without water pump.
- 4. Supporter gap of drainage pipe
 - In general, the supporter gap of the drainage pipe horizontal pipe and vertical pipe is respectively 1m~1.5m and 1.5m~2.0m.
 - Each vertical pipe shall be equipped with not less than two hangers.
 - Overlarge hanger gap for horizontal pipe shall create bending, thus leading to air block.




5. The horizontal pipe layout should avoid converse flow or bad flow



• The false installation will cause converse water flow and the slope of the branch pipe can not be ad-justed.


6. Water storage pipe setting

• If the indoor unit has high extra static pressure and without water pump to elevate the condensate water, such as high extra static pressure duct unit , the water storage pipe should be set to avoid converse flow or blow water phenomena.



7. Blowhole setting

- For the concentrated drainage pipe system, there should design a blowhole at the highest point of main pipe to ensure the condensate water discharge smoothly.
- The air outlet shall face down to prevent dirt entering pipe.
- · Each indoor unit of the system should be installed it.
- The installation should be considering the convenience for future cleaning.



8. The end of drainage pipe shall not contact with ground directly.

5.5.3 Insulation work of drainage pipe

Refer the introduction to the insulation engineering parts on page 53.

5.6 Refrigerant Pipe Installation

5.6.1 Maximum length and drop height

Ensure that the length of the refrigerant pipe, the number of bends, and the drop height between the indoor and outdoor units meets the requirements shown in the following table.

Capacity (kBtu/h)	Max. Length (m/ft)	Max. Elevation (m/ft)
36~60	65/213	30/98.4


Caution:

1. The capacity test is based on the standard length and the maximum permissive length is based on the system reliability.

2. Oil traps

-If oil flows back into the outdoor unit's compressor, this might cause liquid compression or deterioration of oil return. Oil traps in the rising gas piping can prevent this.


-An oil trap should be installed every 10m(32.8ft) of vertical suction line riser (≥36000Btu/h unit).



5.6.2 The procedure of connecting pipes

1. Choose the pipe size according to the specification table.

- 2. Confirm the cross way of the pipes.
- 3. Measure the necessary pipe length.
- 4. Cut the selected pipe with pipe cutter
 - Make the section flat and smooth.



5. Insulate the copper pipe

• Before test operation, the joint parts should not be heat insulated.

6. Flare the pipe

- · Insert a flare nut into the pipe before flaring the pipe
- · According to the following table to flare the pipe.

Dine diameter (inch/mm))	Flare dimens	ion A (mm/inch)	
Pipe diameter (inch(mm))	Min	Max	Flare shape
1/4" (6.35)	8.4/0.33	8.7/0.34	0
3/8" (9.52)	13.2/0.52	13.5/0.53	90°±4
1/2" (12.7)	16.2/0.64	16.5/0.65	A
5/8" (15.9)	19.2/0.76	19.7/0.78	
3/4" (19)	23.2/0.91	23.7/0.93	<u>R0.4~0.8</u>
7/8" (22)	26.4/1.04	26.9/1.06	~++•

• After flared the pipe, the opening part must be seal by end cover or adhesive tape to avoid duct or exogenous impurity come into the pipe.

- 7. Drill holes if the pipes need to pass the wall.
- 8. According to the field condition to bend the pipes so that it can pass the wall smoothly.
- 9. Bind and wrap the wire together with the insulated pipe if necessary.
- 10. Set the wall conduit
- 11. Set the supporter for the pipe.
- 12. Locate the pipe and fix it by supporter
 - For horizontal refrigerant pipe, the distance be-tween supporters should not be exceed 1m.
 - For vertical refrigerant pipe, the distance between supporters should not be exceed 1.5m.
- 13. Connect the pipe to indoor unit and outdoor unit by using two spanners.
 - Be sure to use two spanners and proper torque to fasten the nut, too large torque will damage the bell mouthing, and too small torque may cause leakage. Refer the following table for different pipe connec- tion.

Dina Diamatar	Torque	Skatah man
Pipe Diameter	N.m(lb.ft)	Sketch map
1/4" (6.35)	18~20	
	(13.3~14.8)	5
3/8" (9.52)	32~39	(BL
	(23.6~28.8)	1319
1/2" (12.7)	49~59	TV
172 (12.7)	(36.1~43.5)	l ´ WV
E/0" (1E 0)	57~71	- Ala
5/8" (15.9)	(42~52.4)	JE-JUN
0/411/40)	67~101	
3/4" (19)	(49.4~74.5)	
7 (011 (00)	85-110	
7/8" (22)	(62.7-81.1)	

5.7 Vacuum Drying and Leakage Checking

5.7.1 Purpose of vacuum drying

- Eliminating moisture in system to prevent the phenomena of ice-blockage and copper oxidation. Ice-blockage shall cause abnormal operation of system, while copper oxide shall damage compressor.
- Eliminating the non-condensable gas (air) in system to prevent the components oxidizing, pressure fluctuation and bad heat exchange during the operation of system.

5.7.2 Selection of vacuum pump

- The ultimate vacuum degree of vacuum pump shall be -756mmHg or above.
- Precision of vacuum pump shall reach 0.02mmHg or above.

5.7.3 Operation procedure for vacuum drying

Due to different construction environment, two kinds of vacuum drying ways could be chosen, namely ordinary vacuum drying and special vacuum drying.

5.7.3.1 Ordinary vacuum drying

1. When conduct first vacuum drying, connect pressure gauge to the infusing mouth of gas pipe and liquid pipe, and keep vacuum pump running for 1hour (vacuum degree of vacuum pump shall be reached

-755mmHg).

2. If the vacuum degree of vacuum pump could not reach -755mmHg after 1 hour of drying, it indicates that there is moisture or leakage in pipeline system and need to go on with drying for half an hour.

3. If the vacuum degree of vacuum pump still could not reach -755mmHg after 1.5 hours of drying, check whether there is leakage source.

4. Leakage test: After the vacuum degree reaches -755mmHg, stop vacuum drying and keep the pressure for 1 hour. If the indicator of vacuum gauge does not go up, it is qualified. If going up, it indicates that there is moisture or leak source.

5.7.3.2 Special vacuum drying

The special vacuum drying method shall be adopted when:

- 1. Finding moisture during flushing refrigerant pipe.
- 2. Conducting construction on rainy day, because rain water might penetrated into pipeline.
- 3. Construction period is long, and rain water might penetrated into pipeline.
- 4. Rain water might penetrate into pipeline during construction.

Procedures of special vacuum drying are as follows:

1. Vacuum drying for 1 hour.

2. Vacuum damage, filling nitrogen to reach 0.5Kgf/cm² .

Because nitrogen is dry gas, vacuum damage could achieve the effect of vacuum drying, but this method could not achieve drying thoroughly when there is too much moisture. Therefore, special attention shall be drawn to prevent the entering of water and the formation of condensate water.

3. Vacuum drying again for half an hour.

If the pressure reached -755mmHg, start to pressure leakage test. If it cannot reached the value, repeat vacuum damage and vacuum drying again for 1 hour.

4. Leakage test: After the vacuum degree reaches -755mmHg, stop vacuum drying and keep the pressure for 1 hour. If the indicator of vacuum gauge does not go up, it is qualified. If going up, it indicates that there is moisture or leak source.

5.8 Additional Refrigerant Charge

After the vacuum drying process is carried out, the additional refrigerant charge process need to be performed.
The outdoor unit is factory charged with refrigerant. The additional refrigerant charge volume is decided by the diameter and length of the liquid pipe between indoor and outdoor unit. Refer the following formula to calculate the charge volume.

	Diameter of liquid pipe (mm(inch))	Formula
R410A(Throttling part in the indoor unit)	9.52(3/8)	V=65(0.69)g/m(oz/ft) × (L- standard pipe length)

V: Additional refrigerant charge volume.

L : The length of the liquid pipe.

Note:

- The standard pipe length is 7.5m (25ft) in North America.
- Refrigerant may only be charged after performed the vacuum drying process.
- · Always use gloves and glasses to protect your hands and eyes during the charge work.
- Use electronic scale or fluid infusion apparatus to weight refrigerant to be recharged. Be sure to avoid extra refrigerant charged, it may cause liquid hammer of the compressor or protections.
- Use supplementing flexible pipe to connect refrigerant cylinder, pressure gauge and outdoor unit. And the refrigerant should be charged in liquid state. Before recharging, the air in the flexible pipe and manifold gauge should be exhausted.
- After finished refrigerant recharge process, check whether there is refrigerant leakage at the connection joint part.(Using gas leakage detector or soap water to detect).

5.9 Engineering of Insulation

5.9.1 Insulation of refrigerant pipe

1. Operational procedure of refrigerant pipe insulation

Cut the suitable pipe \rightarrow insulation (except joint section) \rightarrow flare the pipe \rightarrow piping layout and connection \rightarrow vacuum drying \rightarrow insulate the joint parts

2. Purpose of refrigerant pipe insulation


- During operation, temperature of gas pipe and liquid pipe shall be over-heating or over-cooling extremely. Therefore, it is necessary to carry out in- sulation; otherwise it shall debase the performance of unit and burn compressor.
- Gas pipe temperature is very low during cooling. If insulation is not enough, it shall form dew and cause leakage.
- Temperature of gas pipe is very high (generally 122-212°F) during heating. Insulation work must be carried out to prevent hurt by carelessness touching.

3. Insulation material selection for refrigerant pipe

- The burning performance should over 248°F
- · According to the local law to choose insulation materials
- The thickness of insulation layer shall be above 10mm. If in hot or wet environment place, the layer of insulation should be thicker accordingly.

4. Installation highlights of insulation construction

• Gas pipe and liquid pipe shall be insulated separately, if the gas pipe and liquid pipe were insulated together; it will decrease the performance of air conditioner.



- The insulation material at the joint pipe shall be 1.96~3.93inch longer than the gap of the insulation material.
- The insulation material at the joint pipe shall be inserted into the gap of the insulation material.
- The insulation material at the joint pipe shall be banded to the gap pipe and liquid pipe tightly.
- The linking part should be use glue to paste together.
- Be sure not bind the insulation material overtight, it may extrude out the air in the material to cause bad insulation and cause easy aging of the material.

5.9.2 Insulation of drainage pipe

1. Operational procedure of refrigerant pipe insulation

Select the suitable pipe \rightarrow insulation (except joint section) \rightarrow piping layout and connection \rightarrow drainage test \rightarrow insulate the joint parts

2. Purpose of drainage pipe insulation

The temperature of condensate drainage water is very cold. If insulation is not enough, it shall form dew and cause leakage to damage the house decoration.

3. Insulation material selection for drainage pipe

- The insulation material should be flame retardant material, the flame retardancy of the material should be selected according to the local law.
- Thickness of insulation layer is usually above 0.39inch.
- Use specific glue to paste the seam of insulation ma-terial, and then bind with adhesive tape. The width of tape shall not be less than 1.96inch. Make sure it is firm and avoid dew.

4. Installation and highlights of insulation construction

- The single pipe should be insulated before connecting to another pipe, the joint part should be insulated after the drainage test.
- There should be no insulation gap between the insulation material.

5.10 Engineering of Electrical Wring

5.10.1 Highlights of electrical wiring installation

- All field wiring construction should be finished by qualified electrician.
- · Air conditioning equipment should be grounded according to the local electrical regulations.
- Current leakage protection switch should be installed.
- Do not connect the power wire to the terminal of signal wire.
- When power wire is parallel with signal wire, put wires to their own wire tube and remain at least 300mm gap.
- According to table in indoor part named "the specification of the power" to choose the wiring, make sure the selected wiring not small than the date showing in the table.
- Select different colors for different wire according to relevant regulations.
- Do not use metal wire tube at the place with acid or alkali corrosion, adopt plastic wire tube to replace it.
- There must be not wire connect joint in the wire tube If joint is a must, set a connection box at the place.
- The wiring with different voltage should not be in one wire tube.
- Ensure that the color of the wires of outdoor and the terminal No. are same as those of indoor unit respectively.


Table: Minimum Cross-Sectional Area able of Power and Signal Cables

Rated Current of Appliance (A)	AWG
≤ 6	18
6 - 10	16
10 - 16	14
16 - 25	12
25 - 32	10

5.10.2 Specific wiring method


Connection method A:

Refer to the wiring method of internal and external machine communication and wired controller as follows:



Connection method B:


To use a 24V thermostat, you need to refer to the following wiring:





NOTE: The wiring method of the thermostat and the indoor unit refers to the wiring of the non-communication scheme.

Connection method C:


Non-communication scheme wiring reference








• Wiring for 3H and 1C thermostat




Wiring for 3H and 2C thermostat



Perform disconnection and short-circuit to achieve

partition, control or dehumidification


• Wiring for 2H and 1C thermostat



S4-1 DIP switch o Disconnect and short circuit to realize heating segment

Manufacturer reserves the right to change specifications or designs without notice.

circuit to realize heating segment



Note:


When the indoor and outdoor unit is connected without communication (connection mode C), indoor sensor fault and fan fault, the indoor unit plate outputs L signal to the temperature controller, and the temperature controller shall send out stop command to the outdoor unit .

If the temperature controller provided by the customer is not equipped with the output stop instruction of the outdoor unit , the outdoor units are not allowed to run in the non-communication mode. Please use connection mode B.

5.10.3 Optional function wiring

1. Condensate overflow switch


The unit will accommodate a remote condensate overflow switch. To enable, remote jumper J1, and connect the installer provided condensate overflow device to CN5 per below. When an overflow condition is present, the device should open connection signaling the unit to turn off the system.



2. The fault warning


Alarm output:

An alarm output(CN33) can be utilized if actions are required when a fault is present. This is a passive outlet port, so you will need to input a voltage signal. The relay is normally-open for normal operation, and closed when a fault condition is active.




3. Humidification control wiring

• To connect a humidifier, utilize the passive signal "WORK" output (CN23) port as well as the G and C wires on the controller, and wire the humidistat and humidifier per above wiring diagram. When the fan is running, the CN23 relay will be closed, which will allow power to the humidifier when the humidistat is below humidity setpoint. If the thermostat or zone controller has an HUM interface, connect the humidifier directly to the HUM and C ports.



4. Dehumidification control wiring



Dehumidification control requires indirect humidifier at DH and R. Set S4-2 as OFF. When the humidity rises and exceeds the set value of the humidifier, the 24V

signal of DH changes to 0V, the cooling system starts the dehumidification operation, and the air volume drops to 80% of the nominal cooling air volume.

When the partition control, DH is connected to the DH port of the partition controller. When the 24V signal of DH changes to 0V, the air volume drops to 80% of the nominal refrigeration air volume.

5. UV, fresh air or negative ion wiring

The WORK port is linked with the fan. When the fan is running, the relay is closed; if an active 24V signal is required, it can be directly connected to the G and C ports.



24V control signal or 208/230V power supply

5.10.4 Control Logic

Indoor unit Connector

Connector	Purpose			
R	24V Power Connection			
С	Common			
G	Fan Control			
Y1	Low Cooling			
Y/Y2	High Cooling			
В	Heating Reversing Valve			
W	Heating Control			
W1	Stage 1 Electric heating			
W2	Stage 2 Electric heating			
E/AUX	Emergency heating			
DH/DS/BK	Dehumidification/Zoning control			
L	System Fault Signal			

Outdoor unit Connector

Connector	Purpose	
R	24V Power Connection	
С	Common	
Y1	Low Cooling	
Y2	High Cooling	
В	Heating Reversing Valve	
W	Heating Control	
D	Dehumidification control	
L	System Fault Signal	

5.11 Test Operation

5.11.1 The test operation must be carried out after the entire installation has been completed.

5.11.2 Please confirm the following points before the test operation.

- The indoor unit and outdoor unit are installed properly.
- Piping and wiring are properly connected.
- Ensure that there are no obstacles near the inlet and outlet of the unit that might cause poor performance or product malfunction.
- The refrigeration system does not leak.
- The drainage system is unimpeded and draining to a safe location.
- The heating insulation is properly installed.
- The grounding wires are properly connected
- The length of the piping and the added refrigerant stow capacity have been recorded.
- The power voltage is the correct voltage for the air conditioner.

CAUTION: Failure to perform the test run may result in unit damage, property damage or personal injury.

5.11.3 Test Run Instructions

1.Open both the liquid and gas stop valves.

2.Turn on the main power switch and allow the unit to warm up.

3.Set the air conditioner to COOL mode, and check the following points.

Indoor unit

- Double check to see if the room temperature is being registered correctly.
- Ensure the manual buttons on the indoor unit works properly.
- Check to see that the drainage system is unimpeded and draining smoothly.
- Ensure there is no vibration or abnormal noise dur- ing operation.

Outdoor unit

- Check to see if the refrigeration system is leaking.
- Make sure there is no vibration or abnormal noise during operation.
- Ensure the wind, noise, and water generated by the unit do not disturb your neighbors or pose a safety hazard.

5.11.4 Drainage Test

a.Ensure the drainpipe flows smoothly. New buildings should perform this test before finishing the ceiling.

b.Remove the test cover. Add 2000ml of water to the tank through the attached tube.

c.Turn on the main power switch and run the air conditioner in COOL mode.

d.Listen to the sound of the drain pump to see if it makes any unusual noises.

e.Check to see that the water is discharged. It may take up to one minute before the unit begins to drain depending on the drainpipe.

f.Make sure that there are no leaks in any of the piping.

b.Stop the air conditioner. Turn off the main power switch and reinstall the test cover.

6. Maintenance

6.1 First Time Installation Check

Air and moisture trapped in the refrigerant system affects the performance of the air conditioner by:


- · Increasing pressure in the system.
- Increasing the operating current.
- Decreasing the cooling or heating efficiency.
- · Congesting the capillary tubing due to ice build-up in the refrigerant circuit.
- Corroding the refrigerant system.

To prevent air and moisture from affecting the air conditioner's performance, the indoor unit, as well as the pipes between the indoor and outdoor unit, must be be leak tested and evacuated.

Leak test (soap water method)


Use a soft brush to apply soapy water or a neutral liquid detergent onto the indoor unit connections and outdoor unit connections. If there is gas leakage, bubbles will form on the connection.

Air purging with vacuum pump



- 1. Tighten the flare nuts of the indoor and outdoor units, and confirm that both the 2- and 3-way valves are closed.
- 2. Connect the charge hose with the push pin of Handle Lo to the gas service port of the 3-way valve.
- 3. Connect another charge hose to the vacuum pump.
- 4. Fully open the Handle Lo manifold valve.
- 5. Using the vacuum pump, evacuate the system for 30 minutes.
 - a. Check whether the compound meter indicates -0.1 MPa (14.5 Psi).
 - If the meter does not indicate -0.1 MPa (14.5 Psi) after 30 minutes, continue evacuating for an additional 20 minutes.
 - If the pressure does not achieve -0.1 MPa (14.5 Psi) after 50 minutes, check for leakage.
 - If the pressure successfully reaches -0.1 MPa (14.5 Psi), fully close the Handle Lo valve, then cease vacuum pump operations.
 - **b.** Wait for 5 minutes then check whether the gauge needle moves after turning off the vacuum pump. If the gauge needle moves backward, check wether there is gas leakage.
- 6. Loosen the flare nut of the 3-way valve for 6 or 7 seconds and then tighten the flare nut again.
 - a. Confirm the pressure display in the pressure indicator is slightly higher than the atmospheric pressure.
 - b. Remove the charge hose from the 3-way valve.
- 7. Fully open the 2- and 3-way valves and tighten the cap of the 2- and 3-way valves.

6.2 Refrigerant Recharge




- 1. Close both 2- and 3-way valves.
- 2. Slightly connect the Handle Lo charge hose to the 3-way service port.
- 3. Connect the charge hose to the valve at the bottom of the cylinder.
- 4. The refrigerant cylinder must be inverted to ensure a complete liquid charge.
- 5. Open the valve at the bottom of the cylinder for 5 seconds to purge the air in the charge hose, then fully tighten the charge hose with push pin Handle Lo to the service port of 3-way valve.
- 6. Place the charging cylinder onto an electronic scale and record the starting weight.
- 7. Fully open the Handle Lo manifold valve, 2- and 3-way valves.
- 8. Operate the air conditioner in cooling mode to charge the system with liquid refrigerant.
- 9. When the electronic scale displays the correct weight (refer to the gauge and the pressure of the low side to confirm, the value of pressure refers to chapter Appendix), turn off the air conditioner, then disconnect the charge hose from the 3-way service port immediately.
- 10. Mount the caps of service port and 2- and 3-way valves.
- 11. Use a torque wrench to tighten the caps to a torque of 18 N.m.
- 12. Check for gas leakage.

6.3 Re-Installation


6.3.1 Indoor Unit

Collecting the refrigerant into the outdoor unit



- 1. Confirm that the 2- and 3-way valves are opened.
- 2. Connect the charge hose with the push pin of Handle Lo to the 3-way valve's gas service port.
- 3. Open the Handle Lo manifold valve to purge air from the charge hose for 5 seconds and then close it quickly.
- 4. Close the 2-way valve.
- 5. Operate the air conditioner in cooling mode. Cease operations when the gauge reaches 0.1 MPa (14.5 Psi).
- 6. Close the 3-way valve so that the gauge rests between 0.3 MPa (43.5 Psi) and 0.5 MPa (72.5 Psi).
- 7. Disconnect the charge set and mount the caps of service port and 2- and 3-way valves.
- 8. Use a torque wrench to tighten the caps to a torque of 18 N.m.
- 9. Check for gas leakage.


Air purging with vacuum pump



- 1. Tighten the flare nuts of the indoor and outdoor units, and confirm that both the 2- and 3-way valves are closed.
- 2. Connect the charge hose with the push pin of Handle Lo to the gas service port of the 3-way valve.
- 3. Connect another charge hose to the vacuum pump.
- 4. Fully open the Handle Lo manifold valve.
- 5. Using the vacuum pump, evacuate the system for 30 minutes.
 - a. Check whether the compound meter indicates -0.1 MPa (-14.5 Psi).
 - If the meter does not indicate -0.1 MPa (-14.5 Psi) after 30 minutes, continue evacuating for an additional 20 minutes.
 - If the pressure does not achieve -0.1 MPa (-14.5 Psi) after 50 minutes, check for leakage.
 - If the pressure successfully reaches -0.1 MPa (-14.5 Psi), fully close the Handle Lo valve, then cease vacuum pump operations.
 - **b.** Wait for 5 minutes then check whether the gauge needle moves after turning off the vacuum pump. If the gauge needle moves backward, check wether there is gas leakage.
- 6. Loosen the flare nut of the 3-way valve for 6 or 7 seconds and then tighten the flare nut again.
 - a. Confirm the pressure display in the pressure indicator is slightly higher than the atmospheric pressure.
 - b. Remove the charge hose from the 3-way valve.
- 7. Fully open the 2- and 3-way valves and tighten the cap of the 2- and 3-way valves.


6.3.2 Outdoor Unit

Evacuation for the whole system



- 1. Confirm that the 2- and 3-way valves are opened.
- 2. Connect the vacuum pump to the 3-way valve's service port.
- 3. Evacuate the system for approximately one hour. Confirm that the compound meter indicates -0.1 MPa (-14.5Psi).
- 4. Close the valve (Low side) on the charge set and turn off the vacuum pump.
- 5. Wait for 5 minutes then check whether the gauge needle moves after turning off the vacuum pump. If the gauge needle moves backward, check whether there is gas leakage.
- 6. Disconnect the charge hose from the vacuum pump.
- 7. Mount the caps of service port and 2- and 3-way valves.
- 8. Use a torque wrench to tighten the caps to a torque of 18 N.m.

Refrigerant charging



Procedure:

- 1. Close both 2- and 3-way valves.
- 2. Slightly connect the Handle Lo charge hose to the 3-way service port.
- 3. Connect the charge hose to the valve at the bottom of the cylinder.
- 4. The refrigerant cylinder must be inverted to ensure a complete liquid charge.
- 5. Open the valve at the bottom of the cylinder for 5 seconds to purge the air in the charge hose, then fully tighten the charge hose with push pin Handle Lo to the service port of 3-way valve.
- 6. Place the charging cylinder onto an electronic scale and record the starting weight.
- 7. Fully open the Handle Lo manifold valve, 2- and 3-way valves.
- 8. Operate the air conditioner in cooling mode to charge the system with liquid refrigerant.
- 9. When the electronic scale displays the correct weight (refer to the gauge and the pressure of the low side to confirm, the value of pressure refers to chapter Appendix), turn off the air conditioner, then disconnect the charge hose from the 3-way service port immediately.
- 10. Mount the caps of service port and 2- and 3-way valves.
- 11. Use a torque wrench to tighten the caps to a torque of 18 N.m.
- 12. Check for gas leakage.

Note: 1. Mechanical connectors used indoors shall comply with local regulations.

2. When mechanical connectors are reused indoors, sealing parts shall be renewed. When flared joints are reused indoors, the flare part shall be refabricated.

7. Product Features

7.1 Display Function

Mode	Priority	G	Y1	Y/Y2	В	W	W1	W2	E/AUX	DH/DS/BK	Display
Shut down	/	0	0	0	0	0	0	0	0	*	00
Fan	-	1	0	0	0	0	0	0	0	1	01
Fan	7	1	0	0	0	0	0	0	0	0	
Cooling		*	1	0	0	0	0	0	0	1	02
Cooling 2	6	*	*	1	0	0	0	0	0	1	03
Dehumidification 1		*	1	0	0	0	0	0	0	0	04
Dehumidification 2		*	*	1	0	0	0	0	0	0	05
Heating 1	_	*	1	0	1	0	0	0	0	1	06
Heating 2	5	*	*	1	1	0	0	0	0	1	07
Heating 2		*	*	*	*	1	0	0	0	1	07
Electric heating 1		*	0	0	0	0	1	0	0	*	08
Electric heating 1	3	*	0	0	0	0	0	1	0	*	08
Electric heating 2		*	0	0	0	0	1	1	0	*	09
Heating 1+Electric heating 1		*	1	0	1	0	1	0	0	1	. 10
Heating 1+Electric heating 1		*	1	0	1	0	0	1	0	1	
Heating 2+Electric heating 1]	*	*	1	1	0	1	0	0	1	
Heating 2+Electric heating 1		*	*	*	*	1	1	0	0	1	
Heating 2+Electric heating 1	4	*	*	1	1	0	0	1	0	1	
Heating 2+Electric heating 1		*	*	*	*	1	0	1	0	1	
Heating 1+Electric heating 2		*	1	0	1	0	1	1	0	1	11
Heating 2+Electric heating 2		*	*	1	1	0	1	1	0	1	
Heating 2+Electric heating 2		*	*	*	*	1	1	1	0	1	
Emergency heating	1	*	*	*	*	*	*	*	1	*	12
Heating zone control		*	1	0	1	0	*	*	0	0	
Heating zone control	2	*	*	1	1	0	*	*	0	0	13
Heating zone control		*	*	*	*	1	*	*	0	0	

NOTICE:

1 : signal

0 : no signal

If the input does not meet the above, press shutdown for processing.

7.2 Safety Features

Compressor three-minute delay at restart

Compressor functions are delayed for up to ten seconds upon the first startup of the unit, and are delayed for up to three minutes upon subsequent unit restarts.

Automatic shutoff based on discharge temperature

If the compressor discharge temperature exceeds a certain level for nine seconds, the compressor stops operation.

Inverter module protection

The inverter module has an automatic shutoff mechanism based on the unit's current, voltage, and temperature. If automatic shutoff is initiated, the corresponding error code is displayed on the indoor unit and the unit stops operation.

Indoor fan delayed operation

- When the unit starts, the indoor fan will operate after a period of setting time.
- If the unit is in heating mode, the indoor fan is regulated by the anti-cold wind function.

Compressor preheating

Preheating is automatically activated when T4 sensor is lower than setting temperature.

Sensor redundancy and automatic shutoff

- If one temperature sensor malfunctions, the air conditioner continues operation and displays the corresponding error code, allowing for emergency use.
- When more than one temperature sensor is malfunctioning, the air conditioner stops operation.

7.3 Basic Functions

7.3.1 Abbreviation

Unit element abbreviations

Abbreviation	Element			
T1	Indoor room temperature			
T2	Coil temperature of evaporator			
Т3	Coil temperature of condenser			
T4	Outdoor ambient temperature			
TP	Compressor discharge temperature			
TS	Setting temperature			
Tsc	Adjusted setting temperature			

In this manual, such as CDIFTEMP, HDIFTEMP2, TCE1, TCE2...etc., they are well-setting parameter of EEPROM.

7.3.2 Fan Mode

When fan mode is activated:

- The outdoor fan and compressor are stopped.
- Temperature control is disabled and no temperature setting is displayed.
- The indoor fan speed can be set to low, medium, high, turbo and auto.
- Auto fan: In fan-only mode, AC operates the same as auto fan in cooling mode with the temperature set at 75°F. Please refer to the indoor auto fan control on page 69 and page 70.

7.3.3 Cooling Mode

7.3.4.1 Compressor Control

- If the following conditions are satisfied, the compressor stops operation.
 - When the frequency value calculated through GA algorithm is negative compensation.
 - T1 is less than or equal to (Tsc-CDIFTEMP). CDIFTEMP is a parameter of EEPROM.
 - Compressor running time is greater than or equal to 10 minutes. If compressor running time is less than 10 minutes, even if the above shutdown conditions are met, the compressor cannot be turned off, but will maintain operation in the minimum frequency FminH(until the running time is over 10 minutes).
- If one of the following conditions is satisfied, the minimum compressor running time(10mins) could be ignored.
 - Compressor running frequency fr is greater than test frequency TestFre.
 - When compressor running frequency fr is equal to test frequency TestFre, T4 is greater than or equal to 59°F or T4 fault.
 - Changing remote controller setting temperature.
 - Turn on or off these functions: Turbo function, Sleep function, Mute function.
 - Any protection occurs.

7.3.3.2 Indoor Fan Control

1) In cooling mode, the indoor fan operates continuously. The fan speed can be set to low, medium, high, turbo and auto.

2) Auto fan action in cooling mode:

- Descent curve
 - When T1-Tsc is lower than or equal to 7°F, fan speed reduces to high;
 - When T1-Tsc is lower than or equal to 2°F, fan speed reduces to medium;
 - When T1-Tsc is lower than or equal to 1°F, fan speed reduces to low;
- Rise curve
 - When T1-Tsc is higher than 2°F, fan speed increases to medium;
 - When T1-Tsc is higher than 3°F, fan speed increases to high;
 - When T1-Tsc is higher than 8°F, fan speed increases to turbo.

7.3.3.3 Outdoor Fan Control

- The outdoor unit will be run at different fan speed according to T4 and compressor frequency.
- · For different outdoor units, the fan speeds are different.

7.3.3.4 Condenser Temperature Protection

When the condenser temperature exceeds a configured value, the compressor stops operation.

7.3.3.5 Evaporator Temperature Protection

When evaporator temperature drops below a configured value, the compressor and outdoor fan stop operation.

7.3.4 Heating Mode(Heat Pump Units)


7.3.4.1 Compressor Control

- If the following conditions are satisfied, the compressor stops operation.
 - When the frequency value calculated through GA algorithm is negative compensation.
 - T1 is greater than or equal to (Tsc+HDIFTEMP2). HDIFTEMP2 is a parameter of EEPROM.
 - Compressor running time is greater than or equal to 10 minutes. If compressor running time is less than 10 minutes, even if the above shutdown conditions are met, the compressor cannot be turned off, but will maintain operation in the minimum frequency FminH(until the running time is over 10 minutes).
- If one of the following conditions is satisfied, the minimum compressor running time(10mins) could be ignored.
 - · Compressor running frequency fr is greater than test frequency TestFre.
 - When compressor running frequency fr is equal to test frequency TestFre, T4 is greater than or equal to 59°F or T4 fault.
 - · Changing remote controller setting temperature.
 - Turn on or off these functions: Turbo function, Sleep function, Mute function.
 - · Any protection occurs.

7.3.4.2 Indoor Fan Control:

- 1) In heating mode, the indoor fan operates continuously. The fan speed can be set to low, medium, high, turbo and auto.
 - Anti-cold air function
 - The indoor fan is controlled by the indoor temperature T1 and indoor unit coil temperature T2.
 - TEL0, TEH0, TEH1...

are the parameters of of EEPROM.



ΔTE1=0

2) Auto fan action in heating mode:

- Rise curve
 - When T1-Tsc is higher than -3 °F, fan speed reduces to high;
 - When T1-Tsc is higher than 0°F, fan speed reduces to medium;
 - When T1-Tsc is higher than 1°F, fan speed reduces to low.
- Descent curve
 - When T1-Tsc is lower than or equal to 0°F, fan speed increases to medium;
 - When T1-Tsc is lower than or equal to -3°F, fan speed increases to high;
 - When T1-Tsc is lower than or equal to -6°F, fan speed increases to turbo.

7.3.4.3 Outdoor Fan Control:

- The outdoor unit will be run at different fan speed according to T4 and compressor frequency.
- · For different outdoor units, the fan speeds are different.

7.3.4.3 Outdoor Fan Control:

- The outdoor unit will be run at different fan speed according to T4 and compressor frequency.
- For different outdoor units, the fan speeds are different.

7.3.4.4 Defrosting mode

- The unit enters defrosting mode according to the temperature value of T3 and T4 as well as the compressor running time.
- In defrosting mode, the compressor continues to run, the indoor and outdoor motor will cease operation, the defrost light of the indoor unit will turn on, and the " " symbol is displayed.
- If any one of the following conditions is satisfied, defrosting ends and the machine switches to normal heating mode:
 - T3 rises above TCDE1.
 - T3 maintained above TCDE2 for 80 seconds.
 - Unit runs for 15 minutes consecutively in defrosting mode.
- If T4 is lower than or equal to -8°F and compressor running time is more than TIMING_DEFROST_TIME, if any one of the following conditions is satisfied, defrosting ends and the machine switches to normal heating mode:
 - Unit runs for 10 minutes consecutively in defrosting mode.
 - T3 rises above 50°F.

Note: TCDE1, TCDE2 are the parameters of of EEPROM.

3.4.5 Evaporator Coil Temperature Protection

When the evaporator temperature exceeds a preset protection value, the compressor stops operation.

7.3.5 Auto Mode

- This mode can be selected with the remote controller and the temperature setting can be adjusted between 60° F~86°F.
- · In auto mode, the unit selects cooling, heating, or

fan-only mode on the basis of ΔT (ΔT =T1-TS).

ΔΤ	Running mode
Δ T>4 °F	Cooling
-6°F<∆T≤4°F	Fan-only
∆T≤-6 °F	Heating*

Heating*: In auto mode, cooling only models run the fan

- Indoor fan will run at auto fan speed.
- If the machine switches mode between heating and cooling, the compressor will keep stopping for certain time and then choose mode according to ΔT .

7.3.6 Dry Mode

- In drying mode, AC operates the same as auto fan in cooling mode.
- All protections are activated and operate the same as they do that in cooling mode.
- Low Room Temperature Protection

If the room temperature is lower than 50°F, the compressor ceases operations and does not resume until room temperature exceeds 54°F.

7.3.7 Forced Operation Function

Press the AUTO/COOL button, the AC will run as below sequence:

Forced auto \rightarrow Forced cooling \rightarrow Off

• Forced cooling mode:

The compressor and outdoor fan continue to run and the indoor fan runs at fixed speed. After running for 30 minutes, the AC will switch to auto mode with a preset temperature of 76° F.

• Forced auto mode:

Forced auto mode operates the same as normal auto mode with a preset temperature of 76°F.

- The unit exits forced operation when it receives the following signals:
 - Switch off
 - · Changes in:
 - mode
 - · fan speed
 - · sleep mode
 - · Follow me

7.3.8 Timer Function

- The timing range is 24 hours.
- Timer On. The machine turns on automatically at the preset time.
- Timer Off. The machine turns off automatically at the preset time.
- Timer On/Off. The machine turns on automatically at the preset On Time, and then turns off automatically at the preset Off Time.
- Timer Off/On. The machine turns off automatically at the preset Off Time and then turns on automatically at the preset On Time.
- The timer does not change the unit operation mode. If the unit is off now, it does not start up immediately after the "timer off" function is set. When the setting time is reached, the timer LED switches off and the unit running mode remains unchanged.
- · The timer uses relative time, not clock time

7.3.9 Sleep Function

- The sleep function is available in cooling, heating, or auto mode.
- · The operational process for sleep mode is as follows:
 - When cooling, the temperature rises 2°F (to not higher than 86°F) every hour. After 2 hours, the temperature stops rising and the indoor fan is fixed at low speed.
 - When heating, the temperature decreases 2°F (to not lower than 60°F) every hour. After 2 hours, the temperature stops decreasing and the indoor fan is fixed at low speed. Anti-cold wind function takes priority.
- The operating time for sleep mode is 8 hours, after which, the unit exits this mode.
- The timer setting is available in this mode.

7.3.10 Auto-Restart Function

• The indoor unit has an auto-restart module that allows the unit to restart automatically. The module automatically stores the current settings and in the case of a sudden power failure, will restore those setting automatically within 3 minutes after power returns.

7.4 Remote Controller Functions

7.4.1 LCD Wired Remote Controller (ECT01)

i) Features and functions



Features:


- LCD display.
- Malfunction code display: it can display the error code, helpful for service.
- 4-way wire layout design, no raised part at backside, more convenient to place the wires and install the device.
- Room temperature display.
- Weekly Timer.

Functions:

- Mode: Choose Auto-Cool-Dry-Heat-Fan
- Fan speed: Auto/Low/Med/High speed
- Swing(on some models)
- Timer ON/OFF
- Temp setting
- Weekly timer
- Follow me
- Turbo
- 24-hour System
- 12-hour System


- Auto-restart
- Individual louver control (on some models)
- Automatic airflow test
- Rotation & Back-up
- Dual Control
- Group Control
- Child Lock
- LCD display
- Clock

ii) LCD Screen




iii) Installation

• Dimensions




1) Connection


Wire with the indoor unit:




- 1: Indoor Unit.
- 2: Notch the part for the wiring to pass through with a nipper tool.
- Connect the terminals on the remote controller (HA ,HB), and the terminals of the indoor unit. (HA ,HB). (HA and HB do not have polarity.)

For some models: The wired controller connects to main control board directly.





For some models: The wired controller connects to terminal board, terminal board connects to main control board.



Note: DO NOT allow water to enter the remote control. Use the trap and putty to seal the wires.

8. Troubleshooting


8.1 Safety Caution

Î WARNING

Be sure to turn off all power supplies or disconnect all wires to avoid electric shock. While checking indoor/outdoor PCB, please equip oneself with antistatic gloves or wrist strap to avoid damage to the board.

Electricity remains in capacitors even when the power supply is off. Ensure the capacitors are fully discharged before troubleshooting.

Test the voltage between P and N on back of the main PCB with multimeter. If the voltage is lower than 36V, the capacitors are fully discharged. For models that cannot be measured, wait 5 minutes after the power supply is off to ensure that the capacitors are fully discharged.



Note: This picture is for reference only. Actual appearance may vary.

8.2 General Troubleshooting

8.2.1 Error Display (Indoor Unit)

When the indoor unit encounters a recognized error, the operation lamp will flash in a corresponding series, the timer lamp may turn on or begin flashing, and an error code will be displayed. These error codes are described in the following table:

Display	Error Information	Page
EH 00	Indoor unit EEPROM parameter error	95
EL01	Indoor / outdoor unit communication error	96
EL16	Communication malfunction between adapter board and outdoor main board	123
EH03	The indoor fan speed is operating outside of the normal range	99
EH60	Indoor room temperature sensor T1 is in open circuit or has short circuited	101
EH61	Evaporator coil temperature sensor T2 is in open circuit or has short circuited	101
EH62	Evaporator coil temperature sensor T2B is in open circuit or has short circuited	101
EH65	Evaporator coil temperature sensor T2A is in open circuit or has short circuited	101
EL0C	Refrigerant Leakage Detection	102
EH0b	Communication error between indoor two chips	122
EH0E	Water-level alarm malfunction	103
EC53	Outdoor room temperature sensor T4 is in open circuit or has short circuited	101
EC52	Condenser coil temperature sensor T3 is in open circuit or has short circuited	101
EC54	Compressor discharge temperature sensor TP is in open circuit or has short circuited	101
EC51	Outdoor unit EEPROM parameter error	98
EC07	The outdoor fan speed is operating outside of the normal range	99
PC00	IPM malfunction or IGBT over-strong current protection	104
PC01	Over voltage or over low voltage protection	105
PC02	Top temperature protection of compressor or High temperature protection of IPM module	108
PC04	Inverter compressor drive error	106

PC03	Low pressure protection	107
EC0d	Outdoor unit malfunction	109
PC0L	Low ambient temperature protection	116
FL09	Mismatch between the new and old platforms	


For other errors:

The display board may show a garbled code or a code undefined by the service manual. Ensure that this code is not a temperature reading.

Troubleshooting:

Test the unit using the remote control. If the unit does not respond to the remote, the indoor PCB requires replacement. If the unit responds, the display board requires replacement.

LED flash frequency:



8.2.2 Error Display on Two Way Communication Wired Controller

Display	Malfunction or Protection	Page	
EHb3	Communication error between wire controller and indoor unit	124	

The other error codes displayed on the wire controller are same from those on the unit.

8.2.3 Error Display (Outdoor Unit)

Display	Malfunction or Protection	Page
EC51	Outdoor EEPROM malfunction	95
EL01	Indoor / outdoor units communication error	96
EL16	Communication malfunction between adapter board and outdoor main board	123
PC00	IPM module protection	104
PC02	Top temperature protection of compressor or High temperature protection of IPM module	108
PC06	Temperature protection of compressor discharge	121
PC08	Outdoor overcurrent protection	111
PC0A	High temperature protection of condenser	120
PC0F	PFC module protection	113
PC10	Outdoor unit low AC voltage protection	105
PC11	Outdoor unit main control board DC bus high voltage protection	105
PC12	Outdoor unit main control board DC bus high voltage protection /341 MCE error	105
PC30	High pressure protection	118
PC31	Low pressure protection	107
PC40	Communication malfunction between IPM board and outdoor main board	110
PC41	Outdoor compressor current sampling circuit failure	124
PC43	Outdoor compressor lack phase protection	115
PC44	Outdoor unit zero speed protection	111
PC45	Outdoor unit IR chip drive failure	116
PC46	Compressor speed has been out of control	111
PC49	Compressor overcurrent failure	111
EC52	Condenser coil temperature sensor T3 is in open circuit or has short circuited	101
EC32 EC53		
	Outdoor room temperature sensor T4 is in open circuit or has short circuited	101
EC54	Compressor discharge temperature sensor TP is in open circuit or has short circuited	101
EC57	Refrigerant pipe temperature sensor error	101
EC5C	High pressure sensor is in open circuit or has short circuited	101
EC71 EC72	Over current failure of outdoor DC fan motor Lack phase failure of outdoor DC fan motor	99 114
EC72 EC73	Zero-speed failure of outdoor DC fan motor	99
EC07	Outdoor fan speed has been out of control	99
PC0L	Low ambient temperature protection	116
LC06	High temperature protection of IPM module	108
EC55	Outdoor IPM module temperature sensor fault	117
FH90	High temperature protection of evaporator	
EH91	Low temperature protection of evaporator	

8.3 Outdoor Unit Point Check Function

- A check switch is included on the outdoor PCB.
- Push SW1 to check the unit's status while running. The digital display shows the following codes each time the SW1 is pushed.

Number of Presses	Display	Remark		
		Displays running frequency, running state, or malfunction code		
00	Normal display	Defrosting mode: "dF" or alternative displays between running frequency and "dF" (ach appears for 0.5s.)		
		Forced cooling mode: the LED displays "FC" or alternative displays between running frequency and "FC" (each appears for 0.5s).		
		Actual data*HP*10		
01	Indoor unit capacity demand code	If capacity demand code is higher than 99, the digital display tube will show single digit and tens digit. (For example, the digital display tube show "5.0",it means the capacity demand is 15. the digital display tube show "60",it means the capacity demand is 6.0)		
		GA algorithm models display ""		
02	The frequency after the capacity requirement adapter	If the value is higher than 99, the digital display tube will show single digit and tens digit.		
03	Room temperature (T1)	If the temp. is lower than 0 degree, the digital display tube will show "0".If the temp. is higher than 70 degree, the digital display tube will show "70".		
04	Indoor unit evaporator temperature (T2)	If the temp. is lower than -9 degree, the digital display tube		
05	Condenser pipe temp.(T3)	will show "-9".If the temp. is higher than 70 degree, the digital display tube will show "70". If the indoor unit is not		
06	Outdoor ambient temp.(T4)	connected, the digital display tube will show: ""		
07	Compressor discharge temp.	The display value is between 0~199 degree. If the temp. is lower than 0 degree, the digital display tube will show "0". If the temp. is higher than 99 degree, the digital display tube will show single digit and tens digit. (For example, the digital display tube show "0.5", it means the compressor discharge temp. is 105 degree. the digital display tube show "1.6", it means the compressor discharge temp. is 116 degree)		
08	AD value of current	The display value is a hex number.		
09	AD value of voltage	For example, the digital display tube shows "Cd", it means AD value is 205.		
10	Indoor unit running mode code			
11	Outdoor unit running mode code	Standby:0,Cooling:1, Heating:2, Fan only 3, Drying:4, Forced cooling:6, Defrost:7		
		Actual data/4.		
12	12 EXV open angle	If the value is higher than 99, the digital display tube will show single digit and tens digit. For example, the digital display tube show "2.0",it means the EXV open angle is 120×4=480p.)		

		Bit7	Frequency limit caused by IGBT radiator	
		Bit6	Reserved	
		Bit5	Reserved	The display value is a hex number. For
		Bit4	Frequency limit caused by low temperature of T2.(LH00)	example, the digital display show 2A, then Bit5=1, Bit3=1, and
13	Frequency limit symbol	Bit3	Frequency limit caused by T3.(LC01)	Bit1=1. This means that a
		Bit2	Frequency limit caused by TP.(LC02)	frequency limit may be caused by T4, T3, or the
		Bit1	Frequency limit caused by current(LC03)	current.
		Bit0	Frequency limit caused by voltage (LC05)	
14	Outdoor unit fan speed	If it is higher than 99, the digital display tube will show single digit and tens digit. (For example, the digital display tube show "2.0",it means the fan speed is 120.) This value is multiplied by 8, and it is the current fan speed: 120*8=960		
15	The average value of the temperature values detected by the high and low pressure sensors in the last 10 seconds of the compressor frequency calculation period	The displayed value is the actual value plus 60 (that is, when the displayed value is 10, the actual value is -50). When the displayed value is higher than 99, the digital display tube will show single digit and tens digit. (if it displays 2.0, it		
16	The temperature value detected by the high and low pressure sensor	means 120) When there is no pressure sensor, it is displayed as		displayed as
17	AD value detected by the high and low pressure sensor	The display value is a hex number. For example, the digital display tube shows "Cd", it means AD value is 205. When there is no pressure sensor, it is displayed as		
18	The currently running communication protocol version	00-99		

8.4 Information Inquiry

- To enter engineer mode, in power-on or standby mode, and in non-locked state, press the key combination "ON/OFF + Air Speed" for 7s:
- After entering the engineer mode, the remote control will display icons of "Auto, Cool, Dry, Heat", and the Battery icon; at the same time, it will also display the numeric code of the current engineer mode (for the initial engineer mode, the numeric code displayed is 0), and all other icons are inactive.
- In engineer mode, the value of the current numeric code can be adjusted circularly through the Up/Down key, with the setting range of 0 to 30. Each time the current numeric code is adjusted, the special code of the engineer mode will be transmitted with a delay of 0.6s. The code can also be transmitted by pressing "OK", and the special code of the engineer mode sent contains information of the currently displayed numeric code (if the numeric code is 0, the code to enter the engineer mode will be transmitted).
- In engineer mode, other keys or operations are invalid except for the On/Off key, the Up/Down key, the OK key or executing the operation to exit the engineer mode.

Code	Query Content	Advanced Function Setting
0	Error code	
1	T1 temperature	press "On/Off" for 2s to enter the Power Down Memory Selector, the code displayed is "Ch", press "OK" to send the Query Power Down Memory Selector code; press the Up/Down key to select 1 or 0 and press "OK" to confirm, 1 indicates that the power down memory exists, and 0 indicates that no power down memory exists; and press "On/Off" for 2s to exit.(Set within 1 minute after power on)
2	T2 temperature	press "On/Off" for 2s to enter the Internal Fan Control Selector after the pre- set temperature is reaches, the code displayed is "Ch", press "OK" to send the Query Internal Fan Control Selector code; press the Up/Down key to select 1 to 11: 1 - Stop the fan, 2 - Min. air speed, 3 - Set the air speed, 4 - Termal running for 5min, press "OK" to confirm, and press "On/Off" for 2s to exit. (Set within 1 minute after power on)
3	T3 temperature	press "On/Off" for 2s to enter the Mode Selector, press the Up/Down key to select CH (cool and heat, Auto + Cool + Dry + Heat + Fan), CC (Cool only without Auto, Cool + Dry + Fan), press "OK" to confirm, and the mode selected can be memorized when the remote control is powered down and powered on; and press "On/Off" for 2s to exit. When the remote control does not burn any parameters, the mode setting will not be memorized. (Set within 1 minute after power on)
4	T4 temperature	press the "On/Off" for 2s to enter the Min. Set Temperature Selector, press the Up/Down key to select "16°C~24°C", press "OK" to confirm, and the Min. Set Temperature can be memorized when the remote control is powered on and power lost; and press "On/Off" for 2s to exit. When the remote control does not burn any parameters, the min. set temperature will not be memorized.(Set within 1 minute after power on)
5	TP temperature	press "On/Off" for 2s to enter the Max. Set Temperature Selector, press the Up/Down key to select "25°C~30°C", press "OK" to confirm, and the Max. Set Temperature can be memorized when the remote control is powered on and power lost; and press "On/Off" for 2s to exit. When the remote control does not burn any parameters, the max. set temperature will not be memorized.(Set within 1 minute after power on)
6	Compressor Target Frequency FT	

	Compressor	press "On/Off" for 2s to enter Twins Selector, the code displayed is "Ch",
7	Running Frequency Fr	press "OK" to send the Query Twins Selector code; press the Up/Down key to select, 0 indicates that there is no Twins, 1 indicates the host, and 2 indicates the slave. Press "OK" to confirm, and press "On/Off" for 2s to exit.
8	Current dL	1
9	Current AC Voltage Uo	1
10	Current indoor capacity test state Sn	/
11	1	press "On/Off" for 2S to enter the Min. Desired Cooling Frequency Selector, the code displayed is Ch, press "OK" to send the Query Min. Desired Cooling Frequency Selector code; press the Up/Down key to select the minimum cooling frequency desired and press "OK" to confirm; press "On/Off" for 2s to exit.(for some models)
12	Set Speed Pr of the outdoor fan	press "On/Off" for 2s to enter the Min. Desired Heating Frequency Selector, the code displayed is "Ch", press "OK" to send the Query Min. Desired Heating Frequency Selector code; press the Up/Down key to select the min. desired heating frequency value, press "OK" to confirm; and press the "On/ Off" for 2s to exit.(for some models)
13	Opening Lr of EEV	press "On/Off" for 2s to enter the Max. Running Frequency Selector of the restricted area 6 in the cooling mode T4, the code displayed is "Ch", press "OK" to send the Query Max. Running Frequency Selector code of the restricted area 6 in the cooling mode T4; press the Up/Down key to select the limit, then press "OK" to confirm; and press "On/Off" for 2s to exit.(for some models)
14	Actual Running Speed ir of the indoor fan	1
15	Indoor Humidity Hu	press "On/Off" for 2s to enter the Outdoor Forced Running Frequency Selector, the code displayed is "Ch", press "OK" to send the Query Outdoor Forced Running Frequency Selector code; press the Up/Down key to select the outdoor forced running frequency, then press "OK" to confirm; and press "On/Off" for 2s to exit.(for some models)
16	Set Temperature TT after compensation	press "On/Off" for 2s to enter One-Key Recovery, the code displayed is "rS", then press "OK" to send the One-Key Recovery code, the mode selector of the remote control will recover to "Cooling and heating", the min. temperature recovers to 16°C, and the max. temperature recovers to 30°C; and press "On/ Off" for 2s to exit.(for some models)
17	/	nA
18	/	/
19	DC bus voltage	press "On/Off" for 2s to enter the Cooling Frequency Threshold Settings; press the Up/Down key to select the cooling frequency threshold, press "OK" to confirm; and press the "On/Off" for 2s to exit. (Set within 1 minute after power on)
20	Indoor Target Frequency oT	press "ON/OFF" for 2s to enter the Heating Frequency Threshold Settings; press the Up/Down key to select the heating frequency threshold, press "OK" to confirm; and press "On/Off" for 2s to exit. (Set within 1 minute after power on)

21		press "On/Off" for 2s to enter the Cooling Temperature Compensation Value Settings, the code displayed is "Ch", then press "OK" to send the Query Cooling Temperature Compensation Value code; press the Up/Down key to select the cooling temperature compensation value, then press "OK"; and press "On/Off" for 2s to exit.
22		press "On/Off" for 2s to enter the Heating Temperature Compensation Value Settings, the code displayed is "Ch", press "OK" to send the Query Heating Temperature Compensation Value code; press the Up/Down key to select the heating temperature compensation value, then press "OK"; and press "On/ Off" for 2s to exit.
23		
24		
25		
26		
27	Reserved	
28		/
29		
30		

• In Channel 1~30 settings of the engineer mode, long press the On/off key to return the previous engineer mode. Exit of engineer mode:

1)In engineer mode, press the key combination of "On/Off + Air speed" for 2s;

2)The engineer mode will be exited if there are no valid key operations for continuous 60s.

Error code of engineer mode

Display	Error Information
EH00	Indoor unit EEPROM parameter error
ELO1	Indoor / outdoor unit communication error
EL16	Communication malfunction between adapter board and outdoor main board
EH03	The indoor fan speed is operating outside of the normal range
EC51	Outdoor unit EEPROM parameter error
EC52	Condenser coil temperature sensor T3 is in open circuit or has short circuited
EC53	Outdoor room temperature sensor T4 is in open circuit or has short circuited
EC54	Compressor discharge temperature sensor TP is in open circuit or has short circuited
EC55	IGBT temperature sensor TH is in open circuit or has short circuited
EC0d	Outdoor unit malfunction
EH60	Indoor room temperature sensor T1 is in open circuit or has short circuited
EH61	Evaporator coil temperature sensor T2 is in open circuit or has short circuited
EH62	Evaporator coil temperature sensor T2B is in open circuit or has short circuited
EH65	Evaporator coil temperature sensor T2A is in open circuit or has short circuited
EC07	The outdoor fan speed is operating outside of the normal range
EH0b	Communication error between indoor two chips
EL0C	Refrigerant leak detected
EH0E	Water-level alarm malfunction
PL09	Mismatch between the new and old platforms
PC00	IPM malfunction or IGBT over-strong current protection
PC01	Over voltage or over low voltage protection
PC02	Top temperature protection of compressor or High temperature protection of IPM module
PC04	Inverter compressor drive error
PC08	Outdoor current protection
PC03	Pressure protection
PC0L	Outdoor low ambient temperature protection
PH90	Evaporator coil temperature over high protection
PH91	Evaporator coil temperature over low Protection
PC0A	Condenser high temperature protection

8.5 Error Diagnosis and Troubleshooting Without Error Code

WARNING

Be sure to turn off unit before any maintenance to prevent damage or injury.

8.5.1 Remote maintenance

SUGGESTION: When troubles occur, please check the following points with customers before field maintenance.

No.	Problem	Page
1	Unit will not start	89-90
2	The power switch is on but fans will not start	89-90
3	The temperature on the display board cannot be set	89-90
4	Unit is on but the wind is not cold(hot)	89-90
5	Unit runs, but shortly stops	89-90
6	The unit starts up and stops frequently	89-90
7	Unit runs continuously but insufficient cooling(heating)	89-90
8	Cool can not change to heat	89-90
9	Unit is noisy	89-90

8.5.2 Field maintenance

No.	Problem	Page
1	Unit will not start	91-92
2	Compressor will not start but fans run	91-92
3	Compressor and condenser (outdoor) fan will not start	91-92
4	Evaporator (indoor) fan will not start	91-92
5	Condenser (Outdoor) fan will not start	91-92
6	Unit runs, but shortly stops	91-92
7	Compressor short-cycles due to overload	91-92
8	High discharge pressure	91-92
9	Low discharge pressure	91-92
10	High suction pressure	91-92
11	Low suction pressure	91-92
12	Unit runs continuously but insufficient cooling	91-92
13		91-92
14	Compressor is noisy	91-92

1.Remote Maintenance		E	lect	rica	l Ci	rcui	it		R	efri	gera	ant	Circ	uit
Possible causes of trouble	Power failure	The main power tripped	Loose connections	Faulty transformer	The voltage too high or too low	The remote control is powered off	Borken the remote control	Diety air filter	Dirty condenser fins	The setting temp is higher or lower than the room's(cooling/heating)	The ambient temp is too high/low when the mode is cooling/heating	Fan mode	SILENCE function is activated(optional)	Frosting and defrosting frequently
Unit will not start	☆	☆	☆	☆										
The power switch is on but fans will not start			☆	☆	☆									
The temperature on the display board cannot be set					☆	☆								
Unit is on but the wind is not cold(hot)										☆	☆	☆		
Unit runs, but shortly stops					☆					☆	☆			
The unit starts up and stops frequently					☆						☆			☆
Unit runs continuously but insufficient cooling(heating)								☆	☆	☆	☆		☆	
Cool can not change to heat														
Unit is noisy														
Test method / remedy	Test voltage	Close the power switch	Inspect connection-tighten	Change the transformer	Test voltage	Replace the battery of the remote control	Replace the remote control	Clean or replace	Replace	Adjust the setting temp.	Turn on the AC later	Adjust to cool mode	Turn off the SILENCE function	Turn on the AC later

1.Remote Maintenance		0	the	rs		
Possible causes of trouble	Heavy load condition	Loosen hold down bolts and / or screws	Bad airproof	The air inlet or outlet of either unit is blocked	Interference from cell phone towers and remote boosters	Shipping plates remain attached
Unit will not start						
The power switch is on but fans will not start					☆	
The temperature on the display board cannot be set						
Unit is on but the wind is not cold(hot)						
Unit runs, but shortly stops						
The unit starts up and stops frequently				☆		
Unit runs continuously but insufficient cooling(heating)	☆		☆	☆		
Cool can not change to heat						
Unit is noisy		☆				☆
Test method / remedy	Check heat load	Tighten bolts or screws	Close all the windows and doors	Remove the obstacles	Reconnect the power or press ON/OFF button on remote control to restart operation	Remove them

2.Field Maintenance		Refrigerant Circuit									Others												
Possible causes of trouble	Compressor stuck	Shortage of refrigerant	Restricted liquid line	Dirty air filter	Dirty evaporator coil	Insufficient air through evaporator coil	Overcharge of refrigerant	Dirty or partially blocked condenser	Air or incompressible gas in refrigerant cycle	Short cycling of condensing air	High temperature condensing medium	Insufficient condensing medium	Broken compressor internal parts	Inefficient compressor	Expansion valve obstructed	Expansion valve or capillary tube closed completely	Leaking power element on expansion valve	Poor installation of feeler bulb	Heavy load condition	Loosen hold down bolts and / or screws	Shipping plates remain attached	Poor choices of capacity	Contact of piping with other piping or external plate
Unit will not start																							
Compressor will not start but fans run	☆																						
Compressor and condenser (outdoor) fan will not start																							
Evaporator (indoor) fan will not start																							
Condenser (Outdoor) fan will not start																							
Unit runs, but shortly stops		☆	☆				☆	☆								☆	☆						
Compressor short-cycles due to overload		☆					☆	☆															
High discharge pressure							☆	☆	☆	☆	☆	☆											
Low discharge pressure		☆												☆									
High suction pressure							☆							☆				☆	☆				
Low suction pressure		☆	☆	☆	☆	☆									☆	☆	☆						
Unit runs continuously but insufficient cooling		☆	☆	☆	☆	☆		☆	☆	☆				☆					☆			☆	
Too cool																							
Compressor is noisy							☆						☆							☆	☆		☆
Horizontal louver can not revolve						1								1	1		1		1				T
Test method / remedy	Replace the compressor	Leak test	Replace restricted part	Clean or replace	Clean coil	Check fan	Change charged refrigerant volume	Clean condenser or remove obstacle	Purge, evacuate and recharge	Remove obstruction to air flow	Remove obstruction in air or water flow	Remove obstruction in air or water flow	Replace compressor	Test compressor efficiency	Replace valve	Replace valve	Replace valve	Fix feeler bulb	Check heat load	Tighten bolts or screws	Remove them	Choose AC of lager capacity or add the number of AC	Rectify piping so as not to contact each other or with external plate

2.Field Maintenance				Eleo	ctric	al C	ircui	t							
Possible causes of trouble	Power failure	Blown fuse or varistor	Loose connections	Shorted or broken wires	Safety device opens	Faulty thermostat / room temperature sensor	Wrong setting place of temperature sensor	Faulty transformer	Shorted or open capacitor	Faulty magnetic contactor for compressor	Faulty magnetic contactor for fan	Low voltage	Faulty stepping motor	Shorted or grounded compressor	Shorted or grounded fan motor
Unit will not start	☆	☆	☆	☆	☆			☆							
Compressor will not start but fans run				☆		☆			☆	☆				☆	
Compressor and condenser (outdoor) fan will not start				*		☆				☆					
Evaporator (indoor) fan will not start				☆					\$		☆				☆
Condenser (Outdoor) fan will not start				☆		☆			☆		☆				☆
Unit runs, but shortly stops										☆		☆			
Compressor short-cycles due to overload										☆		☆			
High discharge pressure															
Low discharge pressure															
High suction pressure															
Low suction pressure															
Unit runs continuously but insufficient cooling															
Too cool						☆	☆								
Compressor is noisy															
Horizontal louver can not revolve		☆	☆		1				☆			r			
Test method / remedy	Test voltage	nspect fuse type & size	Inspect connections - tighten	Test circuits with tester	Test continuity of safety device	Test continuity of thermostat / sensor & wiring	Place the temperature sensor at the central of the air inlet grille	Check control circuit with tester	Check capacitor with tester	Test continuity of coil & contacts	Test continuity of coil & contacts	Test voltage	Replace the stepping motor	Check resistance with multimeter	Check resistance with multimeter

Manufacturer reserves the right to change specifications or designs without notice.

8.6 Quick Maintenance by Error Code

If you do not have the time to test which specific parts are faulty, you can directly change the required parts according the error code.

You can find the parts to replace by error code in the following table.

Part requiring					Error	Code				
replacement	EH00	EL01	EH03	EH60	EH61	EH62	EH65	EL0C	EH0E	EC53
Indoor PCB	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	x
Outdoor PCB	x	\checkmark	x	x	x	x	х	x	x	\checkmark
Indoor fan motor	x	x	\checkmark	x	x	x	х	x	x	х
T1 sensor	х	х	х	\checkmark	x	х	х	х	х	х
T2 Sensor	х	х	х	x	\checkmark	х	х	х	х	х
T2B Sensor	х	х	x	x	x	\checkmark	х	x	x	х
T2A Sensor	х	х	х	x	x	х	\checkmark	х	х	х
T3 Sensor	х	х	x	x	х	x	х	x	x	х
T4 Sensor	x	x	x	x	x	x	х	x	x	\checkmark
Reactor	х	\checkmark	x	x	х	x	х	x	x	х
Compressor	x	x	x	x	x	x	х	x	x	х
Additional refrigerant	x	x	x	x	x	x	х	\checkmark	x	х
Water-level switch	x	x	x	x	x	x	х	x	\checkmark	х
Water pump	x	x	x	x	x	x	x	x	\checkmark	x
Part requiring replacement	EC54	EC51	EC5C	EC52	EC07/71 /72/73	PC00	PC01	PC02	PC04	PC03
Indoor PCB	x	x	x	x	x	x	x	x	x	x
Outdoor PCB	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark
Outdoor fan motor	x	x	x	x	\checkmark	\checkmark	x	\checkmark	\checkmark	x
T3 Sensor	x	x	x	\checkmark	x	x	x	x	х	x
TP Sensor	\checkmark	x	x	x	х	x	x	x	х	x
Pressure sensor	x	х	\checkmark	x	х	х	х	х	х	x
Reactor	x	х	х	x	х	х	\checkmark	х	х	x
Compressor	x	х	х	x	х	\checkmark	х	х	\checkmark	x
IPM module board	x	х	х	x	х	\checkmark	\checkmark	\checkmark	\checkmark	x
Low pressure protector	x	х	х	x	х	х	х	х	х	\checkmark
Additional refrigerant	x	x	x	x	x	x	x	x	x	\checkmark

Part requiring replacement	EL16	EH0b	PC06	PC08/44/ 49	PC0A	PC0F
Indoor PCB	x	\checkmark	x	x	х	x
Outdoor PCB	\checkmark	х	\checkmark	\checkmark	\checkmark	\checkmark
Outdoor fan motor	х	x	x	\checkmark	\checkmark	x
T3 Sensor	x	x	х	x	\checkmark	x
TP Sensor	x	x	\checkmark	x	x	x
Pressure sensor	x	x	x	x	x	x
Reactor	x	x	х	\checkmark	x	\checkmark
Compressor	x	x	x	x	x	x
IPM module board	x	x	х	\checkmark	x	x
Data adapter board	\checkmark	\checkmark	х	x	x	x
High pressure valve assy	x	x	\checkmark	x	х	x
High pressure protector	x	x	x	x	x	x
Low pressure protector	x	x	x	x	x	x
Additional refrigerant	x	x	\checkmark	x	\checkmark	x

Part requiring replacement	PC41	PC43	PC10/11/12	PC30	PC31	PC40
Indoor PCB	x	x	x	х	x	х
Outdoor PCB	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark
Outdoor fan motor	x	x	x	\checkmark	x	x
T3 Sensor	x	x	x	x	x	x
TP Sensor	x	x	x	x	x	x
Pressure sensor	x	x	x	х	x	x
Reactor	x	x	\checkmark	x	x	x
Compressor	x	\checkmark	x	х	x	x
IPM module board	x	x	\checkmark	х	x	\checkmark
Data adapter board	x	x	x	х	x	x
High pressure valve assy	x	x	x	х	x	x
High pressure protector	x	x	x	\checkmark	x	x
Low pressure protector	x	x	x	x	\checkmark	x
Additional refrigerant	x	x	x	x	\checkmark	x
Electric control box	x	x	x	x	x	\checkmark

8.7 Troubleshooting by Error Code


8.7.1 EH 00 / EC 51 (EEPROM Parameter Error Diagnosis and Solution)

Description: Indoor or outdoor PCB main chip does not receive feedback from EEPROM chip.

Recommended parts to prepare:


- Indoor PCB
- Outdoor PCB

Troubleshooting and repair:



Remarks:

EEPROM: A read-only memory whose contents can be erased and reprogrammed using a pulsed voltage. The location of the EEPROM chip on the indoor and outdoor PCB is shown in the following two images:



Note: For certain models, outdoor PCB could not be removed separately. In this case, the outdoor electric control box should be replaced as a whole. This pictures are only for reference, actual appearance may vary.

Troubleshooting and repair of compressor driven chip EEPROM parameter error and communication error between outdoor main chip and compressor driven chip are same as EC 51.

8.7.2 EL 01 (Indoor and Outdoor Unit Communication Error Diagnosis and Solution)


Description: Indoor unit can not communicate with outdoor unit

Recommended parts to prepare:


- · Signal wires
- Magnet ring
- Indoor PCB
- Outdoor PCB

Troubleshooting and repair:

XYE Communication:




S Communication:




Remarks:

- Use a multimeter to test the DC voltage between 2 port(or S or L2 port) and 3 port(or N or S port) of outdoor unit. The red pin of multimeter connects with 2 port(or S or L2 port) while the black pin is for 3 port(or N or S port).
- When AC is normal running, the voltage is moving alternately as positive values and negative values
- If the outdoor unit has malfunction, the voltage has always been the positive value.
- While if the indoor unit has malfunction, the voltage has always been a certain value.



- Use a multimeter to test the resistance of the reactor which does not connect with capacitor.
- The normal value should be around zero ohm. Otherwise, the reactor must have malfunction.



Note: The picture and the value are only for reference, actual condition and specific value may vary.


8.7.3 EH 03 / EC 07 (Fan Speed Is Operating Outside of Normal Range)/EC 71(Over Current Failure of Outdoor DC Fan Motor)/ EC73(Zero-speed failure of outdoor DC fan motor) Diagnosis and Solution

Description: When indoor / outdoor fan speed keeps too low or too high for a certain time, the unit stops operation and the LED displays the failure.

Recommended parts to prepare:

- · Connection wires
- Fan assembly
- · Fan motor
- PCB


Troubleshooting and repair:



Index:

1. Indoor DC Fan Motor(control chip is in fan motor)

Power on and when the unit is in standby, measure the voltage of pin1&pin2 of CN15, pin3 of CN34 in fan motor connector. If the value of the voltage is not in the range showing in below table, the PCB must has problems and need to be replaced.



CN34


NO.	Color	Signal	Voltage
1	/	/	
2	Black	GND	
3	Orange	PWM	5-12VDC
4	Blue	FG	0-12VDC

CN15

NO.	Color	Signal	Voltage
1	Yellow		208/230VAC
2	Black		208/230VAC
3	Yellow-Green	GND	

2. Outdoor DC Fan Motor (control chip is in outdoor PCB)

Release the UVW connector. Measure the resistance of U-V, U-W, V-W. If the resistance is not equal to each other, the fan motor must has problems and need to be replaced. otherwise the PCB must has problems and need to be replaced.




8.7.4 EH 60/EH 61/EH 62/ EH 65/ EC 53/EC 52/EC 54/EC 57/EC 50/EC 5C (Open Circuit or Short Circuit of Temperature Sensor Diagnosis and Solution)

Description: If the sampling voltage is lower than 0.06V or higher than 4.94V, the LED displays the failure.

Recommended parts to prepare:

- · Connection wires
- Sensors
- PCB

Troubleshooting and repair:



Note: For certain models, outdoor PCB could not be removed separately. In this case, the outdoor electric control box should be replaced as a whole. This picture and the value are only for reference, actual appearance and value may vary

8.7.5 EL 0C (Refrigerant Leakage Detection Diagnosis and Solution)


Description:

Judging the abnormality of the refrigeration system according to the number of compressor stops and the changes in operating parameters caused by excessive exhaust temperature.

Recommended parts to prepare:

- Indoor PCB
- Additional refrigerant

Troubleshooting and repair:




8.7.6 EH 0E(Water-Level Alarm Malfunction Diagnosis and Solution)

Description: If the sampling voltage is not 5V, the LED displays the failure code.

Recommended parts to prepare:

- · Connection wires
- · Water level switch
- Indoor PCB




8.7.7 PC 00(IPM malfunction or IGBT over-strong current protection Diagnosis and Solution)

Description: When the voltage signal the IPM sends to the compressor drive chip is abnormal, the display LED shows "PC 00" and the AC turn off.

Recommended parts to prepare:

- Connection wires
- · IPM module board
- · Outdoor fan assembly
- · Compressor
- Outdoor PCB

Troubleshooting and repair:




8.7.8 PC 01(Over voltage or too low voltage protection)/PC 10(Outdoor unit low AC voltage protection)/PC 11(Outdoor unit main control board DC bus high voltage protection)/PC 12(Outdoor unit main control board DC bus high voltage protection/341 MCE error) Diagnosis and Solution

Description: Abnormal increases or decreases in voltage are detected by checking the specified voltage detection circuit.

Recommended parts to prepare:

- Power supply wires
- · IPM module board
- PCB
- Reactor

Troubleshooting and repair:




8.7.9 PC 04(Inverter compressor drive error Diagnosis and Solution)

Description: An abnormal inverter compressor drive is detected by a special detection circuit, including communication signal detection, voltage detection, compressor rotation speed signal detection and so on.

Recommended parts to prepare:

- · Connection wires
- · IPM module board
- · Outdoor fan assembly
- Compressor
- Outdoor PCB

Troubleshooting and repair:




8.7.10 PC 03/PC 31(Low Pressure Protection Diagnosis and Solution)

Description: If the sampling voltage is not 5V, the LED displays a failure code.

Recommended parts to prepare:

- · Connection wires
- · Low pressure protector
- Indoor fan assembly
- Outdoor PCB

Troubleshooting and repair:



8.7.11 PC 02/LC 06(Top temperature protection of compressor or High temperature protection of IPM module diagnosis and solution)


Description: For some models with overload protection, If the sampling voltage is not 5V, the LED will display the


failure. If the temperature of IPM module is higher than a certain value, the LED displays the failure code.

Recommended parts to prepare:

- · Connection wires
- Outdoor PCB
- · IPM module board
- · High pressure protector
- · System blockages

Troubleshooting and repair:






8.7.12 EC 0d(Outdoor unit malfunction Diagnosis and Solution)

Description: The indoor unit detect the outdoor unit is error.

Recommended parts to prepare:

• Outdoor unit




8. 7.13 PC 40(Communication error between outdoor main PCB and IPM board diagnosis and solution)

Description: The main PCB cannot detect the IPM board.

Recommended parts to prepare:

- · Connection wires
- IPM board
- Outdoor main PCB
- · Electric control box




8.7.14 PC 08(Current overload protection)/PC 44(Outdoor unit zero speed protection)/ PC 46(Compressor speed has been out of control)/PC 49(Compressor overcurrent failure) diagnosis and solution

Description: An abnormal current rise is detected by checking the specified current detection circuit.

Recommended parts to prepare:

- · Connection wires
- Rectifier
- · PFC circuit or reactor
- · Blocked refrigeration piping system
- · Pressure switch
- Outdoor fan
- · IPM module board
- Outdoor PCB



Note: For certain models, outdoor PCB could not be removed separately. In this case, the outdoor electric control box should be replaced as a whole.

8.7.15 PC 0F(PFC module protection diagnosis and solution)


Description: When the voltage signal that IPM send to compressor drive chip is abnormal, the LED displays the failure code and the AC turns off.

Recommended parts to prepare:

- · Connection wires
- Inductance
- Outdoor main PCB
- PFC module

Troubleshooting and repair:

At first test the resistance between every two ports of U, V, W of IPM and P, N. If any result of them is 0 or close to 0, the IPM is defective. Otherwise, please follow the procedure below:




8.7.16 EC 72 (Lack phase failure of outdoor DC fan motor diagnosis and solution)

Description: When the three-phase sampling current of the DC motor is abnormal, especially when the current of one or more phases is always small and almost 0, the LED displays the failure code.

Recommended parts to prepare:

- Connection wire
- · Fan motor
- Outdoor PCB




8.7.17 PC 43 (Outdoor compressor lack phase protection diagnosis and solution)

Description: When the three-phase sampling current of the compressor is abnormal, especially when the current of one or more phases is always small and almost 0, the LED displays the failure code

Recommended parts to prepare:

- · Connection wire
- Compressor
- Outdoor PCB




8.7.18 PC 45 (Outdoor unit IR chip drive failure) diagnosis and solution

Description: When the IR chip detects its own parameter error, the LED displays the failure code when power on.

Recommended parts to prepare:

• Inverter module PCB.

Troubleshooting and repair:



8.7.19 PC 0L (Low ambient temperature protection)

Description: It is a protection function. When compressor is off, outdoor ambient temperature(T4) is lower than - 31°F for 10s, the AC will stop and display the failure code.

When compressor is on, outdoor ambient temperature(T4) is lower than -40°F for 10s, the AC will stop and display the failure code.

When outdoor ambient temperature(T4) is no lower than -26°F for 10s, the unit will exit protection.

8.7.20 EC55 (Outdoor IPM module temperature sensor fault) diagnosis and solution


Description: If the sampling voltage is 0V or 5V, the LED displays the failure code.

Recommended parts to prepare:


- IPM module PCB
- · Connection wires
- Sensors
- Outdoor main PCB

Troubleshooting and repair:

If the radiator has no sensor, follow the steps below to resolve.



If the radiator has a sensor(TH), follow the steps below to resolve,




8.7.21 PC 30 (High pressure protection diagnosis and solution)

Description: Outdoor pressure switch cut off the system because high pressure is higher than 4.4 MPa

Recommended parts to prepare:

- · Connection wires
- · Pressure switch
- Outdoor fan
- Outdoor main PCB




8.7.22 PC 0A (High temperature protection of condenser diagnosis and solution)

Description: When the outdoor pipe temperature is more than 149°F , the unit stops. It starts again only when the outdoor pipe temperature is less than 125°F .

Recommended parts to prepare:

- · Connection wires
- Condenser temperature sensor
- Outdoor fan
- Outdoor main PCB
- · Refrigerant




8.7.23 PC 06 (Discharge temperature protection of compressor diagnosis and solution)

Description: If the compressor discharge temperature exceeds a certain level for nine seconds, the compressor stops operation, the LED displays the failure code

Recommended parts to prepare:

- · Connection wires
- Discharge temperature sensor
- · Additional refrigerant
- · Outdoor main PCB

Troubleshooting and repair:




Note: For certain models, outdoor unit uses combination sensor, T3,T4 and TP are the same of sensor. This picture and the value are only for reference, actual appearance and value may vary.

8.7.24 EH 0b(Communication error between indoor two chips diagnosis and solution)

Description: Indoor PCB main chip does not receive feedback from another chip.

Recommended parts to prepare:

- · Indoor main board
- · Adapter board
- Troubleshooting and repair:




8.7.25 EL 16(Communication malfunction between adapter board and outdoor main board diagnosis and solution)

Description: The adapter PCB cannot detect the main control board.

Recommended parts to prepare:

- · Connection wires
- Adapter board
- Outdoor main PCB

Troubleshooting and repair:



8.7.26 Indoor and outdoor mismatch malfunction diagnosis and solution

Description: Indoor and outdoor units are mismatched, the LED displays this code. Please replace the matching indoor or outdoor unit.


8.7.27 PC 41(Outdoor compressor current sampling circuit failure diagnosis and solution)

Description: Three-phase sampling offset voltage error, the static bias voltage is normally 2.5V

Recommended parts to prepare:

Outdoor main PCB

Troubleshooting and repair:




8.7.28 EH b3 (Communication error between wired controller and indoor unit Diagnosis and Solution

Description: If Indoor PCB does not receive feedback from wired controller, the error displays on the wired controller

Recommended parts to prepare:

- · Connection wires
- Indoor PCB
- · Wired controller




8.8 Check Procedures

8.8.1 Temperature Sensor Check

WARNING

Be sure to turn off all power supplies or disconnect all wires to avoid electric shock. Operate after compressor and coil have returned to normal temperature in case of injury.


- 1. Disconnect temperature sensor from PCB (Refer to Chapter 9. Indoor Disassembly and Chapter 10. Outdoor Disassembly).
- 2. Measure the resistance value of the sensor using a multi-meter.
- 3. Check corresponding temperature sensor resistance value table (Refer to Chapter 11. Appendix).



Note: The picture and the value are only for reference, actual condition and specific value may vary.

8.8.2 Compressor Check

- 1. Disconnect the compressor power cord from outdoor PCB (Refer to Chapter 10. Outdoor Unit Disassembly)).
- 2. Measure the resistance value of each winding using a multi-meter.
- 3. Check the resistance value of each winding in the following table.



Note: The picture and the value are only for reference, actual condition and specific value may vary.


8.8.3 IPM Continuity Check

NARNING

Electricity remains in capacitors even when the power supply is off. Ensure the capacitors are fully discharged before troubleshooting.

- 1. Turn off outdoor unit and disconnect power supply.
- 2. Discharge electrolytic capacitors and ensure all energy-storage unit has been discharged.
- 3. Disassemble outdoor PCB or disassemble IPM board.
- 4. Measure the resistance value between P and U(V, W, N); U(V, W) and N.

Digital	tester	Resistance value	Digita	l tester	Resistance value
(+)Red	(-)Black		(+)Red	(-)Black	
	N	∞	U		∞
	U	(Several MΩ)	V		(Several MΩ)
Р	V		W	N	
	W		-	1	



Note: The picture and the value are only for reference, actual condition and specific value may vary. Normal voltage of P and N

208-240V(1-phase,3-phase)			380-415V(3-phase)
In standby			
around 310VDC around 530VDC			around 530VDC
In operation			
With passive PFC module	With partial active PFC module	With fully active PFC module	/
>200VDC	>310VDC	>370VDC	>450VDC

8.8.4 4-way Valve Check

1. Power on, use a digital tester to measure the voltage, when the unit operates in cooling, it is 0V. When the unit operates in heating, it is about 230VAC.

If the value of the voltage is not in the range, the PCB must have problems and need to be replaced.



2 Turn off the power, use a digital tester to measure the resistance. The value should be 1.8~2.5 K Ω




8.8.5 EEV Check

Electricity remains in capacitors even when the power supply is off. Ensure the capacitors are fully discharged before troubleshooting.

1. Disconnect the connector from outdoor PCB.

- 2. Measure the resistance value of each winding using a multi-meter.
- 3. Check the resistance value of each winding in the following table.




Color of lead winding	Normal Value
Red- Blue	
Red - Yellow	About 500
Brown-Orange	About 50Ω
Brown-White	


8.8.6 Fuse of Electric Auxiliary Heat Module Check(Optional)

- 1. Disassemble the fuse from electric auxiliary heat module.
- 2. Use the multimeter signal gear to check whether there is a signal, if not, fuse is broken.


9. Indoor Unit Disassembly-Air Handle

9.1 Electrical Parts (Antistatic gloves must be worn.)






9.2 Fan Motor and Fan




Procedure	Illustration
3) Release 3 nuts fixing the fan motor and then take out the fan motor. (see AHU_8)	
4) Release the 1 nut fixing the fan and then take out the fan. (see AHU_9)	AHU_8
	AHU_9


9.3 Evaporator

Procedure	Illustration
1) Remove the cover plate (see AHU_10)	
2) Remove 3 screws of cover plate assembly(below) (see AHU_11)	HU_10



9.4 Electric Auxiliary Heat Module (Optional)





10. Outdoor Unit Disassembly-Air Handle

10.1 Outdoor Unit Table


Outdoor Unit Model	Panel Plate	PCB Board
ESCA16H-36	E30	PCB Board 8
ESCA16H-36	E30	PCB Board 8

10.2 Outdoor Unit Disassembly

10.2.1 Panel Plate

Procedure	Illustration
 Turn off the air conditioner and the power breaker. Remove the screws of the big handle and then remove the big handle (2 screws) (see E30_1). 	
	E30_1
 Remove the screws of the top cover and then remove the top cover (4 screws). Two of the screws is located underneath the big handle (see E30_2). 	F30_2
4) Remove the screws of water collecting cover and then remove the water collecting cover (2 screw) (see E30_3).	$F30_3$

Procedure	Illustration
5) Remove the screws of the front right panel and then remove the front right panel (2 screws) (see E30_4).	<image/> <image/>



10.2.2 Electrical Parts

WARING: Antistatic gloves must be worn when you disassemble the electronic box.

Note: Remove the air outlet grille(refer to 10.2.1 Panel Plate) before disassembling electrical parts.

PCB board


 Remove 2 screws to disconnect the power supply wires. (see ODU_PCB_1) Remove 3 screws to disconnect ground wires. (see ODU_PCB_1) Disconnect the wires connected to main control board. (see ODU_PCB_1) Disconnect the wires between main control board and IPM module board. (see ODU_PCB_1) Remove the 4 screws and unfix the 6 hooks and then remove the main control board. (see ODU_PCB_1) Remove 1 screw to remove the fan motor capacitor(1 screw for each capacitor).(see ODU_PCB_1). 	 power supply wires. (see ODU_PCB_1) 2) Remove 3 screws to disconnect ground wires. (see ODU_PCB_1) 3) Disconnect the wires connected to main control board. (see ODU_PCB_1) 4) Disconnect the wires between main control board and IPM module board. (see ODU_PCB_1) 5) Remove the 4 screws and unfix the 6 hooks and then remove the main control board.(see ODU_PCB_1) 6) Remove 1 screw to remove the fan 	 power supply wires. (see ODU_PCB_1) 2) Remove 3 screws to disconnect ground wires. (see ODU_PCB_1) 3) Disconnect the wires connected to main control board. (see ODU_PCB_1) 4) Disconnect the wires between main control board and IPM module board. (see ODU_PCB_1) 	 power supply wires. (see ODU_PCB_1) 2) Remove 3 screws to disconnect ground wires. (see ODU_PCB_1) 3) Disconnect the wires connected to main control board. (see ODU_ 	 power supply wires. (see ODU_ PCB_1) 2) Remove 3 screws to disconnect ground wires. (see ODU_ PCB_1)
connect to indoor unit T3&T4 TP AC Fan motors connect to IPM Fan motor capacitors	capacitor).(see ODU_PCB_1).	 b) Remove the 4 screws and dimix the 6 hooks and then remove the main control board.(see ODU_PCB_1) 6) Remove 1 screw to remove the fan 	control board and IPM module board.	main control board. (see ODU_
 main control board. (see ODU_PCB_1) 4) Disconnect the wires between main control board and IPM module board. (see ODU_PCB_1) 5) Remove the 4 screws and unfix the 6 hooks and then remove the main control board.(see ODU_PCB_1) 6) Remove 1 screw to remove the fan motor capacitor(1 screw for each capacitor).(see ODU_PCB_1). 	 main control board. (see ODU_PCB_1) 4) Disconnect the wires between main control board and IPM module board. (see ODU_PCB_1) 5) Remove the 4 screws and unfix the 6 hooks and then remove the main control board.(see ODU_PCB_1) 6) Remove 1 screw to remove the fan 	 main control board. (see ODU_PCB_1) 4) Disconnect the wires between main control board and IPM module board. (see ODU_PCB_1) 	main control board. (see ODU_	
 ground wires. (see ODU_ PCB_1) 3) Disconnect the wires connected to main control board. (see ODU_ PCB_1) 4) Disconnect the wires between main control board and IPM module board. (see ODU_PCB_1) 5) Remove the 4 screws and unfix the 6 hooks and then remove the main control board.(see ODU_ PCB_1) 6) Remove 1 screw to remove the fan motor capacitor(1 screw for each capacitor).(see ODU_PCB_1). 	 ground wires. (see ODU_PCB_1) 3) Disconnect the wires connected to main control board. (see ODU_PCB_1) 4) Disconnect the wires between main control board and IPM module board. (see ODU_PCB_1) 5) Remove the 4 screws and unfix the 6 hooks and then remove the main control board.(see ODU_PCB_1) 6) Remove 1 screw to remove the fan 	 ground wires. (see ODU_ PCB_1) 3) Disconnect the wires connected to main control board. (see ODU_ PCB_1) 4) Disconnect the wires between main control board and IPM module board. (see ODU_PCB_1) 	ground wires. (see ODU_ PCB_1) 3) Disconnect the wires connected to main control board. (see ODU_	ground wires. (see ODU_ PCB 1)

PCB board

Procedure

- Remove 2 screws to disconnect the power supply wires. (see ODU_PCB_2)
- 2) Remove 3 screws to disconnect the wires connected to the compressor. (see ODU_PCB_2)
- 3) Remove 3 screws to remove the radiator.(see ODU_PCB_2)
- 4) Disconnect the wires between IPM module board and main control board. (see ODU_ PCB_2)
- 5) Remove the 4 screws and unfix the 4 hooks and then remove the IPM moduel board.(see ODU_PCB_2)

Illustration



6) Remove the 1 screw and disconnect the wires and then remove the 24V board.(see ODU_PCB_3)(for some models)

PCB board

Procedure	Illustration
1) Remove the 1 screw and disconnect the wires and then remove the key board.(see ODU_ PCB_4)	ODU_PCB_4

10.2.3 Fan Assembly

Note: Remove the panel plate (refer to 10.2.1 Panel Plate) before disassembling fan.

Procedure	Illustration
 Remove the nut securing the fan with a spanner (see ODU_ FAN_1&2). Remove the fan. 	
	ODU_FAN_1
	ODU_FAN_2
L	<u> </u>


10.2.4 Fan Motor

Note: Remove the panel plate and the connection of fan motor on PCB (refer to 10.2.1 Panel Plate and 10.2.2 Electrical parts) before disassembling fan motor.

Procedure	Illustration
 3) Remove the fixing screws of the fan motor (4 screws) (see ODU_MOTOR_1). 4) Remove the fan motor. 	<image/> <section-header></section-header>

10.2.5 Sound Blanket


Note: Remove the panel plate (refer to 10.2.1 Panel plate) before disassembling sound blanket.



10.2.6 Four-way valve(for heat pump models)

WARNING: Evacuate the system and confirm that there is no refrigerant left in the system before removing the four-way valve and the compressor.

Note: Remove the panel plate, connection of four-way valve on PCB (refer to 10.2.1 Panel plate and 10.2.2 Electrical parts) before disassembling sound blanket.



10.2.7 Compressor

WARNING: Evacuate the system and confirm that there is no refrigerant left in the system before removing the four-way valve and the compressor. (For R32 & R290, you should evacuate the system with the vacuum pump; flush the system with nitrogen; then repeat the two steps before heating up the brazed parts. The operations above should be implemented by professionals.)

Note: Remove the panel plate, connection of compressor on PCB (refer to 10.2.1 Panel plate and 10.2.2 Electrical parts) before disassembling sound blanket.

Procedure	Illustration
1) Remove the flange nut of terminal cover and remove the terminal cover (see ODU_COMP_1).	Terminal Cover
2) Disconnect the connectors (see ODU_ COMP_2).	ODU_COMP_1

10.2.7 Compressor

Procedure	Illustration
 Remove the hex nuts and washers securing the compressor, located on the bottom plate (see ODU_COMP_3). 	
	ODU_COMP_3
 4) Heat up the brazed parts and then remove the the discharge pipe and the suction pipe (see ODU_COMP_4). 5) Lift the compressor from the base pan assembly with pliers. 	Discharge Pipe
	ODU_COMP_4

Appendix

Contents

- i) Temperature Sensor Resistance Value Table for T1, T2, T3, and T4 (°C K)
- ii) Temperature Sensor Resistance Value Table for TP (for some units)(°C --K)
- iii) Pressure On Service Port

i) Temperature Sensor Resistance Value Table for T1,T2,T3 and T4 (°C – K)

°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm
-20	-4	115.266	20	68	12.6431	60	140	2.35774	100	212	0.62973
-19	-2	108.146	21	70	12.0561	61	142	2.27249	101	214	0.61148
-18	0	101.517	22	72	11.5	62	144	2.19073	102	216	0.59386
-17	1	96.3423	23	73	10.9731	63	145	2.11241	103	217	0.57683
-16	3	89.5865	24	75	10.4736	64	147	2.03732	104	219	0.56038
-15	5	84.219	25	77	10	65	149	1.96532	105	221	0.54448
-14	7	79.311	26	79	9.55074	66	151	1.89627	106	223	0.52912
-13	9	74.536	27	81	9.12445	67	153	1.83003	107	225	0.51426
-12	10	70.1698	28	82	8.71983	68	154	1.76647	108	226	0.49989
-11	12	66.0898	29	84	8.33566	69	156	1.70547	109	228	0.486
-10	14	62.2756	30	86	7.97078	70	158	1.64691	110	230	0.47256
-9	16	58.7079	31	88	7.62411	71	160	1.59068	111	232	0.45957
-8	18	56.3694	32	90	7.29464	72	162	1.53668	112	234	0.44699
-7	19	52.2438	33	91	6.98142	73	163	1.48481	113	235	0.43482
-6	21	49.3161	34	93	6.68355	74	165	1.43498	114	237	0.42304
-5	23	46.5725	35	95	6.40021	75	167	1.38703	115	239	0.41164
-4	25	44	36	97	6.13059	76	169	1.34105	116	241	0.4006
-3	27	41.5878	37	99	5.87359	77	171	1.29078	117	243	0.38991
-2	28	39.8239	38	100	5.62961	78	172	1.25423	118	244	0.37956
-1	30	37.1988	39	102	5.39689	79	174	1.2133	119	246	0.36954
0	32	35.2024	40	104	5.17519	80	176	1.17393	120	248	0.35982
1	34	33.3269	41	106	4.96392	81	178	1.13604	121	250	0.35042
2	36	31.5635	42	108	4.76253	82	180	1.09958	122	252	0.3413
3	37	29.9058	43	109	4.5705	83	181	1.06448	123	253	0.33246
4	39	28.3459	44	111	4.38736	84	183	1.03069	124	255	0.3239
5	41	26.8778	45	113	4.21263	85	185	0.99815	125	257	0.31559
6	43	25.4954	46	115	4.04589	86	187	0.96681	126	259	0.30754
7	45	24.1932	47	117	3.88673	87	189	0.93662	127	261	0.29974
8	46	22.5662	48	118	3.73476	88	190	0.90753	128	262	0.29216
9	48	21.8094	49	120	3.58962	89	192	0.8795	129	264	0.28482
10	50	20.7184	50	122	3.45097	90	194	0.85248	130	266	0.2777
11	52	19.6891	51	124	3.31847	91	196	0.82643	131	268	0.27078
12	54	18.7177	52	126	3.19183	92	198	0.80132	132	270	0.26408
13	55	17.8005	53	127	3.07075	93	199	0.77709	133	271	0.25757
14	57	16.9341	54	129	2.95896	94	201	0.75373	134	273	0.25125
15	59	16.1156	55	131	2.84421	95	203	0.73119	135	275	0.24512
16	61	15.3418	56	133	2.73823	96	205	0.70944	136	277	0.23916
17	63	14.6181	57	135	2.63682	97	207	0.68844	137	279	0.23338
18	64	13.918	58	136	2.53973	98	208	0.66818	138	280	0.22776
19	66	13.2631	59	138	2.44677	99	210	0.64862	139	282	0.22231


Manufacturer reserves the right to change specifications or designs without notice.

ii) Temperature Sensor Resistance Value Table for TP(for some units) (°C --K)

°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm	°C	°F	K Ohm
°C	۴	K Ohm	°C	۴	K Ohm	°C	۴	K Ohm	°C	۴	K Ohm
-20	-4	542.7	20	68	68.66	60	140	13.59	100	212	3.702
-19	-2	511.9	21	70	65.62	61	142	13.11	101	214	3.595
-18	0	483	22	72	62.73	62	144	12.65	102	216	3.492
-17	1	455.9	23	73	59.98	63	145	12.21	103	217	3.392
-16	3	430.5	24	75	57.37	64	147	11.79	104	219	3.296
-15	5	406.7	25	77	54.89	65	149	11.38	105	221	3.203
-14	7	384.3	26	79	52.53	66	151	10.99	106	223	3.113
-13	9	363.3	27	81	50.28	67	153	10.61	107	225	3.025
-12	10	343.6	28	82	48.14	68	154	10.25	108	226	2.941
-11	12	325.1	29	84	46.11	69	156	9.902	109	228	2.86
-10	14	307.7	30	86	44.17	70	158	9.569	110	230	2.781
-9	16	291.3	31	88	42.33	71	160	9.248	111	232	2.704
-8	18	275.9	32	90	40.57	72	162	8.94	112	234	2.63
-7	19	261.4	33	91	38.89	73	163	8.643	113	235	2.559
-6	21	247.8	34	93	37.3	74	165	8.358	114	237	2.489
-5	23	234.9	35	95	35.78	75	167	8.084	115	239	2.422
-4	25	222.8	36	97	34.32	76	169	7.82	116	241	2.357
-3	27	211.4	37	99	32.94	77	171	7.566	117	243	2.294
-2	28	200.7	38	100	31.62	78	172	7.321	118	244	2.233
-1	30	190.5	39	102	30.36	79	174	7.086	119	246	2.174
0	32	180.9	40	104	29.15	80	176	6.859	120	248	2.117
1	34	171.9	41	106	28	81	178	6.641	121	250	2.061
2	36	163.3	42	108	26.9	82	180	6.43	122	252	2.007
3	37	155.2	43	109	25.86	83	181	6.228	123	253	1.955
4	39	147.6	44	111	24.85	84	183	6.033	124	255	1.905
5	41	140.4	45	113	23.89	85	185	5.844	125	257	1.856
6	43	133.5	46	115	22.89	86	187	5.663	126	259	1.808
7	45	127.1	47	117	22.1	87	189	5.488	127	261	1.762
8	46	121	48	118	21.26	88	190	5.32	128	262	1.717
9	48	115.2	49	120	20.46	89	192	5.157	129	264	1.674
10	50	109.8	50	122	19.69	90	194	5	130	266	1.632
11	52	104.6	51	124	18.96	91	196	4.849			
12	54	99.69	52	126	18.26	92	198	4.703			
13	55	95.05	53	127	17.58	93	199	4.562			
14	57	90.66	54	129	16.94	94	201	4.426			
15	59	86.49	55	131	16.32	95	203	4.294			
16	61	82.54	56	133	15.73	96	205	4.167			
17	63	78.79	57	135	15.16	97	207	4.045			
18	64	75.24	58	136	14.62	98	208	3.927			
19	66	71.86	59	138	14.09	99	210	3.812			


Cooling chart(R410A):

°F(°C)	ODU(DB)	0 (-17)	5 (-15)	15 (-9.44)	45 (7.22)	75 (23.89)	85 (29.44)	95 (35)	105 (40.56)	115 (46.11)	120 (48.89)
	70/59 (21.11/15)	6.4	6.5	7.3	8.0	8.2	7.8	8.1	8.6	10.1	10.6
	75/63 (23.89/17.22)	6.7	6.8	7.9	8.6	8.6	8.3	8.7	9.1	10.7	11.2
BAR	80/67 (26.67/19.44)	7.1	7.2	8.5	9.5	9.3	8.9	9.1	9.6	11.2	11.9
	90/73 (32.22/22.78)	7.7	7.8	9.6	10.5	10.3	9.5	10.0	10.6	12.4	13.0
	70/59 (21.11/15)	93	94	106	116	119	113	117	125	147	154
PSI	75/63 (23.89/17.22)	97	99	115	125	124	120	126	132	155	162
	80/67 (26.67/19.44)	103	104	123	138	135	129	132	140	162	173
	90/73 (32.22/22.78)	112	113	139	152	149	138	145	154	180	189
	70/59 (21.11/15)	0.64	0.65	0.73	0.8	0.82	0.78	0.81	0.86	1.01	1.06
MPa	75/63 (23.89/17.22)	0.67	0.68	0.79	0.86	0.86	0.83	0.87	0.91	1.07	1.12
MPa	80/67 (26.67/19.44)	0.71	0.72	0.85	0.95	0.93	0.89	0.91	0.96	1.12	1.19
	90/73 (32.22/22.78)	0.77	0.78	0.96	1.05	1.03	0.95	1	1.06	1.24	1.3



°F(°C)	ODU(DB/WB)	57/53 (13.89/11.67)	47/43 (8.33/6.11)	37/33 (2.78/0.56)	27/23 (-2.78/-5)	17/13 (-8.33/ -10.56)	0/-2 (-17/-19)	-17/-18 (-27/-28)
	55(12.78)	30.3	28.5	25.3	22.8	20.8	18.5	16.5
BAR	65(18.33)	32.5	30.0	26.6	25.4	23.3	20.5	19.0
	75(23.89)	33.8	31.5	27.8	26.3	24.9	21.5	20.0
	55(12.78)	439	413	367	330	302	268	239
PSI	65(18.33)	471	435	386	368	339	297	276
	75(23.89)	489	457	403	381	362	312	290
	55(12.78)	3.03	2.85	2.53	2.28	2.08	1.85	1.65
MPa	65(18.33)	3.25	3.00	2.66	2.54	2.33	2.05	1.90
	75(23.89)	3.38	3.15	2.78	2.63	2.49	2.15	2.00

Heating chart(R410A):



System Pressure Table-R410A

Pressure			Te	emperature		Pressure	Temperature		
Кра	bar	PSI	°C	۴	Кра	bar	PSI	°C	۴
100	1	14.5	-51.623	-60.921	2350	23.5	340.75	38.817	101.871
150	1.5	21.75	-43.327	-45.989	2400	24	348	39.68	103.424
200	2	29	-36.992	-34.586	2450	24.5	355.25	40.531	104.956
250	2.5	36.25	-31.795	-25.231	2500	25	362.5	41.368	106.462
300	3	43.5	-27.351	-17.232	2550	25.5	369.75	42.192	107.946
350	3.5	50.75	-23.448	-10.206	2600	26	377	43.004	109.407
400	4	58	-19.953	-3.915	2650	26.5	384.25	43.804	110.847
450	4.5	65.25	-16.779	1.798	2700	27	391.5	44.592	112.266
500	5	72.5	-13.863	7.047	2750	27.5	398.75	45.37	113.666
550	5.5	79.75	-11.162	11.908	2800	28	406	46.136	115.045
600	6	87	-8.643	16.444	2850	28.5	413.25	46.892	116.406
650	6.5	94.25	-6.277	20.701	2900	29	420.5	47.638	117.748
700	7	101.5	-4.046	24.716	2950	29.5	427.75	48.374	119.073
750	7.5	101.5	-1.933	28.521	3000	30	435	49.101	120.382
800	8	116	0.076	32.137	3050	30.5	442.25	49.818	120.502
850	8.5	123.25	1.993	35.587	3100	30.5	449.5	50.525	121.072
900	9	130.5	3.826	38.888	3150	31.5	456.75	51.224	124.203
950	9.5	137.75	5.584	42.052	3200	32	464	51.914	124.205
1000	9.3 10	145	7.274	45.093	3250	32.5	404	52.596	126.673
1050	10.5	152.25	8.901	48.022	3300	33	471.23	53.27	120.073
1100	10.5	152.25	10.471	50.848	3350	33.5	478.5	53.935	127.000
						33.5	405.75		129.063
1150	11.5 12	166.75 174	11.988	53.578	3400	-		54.593	
1200			13.457	56.223	3450	34.5	500.25	55.243	131.437
1250	12.5 13	181.25	14.879	58.782	3500	35	507.5	55.885	132.593
1300	-	188.5	16.26	61.268	3550	35.5	514.75	56.52	133.736
1350	13.5	195.75	17.602	63.684	3600	36	522	57.148	134.866
1400	14	203	18.906	66.031	3650	36.5	529.25	57.769	135.984
1450	14.5	210.25	20.176	68.317	3700	37	536.5	58.383	137.089
1500	15	217.5	21.414	70.545	3750	37.5	543.75	58.99	138.182
1550	15.5	224.75	22.621	72.718	3800	38	551	59.591	139.264
1600	16	232	23.799	74.838	3850	38.5	558.25	60.185	140.333
1650	16.5	239.25	24.949	76.908	3900	39	565.5	60.773	141.391
1700	17	246.5	26.074	78.933	3950	39.5	572.75	61.355	142.439
1750	17.5	253.75	27.174	80.913	4000	40	580	61.93	143.474
1800	18	261	28.251	82.852	4050	40.5	587.25	62.499	144.498
1850	18.5	268.25	29.305	84.749	4100	41	594.5	63.063	145.513
1900	19	275.5	30.338	86.608	4150	41.5	601.75	63.62	146.516
1950	19.5	282.75	31.351	88.432	4200	42	609	64.172	147.510
2000	20	290	32.344	90.219	4250	42.5	616.25	64.719	148.494
2050	20.5	297.25	33.319	91.974	4300	43	623.5	65.259	149.466
2100	21	304.5	34.276	93.697	4350	43.5	630.75	65.795	150.431
2150	21.5	311.75	35.215	95.387	4400	44	638	66.324	151.383
2200	22	319	36.139	97.050	4450	44.5	645.25	66.849	152.328
2250	22.5	326.25	37.047	98.685	4500	45	652.5	67.368	153.262
2300	23	333.5	37.939	100.290					

©2023 ECOER INC.

43671 Trade Center Place, Suite 100 Dulles, VA 20166 USA

Tel: 703-348-2538

www.ecoer.com